

SAILOR 900 VSAT System



SAILOR 900 VSAT

Installation and user manual

Document number: 98-133400-C

Release date: 13 January 2012

Disclaimer

Any responsibility or liability for loss or damage in connection with the use of this product and the accompanying documentation is disclaimed by Thrane & Thrane. The information in this manual is provided for information purposes only, is subject to change without notice and may contain errors or inaccuracies. Manuals issued by Thrane & Thrane are periodically revised and updated. Anyone relying on this information should acquire the most current version e.g. from <http://www.thrane.com> or from the distributor. Thrane & Thrane is not responsible for the content or accuracy of any translations or reproductions, in whole or in part, of this manual from any other source.

Copyright

© 2012 Thrane & Thrane A/S. All rights reserved.

Trademark acknowledgements

- **Thrane & Thrane** is a registered trademark of Thrane & Thrane A/S in the European Union and the United States.
- **SAILOR** is a registered trademark of Thrane & Thrane A/S in the European Union and the United States.
- **Windows** is a registered trademark of Microsoft Corporation in the United States and other countries.
- Other product and company names mentioned in this manual may be trademarks or trade names of their respective owners.

GPL notification

The software included in this product contains copyrighted software that is licensed under the GPL/LGPL. The verbatim licenses can be found online at:

<http://www.gnu.org/licenses/old-licenses/gpl-2.0.html>

<http://www.gnu.org/licenses/old-licenses/lgpl-2.1.html>

You may obtain the complete corresponding source code from us for a period of three years after our last shipment of this product, which will be no earlier than 2021, by sending a money order or check for DKK 50 to:

SW Technology/GPL Compliance,
Thrane & Thrane A/S,
Lundtoftegaardsvej 93D
2800 Lyngby
DENMARK

Please write "source for product SAILOR 900 VSAT" in the memo line of your payment. You may also find a copy of the source at <http://www.thrane.com/foss>. This offer is valid to anyone in receipt of this information.


Safety summary

The following general safety precautions must be observed during all phases of operation, service and repair of this equipment. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture and intended use of the equipment. Thrane & Thrane A/S assumes no liability for the customer's failure to comply with these requirements.

Microwave radiation hazards

During transmission the Above Deck Unit (antenna) in this system radiates Microwave Power. This radiation may be hazardous to humans close to the Above Deck Unit. During transmission, make sure that nobody gets closer than the recommended minimum safety distance.

The minimum safety distance to the Above Deck Unit reflector on the focal line is 30 m, based on a radiation level of 10 W/m^2 . No hazard exists $>25^\circ$ below the Above Deck Unit's mounting plane. Refer to the drawing below.



No-transmit zones

In order to protect personnel no-transmit zones can be programmed. For further information see *Blocking zones – azimuth and elevation* on page 3-5.

Distance to other equipment

Do not move the Above Deck Unit closer to radars than the minimum safe distance specified in section *Interference* on page 3-13 – it may cause damage to the Above Deck Unit.

Compass Safe Distance:

SAILOR 900 VSAT antenna or ADU (Above Deck Unit): min. 130 cm (IEC 945).

SAILOR 900 VSAT ACU (Antenna Control Unit): min. 10 cm (IEC 945)

Service

User access to the interior of the ACU is prohibited. Only a technician authorized by Thrane & Thrane A/S may perform service - failure to comply with this rule will void the warranty. Access to the interior of the Above Deck Unit is allowed. Replacement of certain modules and general service may only be performed by a technician authorized by Thrane & Thrane A/S.

Grounding, cables and connections

To minimize shock hazard and to protect against lightning, the equipment chassis and cabinet must be connected to an electrical ground. The ACU must be grounded to the ship. For further grounding information refer to the Installation manual.

Do not extend the cables beyond the lengths specified for the equipment. The cable between the ACU and Above Deck Unit can be extended if it complies with the specified data concerning cable losses etc.

Rx and Tx cables for the SAILOR 900 VSAT system are shielded and should not be affected by magnetic fields. However, try to avoid running cables parallel to high power and AC/RF wiring as it might cause malfunction of the equipment.

Power supply

The voltage range for the SAILOR 900 VSAT is 20 – 32 VDC. Note that the Above Deck Unit is powered by the ACU.

If a 24 VDC power bus is not available, an external 115/230 VAC to 28 VDC power supply can be used, for example a SAILOR 6080 Power Supply.

Do not operate in an explosive atmosphere

Do not operate the equipment in the presence of flammable gases or fumes. Operation of any electrical equipment in such an environment constitutes a definite safety hazard.

Keep away from live circuits

Operating personnel must not remove equipment covers. Component replacement and internal adjustment must be made by qualified maintenance personnel. Do not replace components with the power cable connected. Under certain conditions, dangerous voltages may exist even with the power cable removed. To avoid injuries, always disconnect power and discharge circuits before touching them.

Failure to comply with the rules above will void the warranty!

VSAT restrictions

Note

There are restrictions in use of the frequency band 13.75 to 14 GHz in the following countries:

- Belgium
- Hungary
- Latvia
- Malta
- Slovakia

Contact VSAT modem provider for local setups.

Record of Revisions

| Rev. | Description | Release Date | Initials |
|------|---|-------------------|----------|
| A | Original document | 26 September 2011 | UFO |
| B | <p>The following sections have been added: 6.3.6, 6.3.7, 6.3.8, 9.4, Appendix B, Appendix C.</p> <p>The following sections have been edited: 1.2, 3.1.1, 3.2.6 (p. 3-10) 3.6.1, 4.1.7, 6.2.2, 6.3, 9.1.1.</p> <p>The following figures have been added: 6-3, A-1, A-2,</p> <p>The following figures have been edited: 2-4, 2-5, 6-4, 6-5, 6-6, 6-7, 6-14, 8-1, 9-10, 9-11.</p> <p>The following tables have been edited: 2-1, 2-2, 6-5.</p> | 8 November 2011 | UFO |
| C | <p>The following sections have been added: p.v (VSAT restrictions), 1.3, 3.32, App. D,</p> <p>The following sections have been edited: 4.1.8, 4.1.10, 6.2.1, 6.2.2, 6.3.3, 6.3.4, 6.3.5, 6.3.6, 6.3.10,</p> <p>The following figures have been edited: 2-4, 6-8, 6-9, 6-11, 6-17, 9-5, 9-10</p> <p>The following tables have been added: 6-5, 6-6,</p> <p>The following tables have been edited: 6-3, 6-9, F-1, F-2</p> | 13 January 2012 | UFO |

Table of Contents

| | | |
|----------------------|--|------|
| Chapter 1 | About this manual | |
| | 1.1 Intended readers | 1-1 |
| | 1.2 Manual overview | 1-1 |
| | 1.3 Software version | 1-2 |
| | 1.4 Related documents | 1-2 |
| | 1.5 Typography | 1-2 |
| | 1.6 Precautions | 1-2 |
| Chapter 2 | Introduction | |
| | 2.1 SAILOR 900 VSAT system | 2-1 |
| | 2.1.1 Above Deck Unit (ADU) | 2-3 |
| | 2.1.2 Antenna Control Unit (ACU) | 2-6 |
| | 2.1.3 VSAT Modem Unit (VMU) | 2-9 |
| | 2.1.4 Satellite type approvals | 2-9 |
| | 2.1.5 Power supply | 2-9 |
| | 2.1.6 Service activation | 2-9 |
| | 2.2 Part numbers and options | 2-10 |
| | 2.2.1 Applicable Thrane & Thrane model- and part numbers | 2-10 |
| | 2.2.2 Options for SAILOR 900 VSAT | 2-10 |

Chapter 3**Installation**

| | |
|--|------|
| 3.1 Unpacking | 3-1 |
| 3.1.1 What's in the box | 3-1 |
| 3.1.2 Initial inspection | 3-2 |
| 3.1.3 Tools needed | 3-2 |
| 3.2 Site preparation | 3-3 |
| 3.2.1 General site considerations | 3-3 |
| 3.2.2 Obstructions (ADU shadowing) | 3-3 |
| 3.2.3 Blocking zones – azimuth and elevation | 3-5 |
| 3.2.4 Safe access to the ADU: Radiation hazard | 3-6 |
| 3.2.5 Ship motion and offset from the ship's motion centre | 3-7 |
| 3.2.6 ADU mast design: Foundation and height | 3-8 |
| 3.2.7 Interference | 3-13 |
| 3.2.8 Other precautions | 3-17 |
| 3.3 Installation of the ADU | 3-18 |
| 3.3.1 Installing the ADU | 3-19 |
| 3.3.2 Opening and removing the service hatch | 3-22 |
| 3.3.3 Grounding the ADU | 3-23 |
| 3.3.4 Alternative ADU cable | 3-23 |
| 3.4 Installation of the ACU (bulkhead) | 3-24 |
| 3.4.1 Installing the ACU (bulkhead) | 3-24 |
| 3.4.2 Grounding the ACU (bulkhead) | 3-25 |
| 3.4.3 SAILOR 900 VSAT ACU (bulkhead) with cable support | 3-25 |
| 3.5 Installation of the 19" rack version of the ACU | 3-27 |
| 3.5.1 Installing the 19" rack version of the ACU | 3-27 |
| 3.5.2 Grounding the 19" rack version of the ACU | 3-28 |
| 3.6 Installation of the VMU | 3-29 |
| 3.6.1 General mounting considerations – VMU | 3-29 |

| | | |
|------------------|--|------|
| Chapter 4 | Interfaces | |
| | 4.1 Interfaces of the SAILOR 900 VSAT ACU | 4-1 |
| | 4.1.1 ACU bulkhead – LEDs, display and keypad | 4-1 |
| | 4.1.2 ACU 19” rack version – LEDs, display and keypad | 4-1 |
| | 4.1.3 ACU bulkhead – Connector panel – overview | 4-2 |
| | 4.1.4 ACU 19” rack version – Connector panel – overview | 4-2 |
| | 4.1.5 DC Input connector | 4-3 |
| | 4.1.6 ADU connector | 4-4 |
| | 4.1.7 Rx/Tx connectors for VMU | 4-4 |
| | 4.1.8 NMEA 0183/2000 connector | 4-5 |
| | 4.1.9 RS-232 and RS-422 connectors | 4-6 |
| | 4.1.10 LAN1, LAN2, LAN3 and LAN4 connectors | 4-7 |
| | 4.2 Interfaces of the VMU | 4-9 |
| | 4.2.1 Connecting an iNFINITI® 5000 Series Satellite Router | 4-9 |
| | 4.2.2 Connecting an Evolution® X5 Satellite Router | 4-10 |
| | 4.2.3 Connecting a Comtech 570 L or 625 Satellite Modem | 4-11 |
| Chapter 5 | Connecting power | |
| | 5.1 Power source | 5-1 |
| | 5.2 Power cable selection | 5-2 |
| | 5.2.1 Source impedance | 5-2 |
| | 5.2.2 Measuring the ship source impedance | 5-2 |
| | 5.2.3 Power cable recommendations | 5-3 |
| | 5.3 Connecting power | 5-4 |
| | 5.4 Power up | 5-5 |
| Chapter 6 | Configuration | |
| | 6.1 Introduction to the built-in web interface | 6-1 |
| | 6.1.1 Overview | 6-1 |
| | 6.1.2 Connecting to the web interface | 6-2 |
| | 6.2 Calibration of the SAILOR 900 VSAT | 6-3 |
| | 6.2.1 Setting up a service profile for calibration | 6-4 |
| | 6.2.2 Calibration of azimuth and cable | 6-6 |

| | | |
|------------------|---|------|
| | 6.3 Configuration with the web interface | 6-8 |
| | 6.3.1 Overview and navigation | 6-8 |
| | 6.3.2 Using the Dashboard | 6-12 |
| | 6.3.3 Satellite profiles and VSAT modem profiles | 6-15 |
| | 6.3.4 Setting up Blocking zones (RX and TX) | 6-20 |
| | 6.3.5 Configuring the LAN network | 6-22 |
| | 6.3.6 E-mail setup | 6-25 |
| | 6.3.7 Sending statistics reports | 6-26 |
| | 6.3.8 Sending a diagnostic report | 6-29 |
| | 6.3.9 Upload | 6-30 |
| | 6.3.10 Administration | 6-30 |
| | 6.4 Keypad of the SAILOR 900 VSAT ACU | 6-34 |
| | 6.4.1 ACU display and keypad | 6-34 |
| | 6.4.2 Navigating the menus | 6-35 |
| | 6.4.3 The menu tree | 6-36 |
| | 6.4.4 Adjusting brightness of the display | 6-40 |
| | 6.4.5 Resetting the system | 6-40 |
| Chapter 7 | Installation check | |
| | 7.1 Installation check list: Antenna | 7-1 |
| | 7.2 Installation check list: ACU, connectors and wiring | 7-3 |
| | 7.3 Installation check list: Functional test in harbor | 7-5 |
| Chapter 8 | Daily use – Quick guide | |
| Chapter 9 | Service | |
| | 9.1 Getting support: Helpdesk | 9-2 |
| | 9.1.1 Help desk and diagnostic report | 9-2 |
| | 9.2 Software update | 9-4 |
| | 9.2.1 Software update (ADU and ACU) | 9-4 |
| | 9.2.2 Verifying the software update | 9-5 |
| | 9.3 Status signalling with LEDs and status messages | 9-7 |
| | 9.3.1 LEDs of the ADU modules | 9-8 |
| | 9.3.2 LEDs in the ACU | 9-9 |
| | 9.4 Removal and replacement of the ACU | 9-11 |
| | 9.5 Removal and replacement of ADU modules | 9-12 |

| | | |
|-------------------|---|------|
| | 9.6 Initial troubleshooting | 9-15 |
| | 9.6.1 Viewing the Event list | 9-15 |
| Appendix A | Technical specifications | |
| | A.1 SAILOR 900 VSAT system components | A-1 |
| | A.1.1 General specifications | A-1 |
| | A.1.2 ADU | A-2 |
| | A.1.3 ACU | A-4 |
| | A.1.4 Supported VSAT modems | A-5 |
| | A.2 Outline drawings | A-6 |
| | A.2.1 ADU | A-6 |
| | A.2.2 ACU, bulkhead | A-7 |
| | A.2.3 ACU, 19 inch rack | A-8 |
| Appendix B | VMU cable specifications | |
| | B.1 Modem Cable Comtech Serial & RSSI TT7016A | B-2 |
| | B.2 Modem Cable iNFINITI iDirect VSAT modem | B-3 |
| Appendix C | VMU settings requirements | |
| | C.1 Open AMIP setup for iDirect INFINITI 5000 & Evolution X5 | C-2 |
| | C.1.1 Protocol and interfaces | C-2 |
| | C.1.2 Sample options file | C-5 |
| | C.1.3 Configuration examples (OpenAMIP) | C-9 |
| | C.2 Non-Open-AMIP setup for iDirect iNFINITI 5000 & Evolution X5 | C-10 |
| | C.2.1 Protocol and interfaces | C-10 |
| | C.2.2 Console port settings | C-11 |
| | C.2.3 Configuration examples (Non-OpenAMIP) | C-13 |
| | C.3 Setup of Comtech 570L, ROSS box & ACU | C-14 |
| | C.3.1 Protocols and interfaces | C-14 |
| Appendix D | DVB S satellites | |

| | | |
|-------------------|---|------------|
| Appendix E | Grounding and RF protection | |
| | E.1 Why is grounding required? | E-1 |
| | E.1.1 Reasons for grounding | E-1 |
| | E.1.2 Safety | E-1 |
| | E.1.3 ESD Protection | E-1 |
| | E.2 Grounding Recommendations | E-2 |
| | E.2.1 Grounding the ACU | E-2 |
| | E.2.2 Grounding the ADU | E-3 |
| | E.3 Alternative grounding for steel hulls | E-4 |
| | E.3.1 Grounding the ACU | E-4 |
| | E.3.2 Grounding the ADU | E-4 |
| | E.4 Alternative grounding for aluminum hulls | E-6 |
| | E.4.1 Grounding the ACU | E-6 |
| | E.4.2 Grounding the ADU | E-6 |
| | E.5 Alternative grounding for fiberglass hulls | E-7 |
| | E.5.1 Grounding the ACU | E-7 |
| | E.5.2 Grounding the ADU | E-7 |
| | E.6 Separate ground cable | E-9 |
| | E.6.1 Ground cable - construction | E-9 |
| | E.6.2 Ground cable - connection | E-9 |
| | E.6.3 Isolation of the ADU from the mounting base | E-10 |
| | E.7 RF interference | E-11 |
| | E.7.1 Recommendations | E-11 |
| Appendix F | System messages | |
| | F.1 Event messages – overview | F-1 |
| | F.2 List of ADU events | F-2 |
| | F.3 List of ACU events | F-9 |
| Glossary | | Glossary-1 |
| Index | | Index-1 |

List of Figures

Chapter 1 About this manual

Chapter 2 Introduction

| | | |
|-------------|--|-----|
| Figure 2-1: | Above Deck Unit and Antenna Control Unit (ACU)..... | 2-2 |
| Figure 2-2: | Above Deck Unit and Antenna Control Unit (ACU), 19" rack version | 2-2 |
| Figure 2-3: | Above Deck Unit (ADU) | 2-3 |
| Figure 2-4: | Above Deck Unit modules 1/2..... | 2-4 |
| Figure 2-5: | Above Deck Unit modules 2/2 | 2-5 |
| Figure 2-6: | SAILOR 900 VSAT ACU, connector overview | 2-7 |
| Figure 2-7: | SAILOR 900 VSAT ACU, 19" rack version..... | 2-7 |
| Figure 2-8: | Antenna Control Unit for bulkhead installation..... | 2-8 |
| Figure 2-9: | Antenna Control Unit for 19" rack installation | 2-8 |

Chapter 3 Installation

| | | |
|--------------|---|------|
| Figure 3-1: | Signal degradation because of obstructing objects..... | 3-4 |
| Figure 3-2: | 2 blocking zones with no-transmit zones, azimuth (example) | 3-5 |
| Figure 3-3: | Blocking zone with no-transmit zones, elevation angle (example)..... | 3-5 |
| Figure 3-4: | Radiation hazard, safety distance 30 m | 3-6 |
| Figure 3-5: | Maximum distance from the ship's motion centre (h max) | 3-7 |
| Figure 3-6: | ADU mast flange, top and side view..... | 3-8 |
| Figure 3-7: | ADU mast flange, recommended flatness on the mast mount plateau..... | 3-8 |
| Figure 3-8: | ADU mast flange, distance to the welded seam | 3-9 |
| Figure 3-9: | ADU, bottom view | 3-9 |
| Figure 3-10: | Free mast length and bracing for a tall mast | 3-10 |
| Figure 3-11: | Interference with the vessel's radar | 3-13 |
| Figure 3-12: | Recommended distance to transmitters (m) for frequencies below 1000 MHz | 3-16 |
| Figure 3-13: | Drain pipe with free space | 3-17 |
| Figure 3-14: | Use of strong sling with a belt and tag lines for safe hoisting | 3-18 |
| Figure 3-15: | Free space for access to the service hatch..... | 3-19 |
| Figure 3-16: | ADU installation, webbed sling attached to the 4 lifting brackets..... | 3-20 |
| Figure 3-17: | Mounting the ADU on the mast flange..... | 3-20 |
| Figure 3-18: | Connecting the ADU cable | 3-21 |
| Figure 3-19: | Opening the service hatch | 3-22 |
| Figure 3-20: | Removing the 2 split pins | 3-22 |
| Figure 3-21: | Removing the service hatch | 3-22 |

| | | |
|--------------|--|------|
| Figure 3-22: | ACU, connector panel..... | 3-24 |
| Figure 3-23: | SAILOR 900 VSAT ACU, bulkhead version, ground stud | 3-25 |
| Figure 3-24: | Mounting the cable relief 1/2..... | 3-26 |
| Figure 3-25: | Mounting the cable relief 2/2 | 3-26 |
| Figure 3-26: | ACU, 19" rack version, On/off switch at the back..... | 3-27 |
| Figure 3-27: | ACU, LAN connector at the front: Service port..... | 3-28 |
| Figure 3-28: | ACU, 19" rack version, ground stud | 3-28 |

Chapter 4 Interfaces

| | | |
|-------------|--|------|
| Figure 4-1: | ACU bulkhead, LEDs, display and keypad | 4-1 |
| Figure 4-2: | ACU rack version, LEDs, display and keypad | 4-1 |
| Figure 4-3: | ACU bulkhead, connector panel overview..... | 4-2 |
| Figure 4-4: | ACU rack version, connector panel overview | 4-2 |
| Figure 4-5: | DC Input connector with power cable | 4-3 |
| Figure 4-6: | LAN1 –LAN4 connectors | 4-7 |
| Figure 4-7: | Connecting an iNFINITI® 5000 Series Satellite Router | 4-9 |
| Figure 4-8: | Connecting an Evolution X5 Satellite Router | 4-10 |
| Figure 4-9: | Connecting a Comtech 570 L or 625 Satellite Modem | 4-11 |

Chapter 5 Connecting power

| | | |
|-------------|--|-----|
| Figure 5-1: | Measuring the ship source impedance | 5-3 |
| Figure 5-2: | Connecting power to DC Input..... | 5-4 |
| Figure 5-3: | ACU display after first power on (example with LAN ports 1 and 4 used) | 5-5 |

Chapter 6 Configuration

| | | |
|--------------|--|------|
| Figure 6-1: | Configuration setup..... | 6-1 |
| Figure 6-2: | LAN connector used for configuring the SAILOR 900 VSAT | 6-2 |
| Figure 6-3: | SAILOR 900 VSAT Dashboard | 6-3 |
| Figure 6-4: | Service profile, add a Service 'modem' for calibration | 6-4 |
| Figure 6-5: | Service profile, add satellite information | 6-5 |
| Figure 6-6: | Web interface: SERVICE, Calibration: Azimuth and cable | 6-6 |
| Figure 6-7: | Topics in the web interface (SITE MAP) | 6-8 |
| Figure 6-8: | Sections of the web interface..... | 6-9 |
| Figure 6-9: | Web interface: DASHBOARD..... | 6-12 |
| Figure 6-10: | Web interface: SETTINGS - list of satellite profiles (example)..... | 6-15 |
| Figure 6-11: | Web interface: SETTINGS, Satellite profiles – new entry (example)..... | 6-16 |
| Figure 6-12: | Web interface: SETTINGS, VSAT modem profiles – list (example) | 6-18 |

| | | |
|--------------|---|------|
| Figure 6-13: | Web interface: SETTINGS, VSAT modem profiles – new entry (example) | 6-18 |
| Figure 6-14: | Web interface: SETTINGS, Blocking zones – azimuth and elevation | 6-20 |
| Figure 6-15: | Blocking zone, example: 315 - 45 degrees | 6-21 |
| Figure 6-16: | Blocking zone, example: 45 - 315 degrees | 6-21 |
| Figure 6-17: | Web interface: SETTINGS, Network (LAN connectors, DNS and Gateway setup)... | 6-22 |
| Figure 6-18: | Web interface: SETTINGS, E-mail setup (example) | 6-25 |
| Figure 6-19: | Web interface: SETTINGS, Reports (example) | 6-26 |
| Figure 6-20: | Statistics – how to read data for a range | 6-28 |
| Figure 6-21: | Statistics report (example) | 6-29 |
| Figure 6-22: | Web interface: Administration | 6-30 |
| Figure 6-23: | Web interface: Administration, change administrator login | 6-31 |
| Figure 6-24: | Web interface: ADMINISTRATION, Reset administrator password | 6-31 |
| Figure 6-25: | Web interface: ADMINISTRATION, User permissions..... | 6-32 |
| Figure 6-26: | Web interface: ADMINISTRATION, Factory default | 6-33 |
| Figure 6-27: | Display (example) and keypad of the ACU..... | 6-34 |
| Figure 6-28: | Antenna Control Unit, menu tree | 6-36 |
| Figure 6-29: | Reset the system..... | 6-40 |

Chapter 7 Installation check

Chapter 8 Daily use – Quick guide

| | | |
|-------------|--|-----|
| Figure 8-1: | SAILOR 900 VSAT Quick Guide – web interface and satellite profiles | 8-1 |
| Figure 8-2: | SAILOR 900 VSAT Quick Guide – Viewing system parameters | 8-2 |

Chapter 9 Service

| | | |
|--------------|---|------|
| Figure 9-1: | Web interface: HELPDESK | 9-2 |
| Figure 9-2: | Web interface: HELPDESK, enter support contact | 9-2 |
| Figure 9-3: | LAN connector used for configuring the SAILOR 900 VSAT..... | 9-4 |
| Figure 9-4: | Web interface: SERVICE, Upload | 9-5 |
| Figure 9-5: | Verifying software update | 9-6 |
| Figure 9-6: | LEDs on the ACU | 9-9 |
| Figure 9-7: | LEDs on the ACU, 19” rack version | 9-9 |
| Figure 9-8: | Removal and replacement of the ACU bulkhead | 9-11 |
| Figure 9-9: | Removal and replacement of the ACU 19” rack | 9-11 |
| Figure 9-10: | ADU modules and motor stop switch | 9-12 |
| Figure 9-11: | Above Deck Unit modules (continued) | 9-13 |

App. A Technical specifications

| | | |
|-------------|---|-----|
| Figure A-1: | Outline drawing: ADU | A-6 |
| Figure A-2: | Outline drawing: ACU, bulkhead | A-7 |
| Figure A-3: | Outline drawing: ACU, 19 inch rack..... | A-8 |

App. B VMU cable specifications

| | | |
|-------------|--|-----|
| Figure B-1: | Modem Cable Comtech Serial & RSSI TT7016A..... | B-2 |
| Figure B-2: | Modem Cable iNIFINITI iDirect VSAT modem | B-3 |

App. C VMU settings requirements

| | | |
|--------------|---|------|
| Figure C-1: | Connecting iDirect iNFINITI 5000 series to the ACU (OpenAMIP) | C-3 |
| Figure C-2: | Connecting iDirect Evolution X5 to the ACU (OpenAMIP) | C-3 |
| Figure C-3: | Supported OpenAMIP commands | C-4 |
| Figure C-4: | VSAT modem profile, OpenAMIP (example) | C-9 |
| Figure C-5: | Satellite profile, OpenAMIP (example) | C-9 |
| Figure C-6: | Connecting iDirect iNFINITI 5000 series to the ACU (Non-OpenAMIP) | C-10 |
| Figure C-7: | Connecting iDirect Evolution X5 to the ACU (Non-OpenAMIP) | C-10 |
| Figure C-8: | RS-232 Console cable for iDirect Non-OpenAMIP VSAT modem..... | C-11 |
| Figure C-9: | Requirements for VSAT modem option file, Non-OpenAMIP | C-12 |
| Figure C-10: | VSAT modem profile, Non-OpenAMIP (example) | C-13 |
| Figure C-11: | Satellite profile, Non-OpenAMIP (example) | C-13 |
| Figure C-12: | Connecting Comtech 570L and ROSS box to the ACU (example) | C-14 |

App. D DVB S satellites

| | | |
|-------------|---|-----|
| Figure D-1: | Satellite data, example from www.lyngsat.com | D-2 |
|-------------|---|-----|

App. E Grounding and RF protection

| | | |
|-------------|--|------|
| Figure E-1: | Extending the ground plane | E-2 |
| Figure E-2: | Grounding the ADU | E-3 |
| Figure E-3: | Grounding at a dedicated RF ground (alternative) | E-5 |
| Figure E-4: | Alternative grounding for aluminium hulls..... | E-7 |
| Figure E-5: | Alternative grounding for fiberglass hulls | E-8 |
| Figure E-6: | Separate ground cable | E-9 |
| Figure E-7: | Isolation of the ADU from the mounting base | E-10 |
| Figure E-8: | ADU isolation and grounding cable..... | E-11 |

App. F System messages

List of Tables

Chapter 1 About this manual

| | | |
|------------|---------------------------------|-----|
| Table 1-1: | List of Related Documents | 1-2 |
|------------|---------------------------------|-----|

Chapter 2 Introduction

| | | |
|------------|--|------|
| Table 2-1: | Model and part numbers for the SAILOR 900 VSAT system (T&T units)..... | 2-10 |
| Table 2-2: | Model and part numbers for options of the SAILOR 900 VSAT system | 2-10 |

Chapter 3 Installation

| | | |
|------------|---|------|
| Table 3-1: | Maximum distance from the ship's motion center versus ship's roll period..... | 3-7 |
| Table 3-2: | Mast dimensions without braces | 3-11 |
| Table 3-3: | Mast dimensions with 3 braces..... | 3-11 |
| Table 3-4: | Mast dimensions with 2 braces..... | 3-12 |
| Table 3-5: | Minimum radar separation, X-band | 3-14 |
| Table 3-6: | Minimum radar separation, S-band..... | 3-14 |
| Table 3-7: | ADU cable types and maximum lengths..... | 3-23 |

Chapter 4 Interfaces

| | | |
|------------|--|------|
| Table 4-1: | DC Input plug, outline and pin assignment..... | 4-3 |
| Table 4-2: | N connector, outline and pin assignment | 4-4 |
| Table 4-3: | F connector, Rx and Tx, outline and pin assignment..... | 4-4 |
| Table 4-4: | NMEA 0183/2000 connector, outline and pin assignment | 4-5 |
| Table 4-5: | RS-232 connector, male, outline and pin assignment..... | 4-6 |
| Table 4-6: | RS-422 connector, male, outline and pin assignment..... | 4-7 |
| Table 4-7: | Ethernet connector, outline and pin assignment..... | 4-8 |
| Table 4-8: | Cables to connect an iNFINITI® 5000 Series Satellite Router..... | 4-9 |
| Table 4-9: | Cables to connect a Comtech 570 L-Band Satellite Modem | 4-11 |

Chapter 5 Connecting power

Chapter 6 Configuration

| | | |
|------------|---|------|
| Table 6-1: | Satellite requirements for elevation and carrier | 6-5 |
| Table 6-2: | Web interface: Icons | 6-10 |
| Table 6-3: | Web interface, DASHBOARD, SAILOR 900 VSAT parameters..... | 6-13 |
| Table 6-4: | Web interface, DASHBOARD, VSAT MODEM parameter | 6-14 |
| Table 6-5: | Web interface, DASHBOARD, POINTING parameter | 6-14 |

| | | |
|-------------|---|------|
| Table 6-6: | Elevation cutoff (in degrees) versus VSAT modem bandwidth and power | 6-17 |
| Table 6-7: | Setup of LAN connectors, DNS and Gateway..... | 6-23 |
| Table 6-8: | Parameters recorded in a statistics report | 6-27 |
| Table 6-9: | Items in the ACU display (Example) | 6-34 |
| Table 6-10: | Top-level menus of the ACU | 6-37 |
| Table 6-11: | ANTENNA menu of the ACU..... | 6-38 |
| Table 6-12: | MODEM menu of the ACU..... | 6-38 |
| Table 6-13: | NETWORK menu of the ACU | 6-39 |
| Table 6-14: | SATELLITE menu of the ACU | 6-39 |
| Table 6-15: | EVENTS menu of the ACU | 6-40 |

Chapter 7 Installation check

| | | |
|------------|---|-----|
| Table 7-1: | Installation check list: Antenna | 7-1 |
| Table 7-2: | Installation check list: ACU, connectors and wiring | 7-3 |
| Table 7-3: | Installation check list: Functional test in harbor | 7-5 |

Chapter 8 Daily use – Quick guide

Chapter 9 Service

| | | |
|------------|-------------------------------|-----|
| Table 9-1: | LEDs of the ADU modules | 9-8 |
| Table 9-2: | LEDs on the ACU | 9-9 |

App. A Technical specifications

| | | |
|------------|--|-----|
| Table A-1: | General specifications | A-1 |
| Table A-2: | Technical specifications for the Above Deck Unit | A-2 |
| Table A-3: | Technical specifications for the ACU | A-4 |
| Table A-4: | Supported VSAT modems | A-5 |

App. B VMU cable specifications

App. C VMU settings requirements

| | | |
|------------|---|-----|
| Table C-1: | Messages sent from the VSAT modem to the ACU (examples)..... | C-4 |
| Table C-2: | Messages sent from the ACU to the VSAT modem (examples)..... | C-5 |
| Table C-3: | Ranges for signal strength for iDirect Open AMIP VSAT modem | C-5 |
| Table C-4: | Information in the VSAT modem option file | C-8 |

App. D DVB S satellites

| | | |
|------------|--|-----|
| Table D-1: | DVB-S satellites for azimuth calibration | D-1 |
|------------|--|-----|

App. E Grounding and RF protection

App. F System messages

Table F-1: ADU event messagesF-2

Table F-2: ACU event messages F-9

About this manual

1.1 Intended readers

This is an installation and user manual for the SAILOR 900 VSAT system, intended for installers of the system and service personnel. Personnel installing or servicing the system must be properly trained and authorized by Thrane & Thrane. It is important that you observe all safety requirements listed in the beginning of this manual, and install the system according to the guidelines in this manual.

For daily use of the SAILOR 900 VSAT system see the SAILOR 900 VSAT Quick guide or *Daily use – Quick guide* on page 8-1.

1.2 Manual overview

This manual has the following chapters:

- *Introduction*
- *Installation*
- *Interfaces*
- *Connecting power*
- *Configuration*
- *Installation check*
- *Daily use – Quick guide*
- *Service*

This manual has the following appendices:

- *Technical specifications*
- *VMU cable specifications*
- *VMU settings requirements*
- *DVB S satellites*
- *Grounding and RF protection*
- *System messages*

1.3 Software version

This manual is intended for SAILOR 900 VSAT with **software version 1.10**.

1.4 Related documents

The following related documentation is referred to in this manual:

| Document number | Title |
|-----------------|-----------------------------|
| 98-133401 | SAILOR 900 VSAT Quick guide |

Table 1-1: List of Related Documents

1.5 Typography

In this manual, typography is used as indicated below:

Bold is used for the following purposes:

- To emphasize words.
Example: “Do **not** touch the antenna”.
- To indicate what the user should select in the user interface.
Example: “Select **SETTINGS** > **LAN**”.

Italic is used to emphasize the paragraph title in cross-references.

Example: “For further information, see *Connecting Cables* on page...”.

1.6 Precautions

Warnings, Cautions and Notes

Text marked with “Warning”, “Caution”, “Note” or “Important” show the following type of data:

- **Warning:** A Warning is an operation or maintenance procedure that, if not obeyed, can cause injury or death.
- **Caution:** A Caution is an operation or maintenance procedure that, if not obeyed, can cause damage to the equipment.
- **Note:** A Note gives information to help the reader.
- **Important:** A text marked Important gives information that is important to the user, e.g. to make the system work properly. This text does not concern damage on equipment or personal safety.

General precautions

All personnel who operate equipment or do maintenance as specified in this manual must know and follow the safety precautions.

The warnings and cautions that follow apply to all parts of this manual.



WARNING! Before using any material, refer to the manufacturers' material safety data sheets for safety information. Some materials can be dangerous.



CAUTION! Do not use materials that are not equivalent to materials specified by Thrane & Thrane. Materials that are not equivalent can cause damage to the equipment.



CAUTION! The system contains items that are electrostatic discharge sensitive. Use approved industry precautions to keep the risk of damage to a minimum when you touch, remove or insert parts or assemblies.

Introduction

This chapter is organised in the following sections:

- *SAILOR 900 VSAT system*
- *Part numbers and options*

2.1 SAILOR 900 VSAT system

The SAILOR 900 VSAT is a unique stabilized maritime VSAT antenna system operating in the Ku-band (10.7 to 14.5 GHz). It provides bi-directional IP data connections both on regional satellite beams and quasi-global Ku-band satellite networks. The system only requires a single 50 Ohm cable to provide the Above Deck Unit with both DC power, data and control information. The radome does not have to be opened neither before nor after the installation. To protect the Above Deck Unit the built-in DC motors act as breaks during transport and when the Above Deck Unit is not powered. The ADU system can be accessed remotely and in-depth performance analysis can be done using the built-in web interface.

The SAILOR 900 VSAT system consists of two units:

- Above Deck Unit (ADU)
- Antenna Control Unit (ACU)

The following figures show the SAILOR 900 VSAT system with its two variants of ACUs.




Figure 2-1: Above Deck Unit and Antenna Control Unit (ACU)



Figure 2-2: Above Deck Unit and Antenna Control Unit (ACU), 19" rack version

SAILOR 900 VSAT features

- Single 50 Ohm coax cable for the ADU.
- Support of several VSAT modems.
- Service communication using SAILOR FleetBroadband over WAN.
- Remote or local simultaneous software update of ADU and ACU via PC and Internet browser.
- Global RF configuration.
- Full remote control and troubleshooting with built-in test equipment (BITE).
- ACU with 4 x LAN, NMEA 0183, NMEA 2000, RS-232 and RS-422.
- All interfaces at the ACU, no additional units required.
- DC powered. Start up voltage: 22 VDC guaranteed, operating range: 20 – 32 VDC.
- No scheduled maintenance.

2.1.1 Above Deck Unit (ADU)

The SAILOR 900 VSAT Above Deck Unit is a 103 cm VSAT stabilised tracking antenna, consisting of a suspended antenna with a standard global RF configuration. The Above Deck Unit's weight is around 135 kg. It is stabilized by heavy duty vibration dampers in 3-axis (plus skew) and can be used in environments with elevations of -25° to $+125^{\circ}$. The Above Deck Unit is powered by the Antenna Control Unit and protected by a plastic radome.



Figure 2-3: Above Deck Unit (ADU)

Modules in the SAILOR 900 VSAT Above Deck Unit




Figure 2-4: Above Deck Unit modules 1/2

1. GPS module.
2. VSAT Interface Module (VIM).
3. DC-Motor Driver Module for cross elevation (DDM).
4. Cross elevation motor and encoder.
5. Zero Reference Module (x4) (ZRM). (not visible on photo)
6. DC-Motor Driver Module for elevation (on the side).
7. Elevation motor and encoder. (on the side)
8. Polarisation Motor Module (PMM). (not visible on photo)
9. Polarisation motor and encoder. (not visible on photo)

10. Block Up Converter (BUC). (behind cable screen, not visible on photo)
11. Low Noise Block downconverter (x2) (LNB). (not visible on photo)
12. Ortho Mode Transducer (OMT). (not visible on photo)
13. Inertial Sensor Module (ISM).
14. Pedestal Control Module (PCM).
15. Service switch.

In switch-off position the DC Motor Driver modules and the BUC are turned off for safe conditions during service and repair. The switch must be in on position for normal ADU operation.




Figure 2-5: Above Deck Unit modules 2/2

16. DC-Motor Driver Module for Azimuth (DDM).
17. Azimuth motor and encoder. (not visible on photo)
18. Rotary joint. (not visible on photo)
19. Feed horn.

SAILOR 900 VSAT Above Deck Unit interface

All communication between the Above Deck Unit and the ACU passes through a single standard 50 Ohm cable (with N connector) through the rotary joint. No cable work is required inside the radome.

Installation friendly

Four lifting brackets (included in the delivery) and reuse of packing material help getting the Above Deck Unit safely into place. Satellite link parameters are entered using a PC and the built-in web server of the ACU. They can be displayed at the ACU.

The included cable relief support can be attached to the ACU.

Service friendly

The system configuration is saved in two modules, there is no loss of data at repair. The large service hatch of the radome gives easy access to the ADU on site (one-hand operation). The service switch in the ADU stops the DC Motor Driver modules, turns the BUC off and switches on the light inside the radome. The service tools for replacing modules are placed on a tool holder inside the radome.

All modules have a service and power LED status indicator. Each module is encapsulated in a metal box with self-contained mounting bolts.

If necessary, belts and modules can be exchanged through the service hatch on site.

You can do remote diagnostics and service with the ADU. Its built-in test equipment checks constantly the ADU's components for proper functioning, it monitors and logs information for all modules. The ADU performs a POST (Power On Self Test) and you can request a self test (Person Activated Self Test) and has Continuous Monitoring (CM). Error codes can be read out in the web interface and in the display of the ACU.

Software update is done using a PC connected via LAN to the ACU.

2.1.2 Antenna Control Unit (ACU)

The Antenna Control Unit, also called ACU, is the central unit in the system. It contains all user interfaces and manages all communication between the ADU and the VMU, a connected PC and an optional FleetBroadband service communication line. The ACU has a display, status LEDs and a keypad. It provides a DHCP client. During configuration you can configure heading offset, save satellite and VMU setups and enter *No Transmit Zones* (blocking zones in which the ADU does not transmit).

The ACU provides DC power to the ADU through a single coaxial cable. You can use the TT-6080A Power Supply to provide the DC power (20-32 VDC).

ACU interfaces

The ACU has the following interfaces and switch:




Figure 2-6: SAILOR 900 VSAT ACU, connector overview

- N-connector for ADU cable (50 Ohm).
- 2 x F-connectors for Rx and Tx cables (75 Ohm) to VSAT modem.
- Multi connector for NMEA interfaces (for input from GPS compass or Gyro compass).
- RS-422 interface for modem control.
- RS-232 interface for modem control.
- 4 x LAN ports for VSAT modem control and user equipment (i.e. for SAILOR FleetBroadband service communication line or WAN port for VSAT Internet).
- Power connector.
- On/Off power switch

The 19" rack version of the ACU has additionally a LAN connector at the front for accessing the service port from the ACU front panel.



Figure 2-7: SAILOR 900 VSAT ACU, 19" rack version

Installation friendly

The ACU comes in two models: Wall or desktop installation (bulkhead) or in a 19" rack version.




Figure 2-8: Antenna Control Unit for bulkhead installation




Figure 2-9: Antenna Control Unit for 19" rack installation

Service friendly

You can do remote diagnostics and service with the ACU. Its built-in test equipment checks constantly the ACU's modules for proper functioning, it monitors and logs for all modules. It performs POST (Power On Self Test) and you can request a PAST (Person Activated Self Test). Continuous Monitoring (CM) is another option. BITE error codes can be read out in the web interface and in the display of the ACU.

Software update is done via a connected PC and the built-in web interface of the ACU.

2.1.3 VSAT Modem Unit (VMU)

SAILOR 900 VSAT is designed to be operated with third-party VSAT modems. For a list of supported VSAT modems see the SAILOR 900 VSAT data sheet at thrane.com.

For the latest status of supported VMUs see <http://extranet.thrane.com/> and click ESUPPORT.

2.1.4 Satellite type approvals

For a list of satellite type approvals see the SAILOR 900 VSAT data sheet at thrane.com.

2.1.5 Power supply

To provide DC power to the SAILOR 900 VSAT you can use the TT-6080A Power Supply.

2.1.6 Service activation

Before you can start using the SAILOR 900 VSAT, you need to activate the system for VSAT service. Contact your service provider for activation.

2.2 Part numbers and options

2.2.1 Applicable Thrane & Thrane model- and part numbers

This Installation Manual is for the SAILOR 900 VSAT system and is applicable to the model- and part numbers below:

| T&T part number | Model number | Description |
|-----------------|--------------|---|
| 407009A-00500 | TT-7009A-THR | SAILOR 900 VSAT Above Deck Unit (ADU) |
| 407016A-00500 | TT-7016A-T19 | SAILOR 900 VSAT Antenna Control Unit (19 inch rack) |
| 407016A-00510 | TT-7016A-TBH | SAILOR 900 VSAT Antenna Control Unit (bulkhead) |

Table 2-1: Model and part numbers for the SAILOR 900 VSAT system (T&T units)

2.2.2 Options for SAILOR 900 VSAT

The following options are available for the SAILOR 900 VSAT system:

| T&T part number | Model number | Description |
|-----------------|--------------|---|
| 406080A | TT-6080A | Power Supply |
| 407090A-950 | | Antenna cable 50 m, N-Conn (not mounted), male/male |
| 407090A-925 | | Pigtail Cable 1.25 m, N-Conn, female/male |

Table 2-2: Model and part numbers for options of the SAILOR 900 VSAT system

For information on accessories available for the SAILOR 900 VSAT see <http://extranet.thrane.com/> and click ESHOP.

Installation

This chapter is organised in the following sections:

- *Unpacking*
- *Site preparation*
- *Installation of the ADU*
- *Installation of the ACU (bulkhead)*
- *Installation of the 19" rack version of the ACU*
- *Installation of the VMU*

3.1 Unpacking

3.1.1 What's in the box

ADU

Unpack your SAILOR 900 VSAT ADU and check that the following items are present:

- ADU with 4 lifting brackets (already mounted)
- Package with bolts and washers

ACU (bulkhead)

Unpack your SAILOR 900 VSAT ACU (bulkhead) and check that the following items are present:

- 1 x Ethernet cable (2 m)
- Power connector
- 2 x 75 Ohm coax cables F-F (1m), for Rx and Tx
- NMEA multi-connector
- Installation Manual (this manual)
- Quick Guide
- Cable Relief

ACU (19" rack version)

Unpack your SAILOR 900 VSAT ACU (19" rack version) and check that the following items are present:

- 1 x Ethernet cable (2 m)
- 1 x Ethernet cable (short)
- Power connector
- 2 x 75 Ohm coax cables F-F (1m), for Rx and Tx
- NMEA multi-connector
- Installation Manual (this manual)
- Quick Guide

3.1.2 Initial inspection

Inspect the shipping cartons and wooden box immediately upon receipt for evidence of damage during transport. If the shipping material is severely damaged or water stained, request that the carrier's agent be present when opening the cartons and wooden box. Save all box packing material for future use.



WARNING! To avoid electric shock, do not apply power to the system if there is any sign of shipping damage to any part of the front or rear panel or the outer cover. Read the safety summary at the front of this manual before installing or operating the system.

After unpacking the system, i.e. removing the top and sides of the wooden box and opening the cartons, inspect it thoroughly for hidden damage and loose components or fittings. If the contents are incomplete, if there is mechanical damage or defect, or if the system does not work properly, notify your dealer.

3.1.3 Tools needed

These tools for the ADU installation are included in the delivery and mounted on a tool holder inside the radome:

- Unbraco key (5 mm)

Other tools that may be needed during the installation:

- Wrench to fasten the mounting bolts for the ADU
- Wrench to fasten the N connector at the ADU
- PC and Internet browser
- Drill for the mounting holes for the ACU

- Crimping tools

3.2 Site preparation

The following topics have to be considered when installing the ADU:

- *General site considerations*
- *Obstructions (ADU shadowing)*
- *Blocking zones – azimuth and elevation*
- *Safe access to the ADU: Radiation hazard*
- *Ship motion and offset from the ship's motion centre*
- *ADU mast design: Foundation and height*
- *Interference*
- *Other precautions*

3.2.1 General site considerations

For optimum system performance, some guidelines on where to install or mount the different components of the SAILOR 900 VSAT System must be followed.

It is recommended to mount the ADU in a location with as much **360° free line of sight to the satellite** as possible while making sure that the support structure fulfills the requirements for the mast foundation. The ADU must be mounted on stiffened structures with a minimum of exposure to vibrations.

3.2.2 Obstructions (ADU shadowing)

Place the ADU so that it has as much free line-of-sight without any structures in the beam through one full 360 degrees turn of the vessel. Do not place the ADU close to

large objects that may block the signal. To avoid obstruction elevate the ADU by mounting it on a mast or on a mounting pedestal on a deck or deck house top.




Figure 3-1: Signal degradation because of obstructing objects

The ADU is stabilized in 3-axis (plus skew) and can be used in environments with elevations of -25° to $+125^{\circ}$ to allow for continuous pointing even in heavy sea conditions.

The ADU beam is approximately 1 m in diameter for the first 30 m from the ADU. Beyond 30 m the beam gradually widens so that it is approximately 5 m in diameter at 100 m distance. This beam expansion continues with increasing distance.

Any obstructions, such as masts, funnels, bridge house etc. within this field can cause signal degradation.

Note

Please note that due to the short wavelength at Ku band and the narrow beam width of the ADU even a **6 mm steel wire placed within 50 m** inside the beam can cause signal degradation.

3.2.3 Blocking zones – azimuth and elevation

Your installation may require that you setup blocking zones for the ADU, i.e. areas where the ADU will not transmit and areas where transmit power is potentially dangerous for persons frequently being in these zones. You can set up 8 blocking zones. Each blocking zone is set up with azimuth start and stop, and elevation angle.




Figure 3-2: 2 blocking zones with no-transmit zones, azimuth (example)




Figure 3-3: Blocking zone with no-transmit zones, elevation angle (example)

The blocking zones are set up in the SAILOR 900 VSAT built-in web interface. For further information see *Setting up Blocking zones (RX and TX)* on page 6-20.

3.2.4 Safe access to the ADU: Radiation hazard

The SAILOR 900 VSAT ADU radiates up to 49 dBW EIRP. This translates to a minimum safety distance of 30 m from the ADU while it is transmitting, based on a radiation level of 10 W/m^2 .




Figure 3-4: Radiation hazard, safety distance 30 m

3.2.5 Ship motion and offset from the ship's motion centre

Even though it is recommended to mount the ADU high, keep the distance between the ADU and the ship's motion centre as short as possible. The higher up the ADU is mounted, the higher is the linear g force applied to the ADU. The g force also depends on the roll period of the ship, see Table 3-1. If the g force applied is too high, performance and ADU signal stabilization may be reduced and eventually the ADU may be damaged. Refer to the following table for allowed mounting heights above the ship's motion centre.




Figure 3-5: Maximum distance from the ship's motion centre (h max)

| Min. roll period | Max. ADU mounting height (h max) | |
|---------------------|----------------------------------|---------------------------|
| | Full performance | Potential risk for damage |
| 4 s | 12 m | 16 m |
| 6 s | 27 m | 35 m |
| 8 s | 48 m | 62 m |
| 10 s | 75 m | 98 m |

Table 3-1: Maximum distance from the ship's motion center versus ship's roll period

3.2.6 ADU mast design: Foundation and height

The ADU mast must be designed to carry the weight of the ADU unit, which is approximately 135 kg (+ the weight of the mast flange). The mast must also be able to withstand onboard vibrations and wind speeds up to 110 knots on the radome, even in icing conditions.

ADU mast flange

Fit the top of the ADU mast with a flange with clearance holes matching the bushings in the radome and with minimum 4 gusset plates. No center hole is necessary in the flange.

- **Flange thickness:** Minimum 15 mm.
- **4 gusset plates:** Minimum 15 mm thick, must be placed close to the holes in the mounting plate and evenly distributed.




Figure 3-6: ADU mast flange, top and side view

Recommended flatness on the mast mount plateau is below 3,0 mm.




Figure 3-7: ADU mast flange, recommended flatness on the mast mount plateau




Figure 3-8: ADU mast flange, distance to the welded seam



CAUTION! Avoid sharp edges where the flange is in direct contact with the radome. Round all edges as much as possible to avoid damaging the surface of the radome.




Figure 3-9: ADU, bottom view

Mast length and diameter

The placement of the ADU must ensure a rigid structural connection to the hull or structure of the ship. Parts of the ship with heavy resonant vibrations are not suitable places for the ADU. A small platform or short mast shall provide rigid support for the ADU fastening bolts and a rigid interface to the ship.

If it is necessary to use a tall mast, you must stabilise the mast with bracing. Note that the design values given below depend on rigid ADU-ship interfaces. The cross-sectional properties and the corresponding maximum free length give a natural frequency close to 30 Hz. It is recommended to shorten the mast length as much as possible to obtain higher frequencies. Preferably, mount stays or wires to stabilize the mast further.




Figure 3-10: Free mast length and bracing for a tall mast

Note Make sure that there is free space below the drain tube. Read also *Condensation and water intrusion* on page 3-17.

The tables in the next sections give some suggested design values for the free mast length.

Note The tables list the values for **steel masts**. For **aluminium masts**, the free mast length is reduced to 75% of the values for steel.

Note Bracing and rigid masts can still not prevent vertical vibration if the mast is attached to a deck plate that is not rigid. Make every effort to mount the mast on a surface that is well supported by ribs. If this is not possible, provide extra deck plate propping.

SAILOR 900 VSAT ADU mast length

The below tables show the minimum dimensions for a SAILOR 900 VSAT ADU mast with and without stays or wires. Note that the values are only guidelines - always consider the environment and characteristics of the ship before deciding on the mast dimensions.


| Mast without braces | Max. free mast length (steel), (m) | Outer Diameter (mm) | Wall Thickness (mm) | Weight (kg/m) |
|---|------------------------------------|---------------------|---------------------|---------------|
|  | 0.4 ^a | 200 | 5 | 24.0 |
| | 0.6 | 220 | 5 | 26.5 |
| | 0.8 | 250 | 5 | 30.2 |
| | 1 | 270 | 5 | 32.7 |

Table 3-2: Mast dimensions without braces

- a. The height of 0.4 m is not recommended to be used as it will make access through the ADU's service hatch difficult.


| Mast with 3 braces | Max. free mast length (steel), (m) | Outer Diameter (mm) | Wall Thickness (mm) | Outer Diameter for brace (mm) | Thickness for brace (mm) |
|---|------------------------------------|---------------------|---------------------|-------------------------------|--------------------------|
|  | 1.2 | 140 | 10 | 50 | 5.0 |
| | 1.2 | 200 | 5 | 50 | 5.0 |
| | 1.6 | 140 | 10 | 70 | 5.0 |
| | 1.6 | 200 | 5 | 70 | 5.0 |
| | 2 | 160 | 10 | 70 | 5.0 |
| | 2 | 220 | 5 | 70 | 5.0 |
| | 2.5 | 180 | 10 | 80 | 5.0 |
| | 2.5 | 220 | 5 | 80 | 5.0 |

Table 3-3: Mast dimensions with 3 braces


| Mast with 2 braces | Max. free mast length (steel), (m) | Outer Diameter (mm) | Wall Thickness (mm) | Outer Diameter for brace (mm) | Thickness for brace (mm) |
|--|------------------------------------|---------------------|---------------------|-------------------------------|--------------------------|
|  | 1.2 | 160 | 10 | 80 | 5.0 |
| | 1.2 | 200 | 5 | 80 | 5.0 |
| | 1.6 | 180 | 10 | 80 | 5.0 |
| | 1.6 | 220 | 5 | 80 | 5.0 |
| | 2 | 180 | 10 | 80 | 5.0 |
| | 2 | 240 | 5 | 80 | 5.0 |
| | 2.5 | 200 | 10 | 80 | 5.0 |
| | 2.5 | 260 | 5 | 80 | 5.0 |

Table 3-4: Mast dimensions with 2 braces

3.2.7 Interference

Note Do not place the ADU close to interfering signal sources or receivers. For allowed distances to other transmitters see Figure 3-12: *Recommended distance to transmitters (m) for frequencies below 1000 MHz* on page 3-16. We recommend testing the total system by operating all equipment simultaneously and verifying that there is no interference.

The ADU must be mounted as far away as possible from the ship's radar and high power radio transmitters, because they may compromise the ADU performance. RF emission from radars might actually damage the ADU.

The SAILOR 900 VSAT ADU itself may also interfere with other radio systems.

Radar

It is difficult to give exact guidelines for the minimum distance between a radar and the ADU because radar power, radiation pattern, frequency and pulse length/shape vary from radar to radar. Further, the ADU is typically placed in the near field of the radar ADU and reflections from masts, decks and other items in the vicinity of the radar are different from ship to ship.

However, it is possible to give a few guidelines. Since a radar radiates a fan beam with a horizontal beam width of a few degrees and a vertical beam width of up to $\pm 15^\circ$, the worst interference can be avoided by mounting the ADU at a different level – meaning that the ADU is installed minimum 15° above or below the radar antenna. Due to near field effects the benefit of this vertical separation could be reduced at short distances between radar antenna and the SAILOR 900 VSAT ADU. Therefore it is recommended to ensure as much vertical separation as possible when the SAILOR 900 VSAT ADU has to be placed close to a radar antenna.




Figure 3-11: Interference with the vessel's radar

Radar distance

The minimum acceptable separation (d min.) between a radar and the ADU is determined by the radar wavelength/frequency and the power emitted by the radar. The tables below show some “rule of thumb” minimum separation distances as a function of radar power at X and S band. If the d min. separation listed below is applied, antenna damage is normally avoided.

“d min.” is defined as the shortest distance between the radar antenna (in any position) and the surface of the SAILOR 900 VSAT ADU.

| X-band (~ 3 cm / 10 GHz) damage distance | | |
|--|-----------------------------------|-----------------------------------|
| Radar power | SAILOR 900 VSAT ADU | |
| | d min. at 15° vertical separation | d min. at 60° vertical separation |
| 0 – 10 kW | 1.0 m | 1.0 m |
| 30 kW | 2.0 m | 1.0 m |
| 50 kW | 3.3 m | 1.7 m |

Table 3-5: Minimum radar separation, X-band

| S-band (~ 10 cm / 3 GHz) damage distance | | |
|--|-----------------------------------|-----------------------------------|
| Radar power | SAILOR 900 VSAT ADU | |
| | d min. at 15° vertical separation | d min. at 60° vertical separation |
| 0 – 10 kW | 2.0 m | 1.0 m |
| 30 kW | 3.0 m | 1.5 m |
| 50 kW | 5.0 m | 2.5 m |

Table 3-6: Minimum radar separation, S-band

The separation distance for C-band (4-8 GHz) radars should generally be the same as for X-band radars.

Radar interference

Even at distances greater than “d min.” in the previous section the radar might still be able to degrade the performance of the SAILOR 900 VSAT system.

The presence of one or more S or X-band radars within a radius up to 100 m may cause a minor degradation of the Ku-band connection. The degradation will be most significant at high radar pulse repetition rates.

As long as receiving conditions are favorable, this limited degradation is without importance. However, if receiving conditions are poor – e.g. due to objects blocking the signal path, heavy rainfall or icing, low satellite elevation and violent ship movements – the small extra degradation due to the radar(s) could cause poor connection quality.

The presence of S-band radar(s) is unlikely to cause any performance degradation – as long as the minimum distances (d min.) listed in the previous section are applied.

It is strongly recommended that interference free operation is verified experimentally before the installation is finalized.



CAUTION! The ADU must never be installed closer to a radar than “d min.” - even if experiments show that interference free operation can be obtained at shorter distances than “d min.” in the previous section.

GPS receivers

Good quality GPS receivers will work properly very close to the ADU - typically down to one meter outside the main beam.

Other transmitters

See the following figure for minimum recommended distance to transmitters in the frequency range below 1000 MHz.




Figure 3-12: Recommended distance to transmitters (m) for frequencies below 1000 MHz

3.2.8 Other precautions

Condensation and water intrusion

If possible, install the radome such that direct spray of seawater is avoided. In some weather condition there may occur condensation inside the radome. The drain tube is designed to lead any water away from inside the radome. Make sure the ADU's drain tube is open and that there is free space between the drain tube and the mounting surface so water can escape and there is ventilation for the ADU.



Figure 3-13: Drain pipe with free space

It is recommended not to use pneumatic tools for cleaning the radome, especially at a short distance and directly at the split between top and bottom.

Deposits

Do not place the ADU close to a funnel, as smoke deposits are corrosive. Furthermore, deposits on the radome can degrade performance.

3.3 Installation of the ADU

The ADU is shipped fully assembled. You have to install it on the mast and attach the ADU cable.



WARNING! Use a strong webbed sling with a belt to lift the ADU without damaging the radome. Make sure that the sling can carry the ADU's weight (135 kg, 288 lbs).



WARNING! The ADU may be subject to swaying motions in windy conditions. Always use tag lines to stabilise the ADU during hoisting.




Figure 3-14: Use of strong sling with a belt and tag lines for safe hoisting

Before installing the ADU read the following guidelines.

3.3.1 Installing the ADU

Make sure that there is sufficient space underneath the ADU to open the service hatch. Through this hatch you access the ADU modules for service and maintenance.



Figure 3-15: Free space for access to the service hatch

The ADU does not have to be aligned with the bow-to-stern line of the ship. When configuring the SAILOR 900 VSAT you make an azimuth calibration to obtain the correct azimuth of the ADU.

- It is important to maintain **vertical orientation of the ADU center line**.
- Consider the aspect of interference, read more about this in *ADU mast design: Foundation and height* on page 3-8.
- Install the ADU where **vibrations are limited to a minimum**.
- Always use **all 4 bolts** when installing the ADU.

To install the ADU, do as follows:

1. Install the mast with the mast flange and have the 4 M12 bolts ready.
2. Undo all shipping buckles, take off the wooden top and remove the casing.
3. Unscrew the 4 bolts holding the ADU on the wooden platform.

4. Attach a webbed, four-part sling with a belt to all 4 lifting brackets.



Figure 3-16: ADU installation, webbed sling attached to the 4 lifting brackets

5. Attach 2 tag lines of suitable length to 2 lifting brackets and man them.
6. With a crane lift the ADU off the wooden platform and move it on top of the ADU mast.
7. Install the ADU on the mast flange with 4 M12 bolts and washers. Read carefully and follow instructions given in *Grounding the ADU* on page E-3.
Tightening torque value: 30 Nm



Figure 3-17: Mounting the ADU on the mast flange

8. Put the coaxial ADU cable through the protection plate as shown in the following figure, and connect the N connector of the ADU cable to the ADU (see picture series below).




Figure 3-18: Connecting the ADU cable

Ensure that the connector assembly is properly protected against seawater and corrosion. As a minimum, wrap it with self-amalgamating rubber.

9. Put the protection plate in place and fasten the 4 bolts (picture 5).
10. Fasten the nut (picture 6).

Where the cables are exposed to mechanical wear – on deck, through bulkheads, etc. – protect the cables with steel pipes. Otherwise, follow standard procedures for cabling in ship installations.

Maximum allowed RF loss in the ADU cable: ≤ 20 dB at 1950 MHz. This is to ensure optimum performance of the system.

3.3.2 Opening and removing the service hatch

Open the hatch to access the antenna modules. You can remove the hatch for better mobility when servicing the antenna. Do as follows to open and remove the service hatch:

1. Pull open the two latches and let the lid fall open.



Figure 3-19: Opening the service hatch

2. Remove the 2 split pins and park them.




Figure 3-20: Removing the 2 split pins

3. Pull the service hatch free. A wire keeps the service hatch attached to the antenna.




Figure 3-21: Removing the service hatch

3.3.3 Grounding the ADU

The ADU must be grounded using the mounting bolts. If the ADU cannot or should not be electrically connected directly to the mounting surface, you can use a separate grounding cable to make the connection between the ADU and the common ground to which the ACU is also connected. If grounding to the ship ground is impossible, for example if you have a fibre glass hull, see *Alternative grounding for fiberglass hulls* on page E-7.

To obtain a good ground connection, the metal underneath the head of **at least** one bolt must be clean of insulating protective coating and a serrated washer should be used. After tightening the bolts we recommend that you seal the area suitably in order to avoid corrosion of the grounding point. Use stainless steel bolts and washers.

For further information on grounding and RF protection see *Grounding and RF protection* on page E-1.

3.3.4 Alternative ADU cable

The maximum allowed RF-loss in the ADU cable must be ≤ 20 dB at 1950 MHz and 0.9 Ohm DC. This is to ensure the performance of the system. Preferably choose one of the cable types listed in the table below.

| Cable Type | Absolute maximum length |
|-------------|-------------------------|
| G02232-D | 6 m |
| RG223-D | 25 m |
| RG214/U | 50 m |
| S 07272B-05 | 95 m |

Table 3-7: ADU cable types and maximum lengths

Check the data sheet from the cable supplier that both the RF- attenuation and the DC-resistance are kept within the maximum specified values:

- ADU cable RF-attenuation at 1950 MHz: max. 20 dB including connector.
- ADU cable modem-attenuation at 10 MHz: Max. 2 dB
ADU cable modem-attenuation at 36 and 54 MHz: Max. 4 dB
- ADU cable loop DC-resistance max: 0.9 Ohm.

Also ensure that the specified minimum bending radius is respected. If this is not the case, the loss in the cable will increase. Check the documentation from the cable supplier.

3.4 Installation of the ACU (bulkhead)

The following sections describe the installation of the bulkhead ACU.

Installation of the SAILOR 900 VSAT 19" Rack ACU is described in *Installing the 19" rack version of the ACU* on page 3-27.

3.4.1 Installing the ACU (bulkhead)

The cable relief for the ACU is already mounted when receiving the ACU. The cable relief is a simple system to secure cables with cable strips. It offers a number of holders to which you can secure the cables from the ACU.

1. Place the ACU on a desktop.
If required, fasten the ACU to the desktop with 6 screws: Insert the mounting bolts (M5) through the mounting holes and into the mounting surface.
2. Make sure the grounding requirements are met. See *Grounding the ACU (bulkhead)* on page 3-25 and the appendix *Grounding and RF protection* on page E-1 for details about grounding.
3. Connect all cables. See *Interfaces of the SAILOR 900 VSAT ACU* on page 4-1 for a description of the ACU connectors.
4. Secure the cables using cable strips.

Connectors of the ACU

The ACU has the following connectors:




Figure 3-22: ACU, connector panel

Each connector is described in detail in *Interfaces of the SAILOR 900 VSAT ACU* on page 4-1.

For information on wiring 24 V DC power see *DC Input connector* on page 4-3.

For more information about power supply and power requirements see *Connecting power* on page 5-1.

3.4.2 Grounding the ACU (bulkhead)

Make sure that the grounding requirements are met. This is important to protect the ACU against lightning. See the appendix *Grounding and RF protection* on page E-1 for details about grounding.

ADU cable

The ADU is connected to the ACU with the ADU cable (coax cable) with an N connector at both ends. For information on ADU grounding, see *Grounding the ADU* on page 3-23.

At the ACU end, it is strongly recommended to ground the ADU cable. Use a short cable from the ACU to a grounding point and connect the short cable to the ADU cable at this grounding point, making sure the shield of the connector is properly connected.

Ground stud

To ensure that the ACU is grounded – also if the cable is disconnected from the ACU, connect an extra ground wire to the ground stud on the ACU. This ground wire must be a heavy wire or braid cable with a larger diameter than the coax cable (minimum cross section: 4 mm²).




Figure 3-23: SAILOR 900 VSAT ACU, bulkhead version, ground stud

3.4.3 SAILOR 900 VSAT ACU (bulkhead) with cable support

You can mount a Cable Relief for the ACU (bulkhead). This is a simple system to which you can secure your cables using cable strips. When mounted on the ACU the cable relief offers a number of holders to which you can secure the cables from the ACU, using cable strips.

To mount the cable relief, do as follows:

1. Remove the two rubber washers from the bottom of the ACU at the connector panel end. The threaded bushings underneath the rubber washers are used for mounting the cable support.




Figure 3-24: Mounting the cable relief 1/2

2. Fasten the Basic cable support to the ACU using two M4 x 6 mm countersunk screws.




Figure 3-25: Mounting the cable relief 2/2

3. Mount the ACU by inserting 6 screws through the holes in the mounting bracket and into the mounting surface.
4. Make sure the grounding requirements are met. See *Grounding the ACU (bulkhead)* on page 3-25 and the appendix *Grounding and RF protection* on page E-1 for details about grounding.
5. Connect all cables. See *Interfaces of the SAILOR 900 VSAT ACU* on page 4-1 for a description of the ACU connectors.
6. Secure the cables to the cable relief using cable strips.

3.5 Installation of the 19" rack version of the ACU

The following sections describe the installation of the 19" rack ACU. Installation of the SAILOR 900 VSAT ACU is described in *Installation of the ACU (bulkhead)* on page 3-24.

3.5.1 Installing the 19" rack version of the ACU

A cable relief bracket is already mounted when receiving the ACU. The cable relief is a simple system to secure cables with cable strips. It offers a number of holders to which you can secure the cables from the ACU. To install the 19" rack version of the ACU, do as follows:

1. Slide the ACU into a 1U space in a 19" rack.
2. Mount the screws in each side through the holes in the front and fasten the screws to the rack. Make sure that the unit is mounted securely according to the requirements for your 19" rack.
3. Connect all cables. See *Interfaces of the SAILOR 900 VSAT ACU* on page 4-1 for a description of the ACU connectors.



Figure 3-26: ACU, 19" rack version, On/off switch at the back

Important

Set the On/Off switch at the back of the ACU to On. Then you can use the On/Off switch at the front panel of the ACU 19" rack version

Connectors of the 19" rack version of the ACU

For a description of the connectors see *Connectors of the ACU* on page 3-24. The 19" rack version of the ACU has additionally a LAN connector at the front for accessing the service port from the ACU front panel.



Figure 3-27: ACU, LAN connector at the front: Service port

For information on wiring 24 VDC power see *DC Input connector* on page 4-3.

For more information about power supply and power requirements see *Connecting power* on page 5-1.

3.5.2 Grounding the 19" rack version of the ACU

Make sure that the grounding requirements are met. See the appendix *Grounding and RF protection* on page E-1 for details about grounding.

ADU cable

The ADU is connected to the ACU with the ADU cable (coax cable) with an N connector at both ends. For information on ADU grounding, see *Grounding the ADU* on page 3-23.

At the ACU end, it is strongly recommended to ground the ADU cable. Use a short cable from the ACU to a grounding point in the rack and connect the short cable to the ADU cable at this grounding point, making sure the shield of the connector is properly connected to the rack.

Ground stud at the ACU

To ensure that the ACU is grounded – also if the ADU cable is disconnected from the ACU, connect an extra ground wire from the rack to the ground stud on the ACU. This ground wire must be a heavy wire or braid cable with a larger diameter than the coax cable.



Figure 3-28: ACU, 19" rack version, ground stud

3.6 Installation of the VMU

For a list of supported VSAT modems see the SAILOR 900 VSAT data sheet. For the latest status of supported VMUs see <http://extranet.thrane.com/> and click ESUPPORT.

3.6.1 General mounting considerations – VMU

1. Mount the VMU close to the ACU, preferably at a distance less than 1 m.
2. Connect all cables. See *Interfaces of the VMU* on page 4-9 for a description of the connectors for supported VSAT modems.
For cable specifications see *VMU cable specifications* on page B-1.

Connectors and pin-out of the VMU

For connectors and pin-out see the user documentation of the VMU and *Interfaces of the VMU* on page 4-9.

Wiring Power

Provide power to the VMU as described in the user documentation of the unit.

Interfaces

This chapter is organised in the following sections:

- *Interfaces of the SAILOR 900 VSAT ACU*
- *Interfaces of the VMU*

4.1 Interfaces of the SAILOR 900 VSAT ACU

4.1.1 ACU bulkhead – LEDs, display and keypad



Figure 4-1: ACU bulkhead, LEDs, display and keypad

4.1.2 ACU 19" rack version – LEDs, display and keypad



Figure 4-2: ACU rack version, LEDs, display and keypad

4.1.3 ACU bulkhead – Connector panel – overview




Figure 4-3: ACU bulkhead, connector panel overview

4.1.4 ACU 19" rack version – Connector panel – overview




Figure 4-4: ACU rack version, connector panel overview

The connector LAN to the left is typically connected to the service port at LAN3 with a straight Ethernet cable. Then you can access the service port from the front of the ACU rack version.

Important

Set the On/Off switch at the back of the ACU to On. Then you can use the On/Off switch at the front panel of the ACU 19" rack version.

Connect the Ethernet cable to provide connection to the service port on the front of the ACU 19" rack version.

4.1.5 DC Input connector

Provide DC power to the ACU, for example by using the TT-6080A Power Supply or 24 VDC from the vessel's power supply.

DC input: Female plug (Weidmuller, Part number 1930050000) for wires up to AWG10/6 mm².


| Outline | Pin number | Pin function | Wire color |
|---|------------|--------------|------------|
|  | 1 | Vin+ | Red |
| | 2 | Vin- | Black |

Table 4-1: DC Input plug, outline and pin assignment

The connector for DC input is included in the delivery. Insert the power cable as shown below, and plug in the connector. Use the two red clamps to fasten the connector.




Figure 4-5: DC Input connector with power cable

For more information about power supply and power requirements see *Connecting power* on page 5-1.

4.1.6 ADU connector

There is just one cable from the ACU to the ADU. This is used to power the ADU, supply 10 MHz clock, handle all communication between ACU and ADU, and deliver the VSAT Rx and Tx signals.


| Outline | Pin number | Pin function |
|---|------------|---|
|  | 1 | Inner conductor: DC to ADU 10 MHz clock to ADU ACU to ADU internal communication VSAT Rx/Tx |
| | 2 | Outer conductor: GND (Shield) |

Table 4-2: N connector, outline and pin assignment

Important

Do not use TNC connectors on the ADU antenna cable or on pigtails. TNC connectors cannot carry the DC current for operating the ADU.

4.1.7 Rx/Tx connectors for VMU

Connect the Rx and Tx channels of the VMU to the Rx and Tx connectors of the ACU with the 2 supplied Rx/Tx cables (75 Ohm coax, F-F, 1 m).


| Outline | Pin number | Pin function |
|---|------------|--|
|  | 1 | Inner conductor: 10 MHz clock VSAT Rx/Tx |
| | 2 | Outer conductor: GND (Shield) |

Table 4-3: F connector, Rx and Tx, outline and pin assignment

For step-by-step guidelines how to set-up the VSAT modem see *VMU settings requirements* on page C-1.

4.1.8 NMEA 0183/2000 connector

(Prepared for NMEA 2000)

Connect the ship's gyro to this connector.


| Outline | Pin number | Pin function | Wire color |
|---|------------|----------------------|------------|
|  | 1 | – | – |
| | 2 | NET-H (NMEA 2000) | White |
| | 3 | NET-L (NMEA 2000) | Blue |
| | 4 | NET-S (NMEA 2000) | Red |
| | 5 | NET-C (NMEA 2000) | Black |
| | 6 | – | – |
| | 7 | – | – |
| | 8 | Shields | |
| | 9 | Line B (+) NMEA 0183 | |
| | 10 | Line A (-) NMEA 0183 | |
| | 11 | – | – |

Table 4-4: NMEA 0183/2000 connector, outline and pin assignment

NMEA 2000 power: 9-16 VDC

NMEA 2000 LEN (Load Equivalency Number): 2 (100mA)

NMEA 0183

The NMEA 0183 connection supports both IEC 61162-1 and IEC 61162-2.

- IEC 61162-1, baud rate 4800, format 8N1.
- IEC 61162-2, baud rate 38400, format 8N1.

The baud rate is auto detected by the ACU, the user cannot configure this interface.

Recommended NMEA 0183 cable:

Two-wire constructed with one enclosed shield

Network signal pair:

- Size: No. 24 AWG (0.24 sq. mm) or heavier
- Characteristic impedance: 95 - 140 Ohm
- Propagation delay: 5 nanoseconds per meter, maximum
- 15 Twists (minimum) per meter

4.1.9 RS-232 and RS-422 connectors

These connectors are used to access and configure the connected VSAT modem and for ACU control. See the VSAT modem requirements for use of the RS-232 or RS-422 connector.


| Outline | Pin number | Pin function |
|--|------------|-----------------------------------|
|  | 1 | – |
| | 2 | RXD |
| | 3 | TXD |
| | 4 | DTR |
| | 5 | Ground |
| | 6 | DSR |
| | 7 | RTS |
| | 8 | CTS |
| | 9 | Receive Signal Strength Indicator |

Table 4-5: RS-232 connector, male, outline and pin assignment


| Outline | Pin number | Pin function |
|---|------------|----------------|
|  | 1 | Ground |
| | 2 | Line A RXD (+) |
| | 3 | Line B TXD (-) |
| | 4 | Ground |
| | 5 | Ground |
| | 6 | – |
| | 7 | Line A RXD (-) |
| | 8 | Line B TXD (+) |
| | 9 | – |

Table 4-6: RS-422 connector, male, outline and pin assignment

4.1.10 LAN1, LAN2, LAN3 and LAN4 connectors

Four Ethernet connectors (type RJ45) for PC/laptops, routers, wireless access points. The maximum cable length per connection is 100 m. Depending on the VMU connected, a LAN connector may be used for modem control.




Figure 4-6: LAN1 –LAN4 connectors

For information how to configure the LAN network see *Configuring the LAN network* on page 6-22.


| Outline | Pin number | Pin function | Wire color |
|---|------------|---------------|--------------|
|  | 1 | Tx+ | white/orange |
| | 2 | Tx- | orange |
| | 3 | Rx+ | white/green |
| | 4 | Not connected | blue |
| | 5 | Not connected | white/blue |
| | 6 | Rx- | green |
| | 7 | Not connected | white/brown |
| | 8 | Not connected | brown |

Table 4-7: Ethernet connector, outline and pin assignment

Cable type: CAT5, shielded.

4.2 Interfaces of the VMU

For interfaces of the VMU and how to connect a VMU correctly to the ACU see the following sections and the user documentation of the VMU.

4.2.1 Connecting an iNFINITI® 5000 Series Satellite Router

Connect the VSAT modem to the ACU as shown in the figure below:




Figure 4-7: Connecting an iNFINITI® 5000 Series Satellite Router

Note Cable 3 is only used when using OpenAMIP protocol.

| Cable | Description | Cable specifications |
|-------|-------------------|---|
| 1 | RX Out to Rx In | 75 Ohm coax cables F-F (1m), included |
| 2 | RS-232 to Console | Possibly supplied together with the VSAT modem. VSAT modem RS-232 on ACU |
| 3 | LAN 1 or 2 | Standard Ethernet cable |
| 4 | Tx In to Tx out | 75 Ohm coax cables F-F (1 m), included |

Table 4-8: Cables to connect an iNFINITI® 5000 Series Satellite Router

For a detailed cable specification for VSAT modems see *VMU cable specifications* on page B-1. For step-by-step guidelines how to set-up the VSAT modem see Appendix C, *VMU settings requirements*.

4.2.2 Connecting an Evolution® X5 Satellite Router

Connect the VSAT modem to the ACU as shown in the figure below:




Figure 4-8: Connecting an Evolution X5 Satellite Router

Note Cable 3 is only used when using OpenAMIP protocol.

For cables see Table 4-8: *Cables to connect an iNFINITI® 5000 Series Satellite Router* on page 4-9.

For a detailed cable specification for VSAT modems see *VMU cable specifications* on page B-1. For step-by-step guidelines how to set-up the VSAT modem see Appendix C, *VMU settings requirements*.

4.2.3 Connecting a Comtech 570 L or 625 Satellite Modem

Connect the VSAT modem to the ACU as shown in the figure below:




Figure 4-9: Connecting a Comtech 570 L or 625 Satellite Modem

| Cable | Description | Cable specifications |
|-------|-------------------------------------|---|
| 1 | RX Out to Rx 950-1950 MHz | 75 Ohm coax cables F-F (1m) and adapter F to N 50 Ohm, included |
| 2 | RS-232 to Remote control and Alarms | 37-134337-A Cable Comtech Serial and RSSI |
| 3 | Tx In to Tx 950-1950 MHz | 75 Ohm coax cables F-F (1 m), included |

Table 4-9: Cables to connect a Comtech 570 L-Band Satellite Modem

For a detailed cable specification for VSAT modems see *VMU cable specifications* on page B-1.

Connecting power

This chapter is organised in the following sections:

- *Power source*
- *Power cable selection*
- *Connecting power*
- *Power up*

5.1 Power source

There are different options for the power supply:

- The 24 VDC ship supply provides power for the ACU.
- An AC line provides power through an AC/DC power supply. The TT-6080A Power Supply is recommended.

Note

Be aware of high start-up peak current: 35 A at 24 VDC, 5 ms.

In order to protect against short circuit in the power cable/connector, the ship's DC outlet must be protected by a 30 A fuse or circuit breaker.

5.2 Power cable selection

5.2.1 Source impedance

The maximum length of the power cable depends on the type of cable used and the source impedance of the DC power installation in the ship.

The maximum allowed source impedance depends on the usage of the power range of the terminal DC input (Start up voltage: 22 VDC guaranteed, operating range: 20 – 32 VDC; 23 A - 14 A).

Select a power outlet from the DC system and measure the source impedance of the ship installation as described in the next section.

Note

If the total impedance is higher than the limits stated in section 5.2.3, the terminal may become unstable and start to on/off oscillate.

The total impedance is made up of the source impedance of the ship power supply plus the impedance of connected cables including connectors and joints where cables are extended.

For further recommendations on power cable selection, see *Power cable recommendations* on page 5-3.

5.2.2 Measuring the ship source impedance

Select a power outlet from the ship 24 VDC system and measure the source impedance of the ship installation as described below.

1. Measure the voltage without load (R.var disconnected).
2. Set the current to e.g. 1 A by adjusting R.var.
3. Measure the corresponding voltage change.

Example: 1 A and 50 mV. Source impedance: $50 \text{ mV} / 1 \text{ Amp} = 50 \text{ mOhm}$.




Figure 5-1: Measuring the ship source impedance

5.2.3 Power cable recommendations

Overview

The ACU is delivered with a power connector (PCB plug-in connector, female plug, Weidmuller, Part number 1930050000), which accepts wires up to AWG10/6 mm².

- When installing the power cable, install positive and negative supply wires closely together side by side to keep cable inductance low.
- Ensure that cable inductance for the selected cable at the desired length is less than 50 uH. Approximately 50 m maximum length.

Calculating the maximum power cable length

For 24 VDC operation, the total impedance must be max. 60 mOhm (R_{max}), including the source impedance in the ship installation (R_{source}).

The total impedance is made up of the following:

- Source impedance in the ship installation
- Impedance of the selected power cable

To calculate the maximum cable extension, do as follows:

1. First measure the source impedance in the ship installation as shown in *Measuring the ship source impedance* on page 5-2.
2. Find the resistance per meter (R_{wire}) for the cable type you are going to use.
For 4 mm²/AWG 11, the value is 4.8 mOhm/m at 55°C
For 6 mm²/AWG 10, the value is 3.8 mOhm/m at 55°C
For other cable types, refer to the data sheet for the cable.

$$\text{Maximum length} = 0,5 \times (R_{max} - R_{source}) / (R_{wire})$$

The length is multiplied by 0.5 above because there are two conductors in the cable.

If the TT-6080A Power Supply is used, use $R_{\text{source}} = 0 \text{ m}\Omega$.

Examples for using the TT-6080A Power Supply:

$$\text{AWG11}_{\text{max}} = 0.5 \times (60 \text{ m}\Omega - 0) / 4.8 \text{ m}\Omega/\text{m} = 6.2 \text{ m}$$

$$\text{AWG10}_{\text{max}} = 0.5 \times (60 \text{ m}\Omega - 0) / 3.8 \text{ m}\Omega/\text{m} = 7.9 \text{ m}$$

5.3 Connecting power

To connect the power cable to the ACU

1. Connect the positive and negative input terminals to the ship's DC supply according to the recommendations in the previous sections.
2. Connect the power plug to DC Input.

For information on pin-out, see *DC Input connector* on page 4-3.




Figure 5-2: Connecting power to DC Input

5.4 Power up

1. Connect power to the VMU.
2. Switch on the ACU. The unit starts up and goes through an initialization procedure:
 - ACU POST
 - ADU Initializing
 - ADU POST
 - READY

This may take some time (up to a couple of minutes). Now the SAILOR 900 VSAT is ready to be calibrated (for first time power up) or receive data from the VSAT modem (when in normal operation). The ACU display shows the following message:



Figure 5-3: ACU display after first power on (example with LAN ports 1 and 4 used)

The LEDs **Power** and **Fail/Pass** are **steady green**, the LED Logon is off. For further information on status indicators see *Status signalling with LEDs and status messages* on page 9-7.

Make sure there are no hardware failures or error codes present, check the display of the ACU for events. For more information on error codes and events see *Initial troubleshooting* on page 9-15 and *System messages* on page F-1.

3. Continue to get the SAILOR 900 VSAT system ready for use and enter the satellite and modem specific data for this installation:
 - Satellite position and polarisation
 - Cable loss and azimuth calibration
 - VSAT modem profiles
 - Satellite profiles

For step-by-step instructions see *Introduction to the built-in web interface* on page 6-1.

For installation check lists see *Installation check* on page 7-1.

Initialisation in daily use

Once the system is configured and a satellite profile is active, the startup sequence is as follows:

- ACU POST

- ADU Initializing
- ADU SW upload (If the software versions in the ADU and ACU are not the same, a software update is done during startup.)
- ADU POST
- READY
- ACQUISITION
- TRACKING

Configuration

This chapter is organised in the following sections:

- *Introduction to the built-in web interface*
- *Calibration of the SAILOR 900 VSAT*
- *Configuration with the web interface*
- *Keypad of the SAILOR 900 VSAT ACU*

6.1 Introduction to the built-in web interface

6.1.1 Overview

Use the built-in web interface of the SAILOR 900 VSAT ACU to make a full configuration of the SAILOR 900 VSAT with the correct VMU, the satellite positions you intend to use and other parameters.




Figure 6-1: Configuration setup

For the rack version, connect the LAN cable to the front LAN connector of the ACU.

For quick start instructions see *Calibration of the SAILOR 900 VSAT* on page 6-3.

Note

For information on daily use of the SAILOR 900 VSAT system refer to the SAILOR 900 VSAT Quick Guide or see chapter 8, *Daily use – Quick guide*.

No installation of software is necessary because the web interface is built into the SAILOR 900 VSAT ACU.

Browsers supported

You access the web interface from a computer with a standard Internet browser.

6.1.2 Connecting to the web interface

To connect to the web interface of the ACU do as follows:

1. Power up the SAILOR 900 VSAT system, i.e. switch on the ACU. Wait until the LEDs on the front plate of the ACU show that the system is ready to be configured.
 - Power LED: Green
 - Logon LED: Off
 - Fail/Pass LED: Flashing green, during power-on self test, after that steady green.
2. Set up your PC network connection to use a static IP address:
 - IP: 192.168.0.2
 - Subnet mask: 255.255.255.0
 - Gateway: 192.168.0.1

For more detailed instructions and proxy server settings see *Overview and navigation* on page 6-8.

3. Connect a PC to LAN interface 3 (Service port, standard Ethernet) of the ACU. For the rack version connect the LAN cable to the front LAN connector of the ACU.




Figure 6-2: LAN connector used for configuring the SAILOR 900 VSAT

4. Open your Internet browser and enter the IP address of the ACU. The IP address is **http://192.168.0.1** (default).

5. The web interface opens directly with the **DASHBOARD** page.




Figure 6-3: SAILOR 900 VSAT Dashboard

For a detailed introduction to the web interface see *Overview and navigation* on page 6-8.

6.2 Calibration of the SAILOR 900 VSAT

You must align the ADU with the vessel's gyro compass. To do this, you make an azimuth calibration, i.e. you determine the offset of the ADU zero direction to the bow-to-stern line of the ship. This procedure is fully automatic.

Before you can do the calibration you must define a Service profile. After that, you create the satellite and VSAT modem profiles you want to use during normal operation. You must also set up blocking zones for the specific installation.

Important

You must logon as an administrator to do a calibration. See *Administration* on page 6-30.

For a detailed introduction to the web interface see *Overview and navigation* on page 6-8.

6.2.1 Setting up a service profile for calibration

To set up a service profile for calibration, do as follows:

1. Add a VSAT modem profile for calibration. This is not a physical modem, but a 'virtual' modem used for azimuth calibration of the antenna. Click **SETTINGS > VSAT modem profiles > New entry**.
2. Enter a name for the service profile, for example: Service.
3. In the drop-down list **VSAT modem** select **Service profile**. The remaining fields stay empty.
4. Click **Apply**. The service profile is added to the list of VSAT modem profiles.

The screenshot shows the Thrane & Thrane web interface. On the left is a sidebar menu with items: DASHBOARD, SETTINGS, Satellite profiles, VSAT modem profiles (circled in red), Blocking zones, Network, E-mail setup, Reports, SERVICE, ADMINISTRATION, HELPDESK, and SITE MAP. The main content area is titled 'ADD VSAT MODEM PROFILE'. It contains several input fields: 'Profile name' (empty), 'VSAT modem' (a dropdown menu showing '<select modem>' and circled in red), 'This modem profile is used on' (a dropdown menu showing '0 satellite profiles'), 'VSAT modem root password' (empty), 'VSAT modem user password' (empty), 'Baud rate' (a dropdown menu showing 'Default'), '10 Mhz reference' (a dropdown menu showing 'Internal ACU reference'), 'OpenAMIP IP address' (four empty boxes for IP address), and 'OpenAMIP port' (empty). At the bottom are 'Apply' and 'Cancel' buttons. A red arrow points to the 'Apply' button.

Figure 6-4: Service profile, add a Service 'modem' for calibration

5. Select **SETTINGS > Satellite profiles > New entry**. Enter the name of the satellite profile for calibration (a name of your own choice) and select the VSAT modem Service profile (created in step 3.).

The screenshot shows the Thrane & Thrane web interface. On the left is a sidebar with menu items: DASHBOARD, SETTINGS, Satellite profiles (circled in red), VSAT modem profiles, Blocking zones, Network, E-mail setup, Reports, SERVICE, ADMINISTRATION, HELPDESK, and SITE MAP. The main area is titled 'ADD SATELLITE PROFILE'. It contains several input fields: 'Satellite profile name' (text box), 'VSAT modem profile' (dropdown menu with 'Service Profile' selected and circled in red), 'Satellite position' (text box with '0 E'), 'Polarisation skew' (text box with '0'), 'Elevation cutoff' (text box with '10'), 'RX polarisation' (radio buttons for 'Horizontal' and 'Vertical', with 'Horizontal' selected), 'TRACKING' (section header), 'RX frequency' (text box with '10' and 'GHz' unit), 'Symbol rate' (text box with '25' and 'MS/s' unit), and 'NID' (text box with '0'). At the bottom are 'Apply' and 'Cancel' buttons. A large red oval highlights the fields from 'Satellite position' to 'NID', and a red arrow points to the 'Apply' button.

Figure 6-5: Service profile, add satellite information

6. Enter the data for the satellite that you want to use as a calibration reference. For satellite data see *DVB S satellites* on page D-1 or www.lyngsat.com. Make sure that the following requirements for the satellite are met:

| Satellite requirements for successful calibration | |
|---|--|
| Elevation | Elevation angle: 10 – 60 degrees Not allowed for calibration: Inclined orbit. |
| System encryption | DVB-S or DVB-S2 |
| NID | Preferably a unique NID (ONID). An azimuth calibration without NID can be useful in regions where the satellite operators do not broadcast NID (US, China, Australia etc.). |
| RX Polarisation | Horizontal or vertical polarisation. Not allowed: Left-hand circular (L) or right-hand circular (R). |

Table 6-1: Satellite requirements for elevation and carrier

7. Elevation cutoff: Not relevant for calibration.
8. Click **Apply** to save the settings for the service profile for calibration. The system is ready for the azimuth and cable calibration.

6.2.2 Calibration of azimuth and cable

Note

First you must set up a service profile, see 6.2.1.
The ship must not move during the calibration procedure.
The satellite must be visible from the location of the installation.

The calibration has 2 steps: Azimuth calibration and cable calibration.

The screenshot shows the Thrane & Thrane web interface. On the left, a sidebar menu lists various options: DASHBOARD, SETTINGS, SERVICE, Upload, Calibration (highlighted with a red circle), XIM data, ADMINISTRATION, HELPDESK, and SITE MAP. The main content area is titled 'CALIBRATION'. It contains two sections: 'Fixed heading' and 'Azimuth calibration'. In the 'Fixed heading' section, the 'Enable' checkbox is checked, and the 'Vessel heading' is set to 0.0 degrees. An 'Apply' button is present. The 'Azimuth calibration' section shows an 'Azimuth calibration value' of 112.35 degrees. The 'Service profile' dropdown menu is highlighted with a red circle and shows '<select service profile>'. Below this, several fields are listed: 'Satellite position', 'RX polarisation', 'RX frequency', 'Symbol rate', and 'NID', all of which are currently empty. At the bottom of the interface, there are two sets of buttons: 'Start', 'Cancel', and 'Refresh' for 'Azimuth calibration', and another set for 'Cable calibration'. Red arrows point to the 'Start' buttons in both sections.

Figure 6-6: Web interface: SERVICE, Calibration: Azimuth and cable

1. Click **SERVICE > Calibration**.
2. If needed, you can enable fixed heading and enter the fixed heading in degrees. This is useful for training, test and fixed installations like remote areas or oil rigs etc. Then click **Apply**.

3. Select the service profile in the drop down list, for example **Service**. All profiles with the VSAT modem Service are displayed in the list.

Important

Do not refresh the browser during calibration, this will interrupt and restart the calibration procedure. The screen is not automatically updated when new data are available from the SAILOR 900 VSAT. You may click the button **Refresh** in the web interface to update the screen.

4. Click **Start** in the section **Azimuth calibration** and wait 5 minutes for the calibration to finish. After finished calibration click the button **Refresh**. Then a message is displayed when the calibration has been completed successfully.
5. Click **Start** below **Cable calibration** and wait 10 minutes for the calibration to finish. After finished calibration click the button **Refresh**. Then a message is displayed when the calibration has been completed successfully.

The SAILOR 900 VSAT is calibrated now.

If the calibration failed there will be a message on the calibration screen.

6.3 Configuration with the web interface

6.3.1 Overview and navigation

Topics in the web interface

Use the site map to get an overview over the existing menus, submenus and topics. You can click on each menu in the site map to go directly to the page or display the respective submenu.




Figure 6-7: Topics in the web interface (SITE MAP)

Navigation

The web interface consists of the following sections:




Figure 6-8: Sections of the web interface

1. The **navigation pane** holds the main menu. Clicking an item in the menu opens a submenu in the navigation pane or a new page in the contents section.
2. The **signal status field** shows the signal strength. The signal strength can vary during operation, depending on the current position relative to the satellite and the call or data session activity.
3. The **icon bar** shows icons for active events, when relevant. For explanations of the icons, see the next section, *Icons in the icon bar*.
4. The **contents section** shows the page selected in the navigation pane. This section is used for viewing or changing settings, or for performing actions.

When the Dashboard is displayed you have verified that the connection to the SAILOR 900 VSAT can be established. The web interface is ready for use. You can continue to configure the system.

If you cannot establish a connection there might be problems with the Proxy server settings of your PC. See *Proxy server settings in your browser* on page 6-10 for further information.

Icons in the icon bar

The following icons may appear in the icon bar in the web interface:


| Icon | Explanation |
|---|--|
|  | An event is active. Click the icon to see a list of active events. For explanations of the event messages, see <i>Event messages – overview</i> on page F-1. Note that this icon will remain in the icon bar as long as the event is active. |

Table 6-2: Web interface: Icons

Navigating the web interface

- **To expand a menu**, click the menu in the navigation pane.
- **To access status and settings**, click the relevant subject in the navigation pane or click the relevant icon in the icon bar. The status or settings are displayed in the contents section.
- **To get an overview over the submenus available use the site map**, click **SITE MAP** in the navigation pane. Click on items in the site map to go directly to the relevant location.

Note

You can give access to some configuration settings for users that are not administrators. For information on how to set up user permissions, see *Setting up user permissions* on page 6-32.

Proxy server settings in your browser


If you are connecting your computer using a LAN or WLAN interface, the **Proxy server** settings in your browser must be disabled before accessing the web interface. Most browsers support disabling of the Proxy server settings for one specific IP address, so you can disable Proxy server settings for the web interface only, if you wish. Consult your browser help for information.

To disable the use of a Proxy server completely, do as follows:

Note

The following description is for **Microsoft Internet Explorer**. If you are using a different browser, the procedure may be different.

1. In Microsoft Internet Explorer, select **Tools > Internet Options > Connections > LAN Settings**.



2. Clear the box labeled **Use a proxy server for your LAN**.
3. Click **OK**.

When the proxy server settings are disabled, close and restart your browser.

You may need to change this setting back on return to your Internet connection.

Setting up a static IP address for your network connection

To set up your PC to a static IP address, do as follows (example for Windows XP):

1. Go to **Start > Settings > Control Panel > Network Connections**.
2. Right-click on the **LAN connection** you want to use.
3. Select **Properties**, highlight **Internet Protocol (TCP/IP)**.
4. Click **Properties**.
 - Make sure that the following is selected:
 - Use the following IP address (works for ACU default IP 192.168.0.1):
IP address: 192.168.0.2, Subnet mask: 255.255.255.0, Default gateway: 192.168.0.1
 - Use the following DNS server addresses: Not used.

6.3.2 Using the Dashboard

The Dashboard is the first screen that is displayed when the user or administrator enters the IP address of the web interface of the ACU. The Dashboard is used for set up and selection of satellite and modem profiles, control and inspection of ongoing communication and for viewing properties and status of the ACU and ADU.




Figure 6-9: Web interface: DASHBOARD

Information fields on the Dashboard

| SAILOR 900 VSAT parameter | Description |
|-------------------------------|--|
| System status | <p>Current status of the SAILOR 900 VSAT.</p> <p>Examples:</p> <p>Not ready (Waiting for input from GNSS, e.g. GPS)</p> <p>Ready (Waiting for data from the VSAT modem or no satellite profile selected),</p> <p>Acquisition (Locating the satellite and acquiring the signal),</p> <p>Tracking (Tracks the current satellite, operational)</p> <p>No Tx zone (Antenna is pointing in a no TX zone; TX is off)</p> <p>Blocking zone (Antenna is pointing into a blocking zone)</p> <p>Service switch (Service switch in ADU activated)</p> <p>Safe mode (Error, followed by an error description)</p> |
| GPS position | Current position of the vessel, reported by the GPS module |
| Vessel heading | Ship's heading in degrees with reference to North, provided by the ship's gyro. |
| Satellite profile | Name of the currently active satellite profile. |
| Satellite position | Entered in EDIT SATELLITE PROFILE |
| RX polarisation | Horizontal or vertical, entered in EDIT SATELLITE PROFILE |
| TX polarisation ^a | Co-pol or X-pol, auto-selected by VSAT modem |
| RX RF frequency ^a | Ku band receiving frequency, auto-selected by VSAT modem |
| LNB Lo frequency ^a | Auto-selected by VSAT modem |
| TX RF frequency ^a | Auto-selected by VSAT modem |
| BUC Lo frequency | 12.8 GHz (system parameter) |

Table 6-3: Web interface, DASHBOARD, SAILOR 900 VSAT parameters

| SAILOR 900 VSAT parameter | Description |
|--|---|
| Tracking RF frequency | Enter in satellite profile. |
| ACU part name, ADU part name, ACU serial number, ADU serial number, Software version | Part names, serial numbers for ACU and ADU, software version of the SAILOR 900 VSAT, read out from the units connected. |

Table 6-3: Web interface, DASHBOARD, SAILOR 900 VSAT parameters (Continued)

a. Can be altered when using a generic modem profile.

| VSAT MODEM parameter | Description |
|-----------------------------|--|
| Signal level | Current input signal level from VSAT modem. iDirect openAMIP modem: (PWR) 0-500, delivered by the connected modem. For values <250 the antenna searches after a new signal. Other modem: Signal level in dB. |
| RX IF frequency | Read out from VMU. |
| TX IF frequency | Read out from VMU. |
| Model | VSAT modem name, entered in SETTINGS > VSAT modem profiles . |

Table 6-4: Web interface, DASHBOARD, VSAT MODEM parameter

| POINTING parameter | Description |
|---------------------------|---|
| Azimuth relative | Current value for azimuth, relative to the vessel heading |
| Elevation relative | Current value for elevation, relative to the vessel |
| Polarisation skew | Current value for polarisation skew |

Table 6-5: Web interface, DASHBOARD, POINTING parameter

6.3.3 Satellite profiles and VSAT modem profiles

Satellite profiles

On the page **Satellite profiles** you add, edit and delete satellite profiles. A satellite profile contains all settings that are necessary for a successful connection to the satellite, including a VSAT modem profile. Most of the data you have to fill in are provided by your VSAT service provider.

You must activate one satellite profile.

Note

You must add at least one VSAT modem profile before you can add a satellite profile. See *VSAT modem profile – New entry and Edit* on page 6-18.

| Thrane & Thrane | | |
|---|---------------------------|---|
| SIGNAL: <div></div> | | |
| <ul style="list-style-type: none"> DASHBOARD SETTINGS <ul style="list-style-type: none"> Satellite profiles VSAT modem profiles Blocking zones Network E-mail setup Reports SERVICE ADMINISTRATION | SATELLITE PROFILES | |
| | Name▼ | Position▼ |
| | 7E W3A Eutelsat | 7° E Edit / Delete / Activate |
| | 15W Telstar 12 | 15° W Edit / Re-activate |
| | New entry | |
| | | |
| | | |
| | | |
| | | |
| | | |

Figure 6-10: Web interface: SETTINGS - list of satellite profiles (example)

Satellite profiles – New entry and Edit

Each satellite profile has one assigned VSAT modem profile.

Figure 6-11: Web interface: SETTINGS, Satellite profiles – new entry (example)

To add or edit a satellite profile, do as follows:

1. Go to **SETTINGS** or **Satellite profiles** and click **Edit** or **New entry**.
2. Enter or edit the Satellite profile name.
3. Select a VSAT modem profile. The page automatically displays the parameters available for the selected VSAT modem profile.
For instruction how to add a VSAT modem profile see *VSAT modem profile – New entry and Edit* on page 6-18.
4. Enter the data for the satellite that you want to use. For satellite data see *DVB S satellites* on page D-1 or www.lyngsat.com.
5. Polarisation skew: See documents from VSAT provider.

6. At Elevation cutoff enter the minimum elevation angle for the antenna to function in accordance with ETSI (ETSI EN 302 340) and FCC (FCC §25.205) regulations.
- **ETSI (ETSI EN 302 340):** The minimum elevation angle depends on the Tx bandwidth and the nominal power of the VSAT modem, see the table below.

| Bandwidth | Nominal VSAT modem power | | | | | | | | |
|-----------|--------------------------|---------|---------|---------|---------|---------|---------|--------|--------|
| | -22 dBm | -20 dBm | -18 dBm | -16 dBm | -14 dBm | -12 dBm | -10 dBm | -8 dBm | -6 dBm |
| 64 kHz | 3° | 4° | 4° | 5° | 6° | 7° | 8° | 10° | 12° |
| 128 kHz | 3° | 4° | 4° | 5° | 6° | 7° | 8° | 10° | 12° |
| 256 kHz | 3° | 4° | 4° | 5° | 6° | 7° | 8° | 10° | 12° |
| 512 kHz | 3° | 4° | 4° | 5° | 6° | 7° | 8° | 10° | 12° |
| 1024 kHz | 3° | 4° | 4° | 5° | 6° | 7° | 8° | 10° | 12° |
| 2048 kHz | 3° | 3° | 3° | 4° | 5° | 5° | 6° | 8° | 9° |
| 4096 kHz | 3° | 3° | 3° | 3° | 4° | 4° | 5° | 6° | 7° |
| 8192 kHz | 3° | 3° | 3° | 3° | 3° | 3° | 4° | 5° | 5° |
| 16384 kHz | 3° | 3° | 3° | 3° | 3° | 3° | 3° | 4° | 4° |
| 32768 kHz | 3° | 3° | 3° | 3° | 3° | 3° | 3° | 3° | 3° |

Table 6-6: Elevation cutoff (in degrees) versus VSAT modem bandwidth and power

- **FCC (FCC §25.205):** 5 degrees
7. Click **Apply** to save the settings for the satellite profile.

VSAT modem profiles

A VSAT modem profile contains all VSAT modem settings that are necessary for a successful connection to the satellite. The data you have to fill in are provided by your

VSAT service and modem provider. You must add at least one VSAT modem profile.




Figure 6-12: Web interface: SETTINGS, VSAT modem profiles – list (example)

To create a new VSAT modem satellite profile, click **New entry**. To edit or delete a VSAT modem profile, click **Edit** or **Delete**.

VSAT modem profile – New entry and Edit

On the page **VSAT modem profiles** you create, edit or delete VSAT modem profiles. The supported VSAT modem profiles are listed in the drop-down list **VSAT modem profile**. The VSAT modem named Service is a modem profile used during azimuth calibration.

To add or edit a VSAT modem profile, do as follows:

- 1. Go to **SETTINGS > VSAT modem profiles** and click **New entry** or **Edit**.




Figure 6-13: Web interface: SETTINGS, VSAT modem profiles – new entry (example)

2. Fill in a VSAT modem profile name of your own choice.
3. Select one of the supported VSAT modems.
Generic modem: If you have a modem that is not included in the list, select the generic modem. This is mainly used for troubleshooting purposes
4. Fill in or edit the data provided by your VSAT service provider.
Enter the passwords, if needed.
Select the VSAT modem baud rate and whether you want to use the 10 MHz reference from the ACU or the VSAT modem.
For OpenAMIP IP address: Make sure that you have entered this IP address also for the LAN connector that is used for the OpenAMIP modem, see *Configuring the LAN network* on page 6-22.
5. Click **Apply** to add the new profile to the list of VSAT modem profiles or to accept the edits.

6.3.4 Setting up Blocking zones (RX and TX)

On this page you define blocking zones, i.e. NO TX and RX zones, enter azimuth values and elevation angles for each blocking zone. You must select **Active** to enable a blocking zone.

Thrane & Thrane

SIGNAL: 00000000

BLOCKING ZONES

| Active | Azimuth | Elevation | No TX |
|-------------------------------------|-------------|------------|-------------------------------------|
| <input checked="" type="checkbox"/> | 264° - 297° | -25° - 12° | <input checked="" type="checkbox"/> |
| <input checked="" type="checkbox"/> | 264° - 281° | -25° - 22° | <input checked="" type="checkbox"/> |
| <input type="checkbox"/> | 0° - 360° | -25° - 30° | <input checked="" type="checkbox"/> |
| <input type="checkbox"/> | 0° - 10° | 0° - 10° | <input type="checkbox"/> |
| <input type="checkbox"/> | 0° - 0° | 0° - 0° | <input type="checkbox"/> |
| <input type="checkbox"/> | 0° - 0° | 0° - 0° | <input type="checkbox"/> |
| <input type="checkbox"/> | 0° - 0° | 0° - 0° | <input type="checkbox"/> |
| <input type="checkbox"/> | 0° - 0° | 0° - 0° | <input type="checkbox"/> |

Apply Cancel

Diagram illustrating the blocking zone configuration. The diagram shows a circular field of view with azimuth angles marked from 0° to 360° in 45° increments. A vertical oval shape is drawn on the diagram, centered at 0°/180°.

Figure 6-14: Web interface: SETTINGS, Blocking zones – azimuth and elevation

To define and set a blocking zone, do as follows:

1. Select **SETTINGS > Blocking zones**.
2. Select **Active** to enable the blocking zone.

3. **Azimuth:** Enter start and stop azimuth value in degrees for the blocking zone. Values allowed: 0 to 360 degrees. Enter clockwise.




Figure 6-15: Blocking zone, example: 315 - 45 degrees




Figure 6-16: Blocking zone, example: 45 - 315 degrees

4. **Elevation:** Enter the start and stop elevation angle for the blocking zone. If you enter nothing, there will be no blocking zone. Values allowed: -30 to 90 degrees.

Important You must enter 2 different elevation angles to have an active blocking zone.

5. Select **No TX** for zones if you don't want the system to transmit.
If not selected, the system also transmits when pointing through areas with blocking objects. The VSAT modem will shut off for TX if no signal is received.
6. Click **Apply** to save the blocking zones.

6.3.5 Configuring the LAN network

You can enter a host name. The host name helps identifying the SAILOR 900 VSAT system when sending e-mail reports. The ACU has four 10/100 Mbit Ethernet ports labelled LAN port 1, 2, 3 and 4. The ports are divided in three groups, each operating in its own network. You can setup DNS and Gateway.

To configure the LAN network go to **SETTINGS > Network**.

NETWORK

Host name:

LAN port 1: VSAT Modem Unit

Mode: ☒ Static IP ☐ DHCP client

IP address:

Netmask:

LAN port 2: LAN

Switched network with LAN port 1

LAN port 3: Service

Mode: Static IP

IP address:

Netmask:

LAN port 4: LAN

Mode: ☐ Static IP ☒ DHCP client

IP address:

Netmask:

DNS setup

DNS source:

Primary DNS:

Secondary DNS:

Gateway setup

Default gateway source:

Default gateway:

Figure 6-17: Web interface: SETTINGS, Network (LAN connectors, DNS and Gateway setup)

Important

Make sure that the 3 networks do not use IP address ranges that overlap.

| Sections | Preferred use |
|-------------------------|--|
| NETWORK Host name | The host name is used for identifying the ACU in local networks and in e-mail reports. The default host name is acu. You can change the name. Letters (a-z), digits (0-9) and hyphen (-) are allowed as legal characters. Note: The host name must start with a letter. |
| LANPort1 + 2 | LAN port 1 and 2 are switched, i.e. they share the same IP address and operate on the same network. This network is usually connected to the VSAT Modem Unit. LAN port 1 can be set to static IP or DHCP client. For OpenAMIP IP modem: Make sure that you have entered this IP address also for the VSAT modem profile of the OpenAMIP modem, see <i>VSAT modem profile – New entry and Edit</i> on page 6-18. |
| LAN Port 3 | LAN port 3 is dedicated as the service port. By default this port has the IP address 192.168.0.1; the current value can be displayed in the ACU display. In a 19" rack mount it is recommended to connect LAN port 3 to the front port (via rear connector, see the figure <i>ACU rack version, connector panel overview</i> on page 4-2), for access to the service port from the rack front. LAN port 3 can be set to static IP or DHCP client. |
| LANPort4 | LAN port 4 can be used for connection to the LAN of the vessel or other general purpose. LAN port 4 can be set to static IP or DHCP client. |

Table 6-7: Setup of LAN connectors, DNS and Gateway

Static IP or DHCP Client

If you select **DHCP client** the network IP address and sub-net mask must be provided by a DHCP server on that network.

If you select **Static IP** address you must specify a unique IP address and a sub-net mask.

DNS setup

If you have access to a Domain Name Server (DNS) you can specify the address of the e-mail server by using the server name instead of its IP address. This can be used in

Outgoing mail server in *E-mail setup* on page 6-25.

You may statically specify the address of one or two DNS. Select the DNS source as static and fill in IP address or addresses.

Alternatively, if your DHCP server can provide a DNS address and you have selected DHCP client above, then select the same LAN as your DNS source.

Gateway setup

If the ACU needs to communicate with network units outside the specified sub-nets, you must specify a default gateway (typically a router).

The default gateway can be set as a static IP address. Then set the default gateway source to static and enter the IP address of the default gateway. To remove the default gateway set it to 0.0.0.0.

Alternatively, if your DHCP server is able to provide a default gateway address and you have selected DHCP client above, then select the same LAN as your default gateway source.

6.3.6 E-mail setup

To be able to send diagnostics and statistics reports using e-mail you must set up a couple of parameters. Contact your IT department for the specific data

To configure the e-mail setup, do the following:

1. Go to **SETTINGS > E-mail setup**.

The screenshot shows the Thrane & Thrane web interface. At the top, there's a header with the company name and a signal strength indicator. Below this is a sidebar menu with options: DASHBOARD, SETTINGS, Satellite profiles, Blocking zones, Network, E-mail setup (highlighted), Reports, SERVICE, ADMINISTRATION, HELPDESK, and SITE MAP. The main content area is titled 'E-MAIL SETUP' and contains the following fields: 'Outgoing mail server (SMTP)' with the value '10.1.6.99', 'SMTP port number' with the value '25', 'SMTP authentication' with radio buttons for 'None' (selected) and 'Credentials', 'User name' with an empty text box, and 'Password' with an empty text box. At the bottom of the form are 'Apply' and 'Cancel' buttons.

Figure 6-18: Web interface: SETTINGS, E-mail setup (example)

2. Enter the data for Outgoing mail server (SMTP), SMTP port number, SMTP authentication, User name and password. This data is typically provided by your IT department.

Note

You must set **Outgoing mail server** to an IP address if DNS has not been set up in **DNS setup** in *Configuring the LAN network* on page 6-22.

6.3.7 Sending statistics reports

SAILOR 900 VSAT can send a statistics report at fixed intervals. This report contains historical information from the SAILOR 900 VSAT of up to 1 month. It is sent as a zipped attachment to an e-mail. The file format is a comma separated text file. The report can then be processed in spreadsheet applications, e.g. Microsoft Excel.

Figure 6-19: Web interface: SETTINGS, Reports (example)

To set up sending a statistics report, do as follows:

1. Go to **SETTINGS > Reports**.
2. In the section **STATISTICS REPORT** enter the following:
 - SMTP server.
 - Sender e-mail address, this address will be the e-mail address from sending the report.
 - List of recipients (comma separated).
 - Send the report each: Select disabled, day (default) with 2-minute samples, week with hourly samples or month with hourly samples. The report contains statistics data for the selected.
3. Click **Apply**.
 You can also send the report at any time by clicking **Send now** or download it directly to your computer by clicking **Download**. You can select statistics for the day, week or month.

The following parameters are recorded in the statistics report:

| Parameter recorded | Description |
|---|--|
| UTC. (s) UTC (YYYY-MM-DD hh:mm) | UTC in seconds and date format for the data set. |
| RSSI.Av RSSI.Max RSSI.Min | Received signal strength (average, maximum and minimum value) for the sampling interval |
| POS.Lat (degree) POS.Long (degree) POS.Valid | Latitude value of position Longitude value of position Fix = valid position, No Fix = invalid position |
| Heading.Samp (degree) Heading.Max (degree) Heading.Min (degree) Heading.Range (+/-degree) | Ship's heading (sample, maximum and minimum value, range) for the sampling interval. See Figure 6-20: <i>Statistics – how to read data for a range.</i> |
| Antenna.Azi (degree) Antenna.Azi Max (degree) Antenna.Azi Min (degree) Antenna.Azi Range (+/-degree) | Current antenna azimuth (sample, maximum and minimum value, range) for the sampling interval. See Figure 6-20: <i>Statistics – how to read data for a range.</i> |
| Antenna.Ele (+/-degree) Antenna.Ele Max (+/-degree) Antenna.Ele Min (+/-degree) | Current antenna elevation (sample, maximum and minimum value) for the sampling interval. |
| Vsat.rx_lo_freq (GHz) Vsat.tx_lo_freq (GHz) | Rx frequency of VSAT modem for this record Tx frequency of VSAT modem for this record |
| Tracking.rf freq (GHz) Tracking.type | Tracking RF frequency for this record Narrow filter, DVB-S2 decoder and VSAT modem RSSI. |
| Sat.long (degree) | |
| Carrier rf.rx (GHz) Carrier rf.tx (GHz) | Rx frequency of carrier for this record Tx frequency of carrier for this record |
| Rx Lock (%) Logon (%) | Rx locked and logon time, in percent, for the sampling interval |

Table 6-8: Parameters recorded in a statistics report

| Parameter recorded | Description |
|--------------------|--|
| Pos Ok (%) | Valid position, in percent of the sampling interval |
| VMU Connection (%) | No link with VSAT modem, in percent of the sampling interval |
| Blocking (%) | Ship in blocking zone, in percent of the sampling interval |

Table 6-8: Parameters recorded in a statistics report (Continued)




Figure 6-20: Statistics – how to read data for a range

Processing the statistics report in a spreadsheet application

The statistics report is in a data format that can be imported into spreadsheet applications, e.g. Microsoft Excel, for further processing.

1. Save the zipped file to your computer and extract the text file. The file name contains the identification of the system (example: adu-acu3_stat_20111021110901_day csv..txt).
2. Open the spreadsheet application, for example Microsoft Excel. On the tab Data click the tab Import from text. Import the unzipped text file and follow the instructions in the wizard. When asked about the delimiter, select 'comma'.

The following figure shows an example of a statistics report in MS Excel 2007.




Figure 6-21: Statistics report (example)

6.3.8 Sending a diagnostic report

You can send automatically generated diagnostic reports at fixed intervals. The diagnostic report contains information relevant for the service personnel during troubleshooting.

To set up sending a statistics report, do as follows:

1. Go to **SETTINGS > Reports**.
2. In the section **DIAGNOSTICS REPORT** enter the following:
 - Sender e-mail address, this address will be the e-mail address from sending the report.
 - List of recipients (comma separated).
 - Send the report each: Select disabled, day (default), week or month. The report contains events and notifications of the selected period.
3. Click **Apply**.

If you want to generate a diagnostic report here and now click **Send now** or go to the page **HELPDESK** and click **Generate report** to download it directly to your computer.

For further details see *Generating a diagnostic report* on page 9-2.

6.3.9 Upload

For uploading new software to the SAILOR 900 VSAT see *Software update* on page 9-4.

6.3.10 Administration

In this section of the web interface you can configure the following administrative settings:

- *Setting up user permissions*
- *Resetting to factory default*

Accessing the administration settings: Logging on

The Administration settings require an Administration user name and password. To log on as administrator, do as follows:

1. Select **ADMINISTRATION** from the left navigation pane.
2. Enter the Administration user name and password.
The default user name is **admin** and the default password is **1234**.

Figure 6-22: Web interface: Administration

If you have forgotten the administrator password, you can reset the password. For further information, see the next section *Resetting the administrator password*.

3. Click **Logon**.
The Administration page is now updated to let you change the user name and password or log off Administration.

Changing the administrator password

1. After entering the administrator user name and password in the **ADMINISTRATION** page, locate the section **Change administrator logon**.

Figure 6-23: Web interface: Administration, change administrator logon

2. Type in the new password and retype it on the next line.
3. Click **Change**.

At the next logon the new password is required.

Resetting the administrator password

If you have forgotten and need to reset the administrator password, do as follows:

1. Contact your service partner for a reset code.
Please report the serial number of the ACU. You find it in the **Dashboard, ACU serial number**.
2. Click the link **Forgot administrator password?** at the bottom of the **ADMINISTRATOR LOGON** page (see Figure 6-22: *Web interface: Administration*).

Figure 6-24: Web interface: ADMINISTRATION, Reset administrator password

3. Type in the reset code obtained from your service partner and click **Reset**.

4. Type in the user name **Admin** and the default password **1234**.
5. Click **Logon**.
For information on how to change the password, see the section *Changing the administrator password* on page 6-31.

Logging off administration

If you have not entered anything for 30 minutes under **ADMINISTRATION**, you are logged off automatically. To log off manually, click **Logoff** under administrator logoff in the **ADMINISTRATION** page.

Setting up user permissions

You can manage user access to certain functions of the SAILOR 900 VSAT system. You can allow or deny users that are not administrators access to certain functions and make these pages read-only. This is useful if you want to protect the system against unintended changes or tampering of the system.

Important

Study this screen thoroughly and decide which areas of the SAILOR 900 VSAT system you want to give non-administrator users access to.

To set up the user permissions, do as follows:

1. From the left navigation pane, select **ADMINISTRATION > User permissions**.

| Thrane & Thrane | |
|--|---|
| SIGNAL: 00000000 | |
| DASHBOARD | |
| SETTINGS | |
| SERVICE | |
| ADMINISTRATION | |
| User permissions | |
| Factory default | |
| HELPDESK | |
| SITE MAP | |
| ALLOW USERS TO: | |
| Upload software | <input type="radio"/> Yes <input checked="" type="radio"/> No |
| Change satellite profiles | <input type="radio"/> Yes <input checked="" type="radio"/> No |
| Change VSAT modem profiles | <input type="radio"/> Yes <input checked="" type="radio"/> No |
| Change blocking zones | <input type="radio"/> Yes <input checked="" type="radio"/> No |
| Change network | <input type="radio"/> Yes <input checked="" type="radio"/> No |
| Perform calibration | <input type="radio"/> Yes <input checked="" type="radio"/> No |
| Modify XIM data | <input type="radio"/> Yes <input checked="" type="radio"/> No |
| Perform self test | <input type="radio"/> Yes <input checked="" type="radio"/> No |
| <input type="button" value="Apply"/> <input type="button" value="Cancel"/> | |

Figure 6-25: Web interface: ADMINISTRATION, User permissions

2. For each item under **ALLOW USERS TO:** select
 - **Yes** to allow access or

- **No** to block access to the settings. Then the pages are read-only, changes cannot be made by non-administrator users.

Change network: Change IP configuration of the LAN connectors. For further information see *Configuring the LAN network* on page 6-22.

Modify XIM data: Only used during service and maintenance.

3. Click **Apply**.

The settings to which access is denied are now greyed out for the non-administrator user.

Resetting to factory default

When resetting SAILOR 900 VSAT to factory default, the following settings are deleted:

- All satellite profiles
- All VSAT modem profiles
- Blocking zones
- Network setup
- User permissions
- ACU display: brightness setting

To reset to factory default settings, do as follows:

1. From the left navigation pane, select **ADMINISTRATION > Factory default**.



Figure 6-26: Web interface: ADMINISTRATION, Factory default

2. Click **Reset to factory default**.

Note

Calibration data for azimuth and cable calibration are not reset during factory default.

6.4 Keypad of the SAILOR 900 VSAT ACU

6.4.1 ACU display and keypad

In the ACU display you can see the current state of the system. You can also see events (warnings, errors and information) and how the system has been configured. Use the keypad to navigate through the menu tree.

You can reset the system by pressing the up and down arrow keys simultaneously.



Signal strength

Figure 6-27: Display (example) and keypad of the ACU

| Display text | Explanation |
|--------------|---|
| TRACKING | <p>Current status of the SAILOR 900 VSAT.</p> <p>Examples:</p> <p>NOT READY (Waiting for input from GNSS, e.g. GPS)</p> <p>READY (Waiting for data from the VSAT modem or no satellite profile selected),</p> <p>ACQUISITION (Locating the satellite and acquiring the signal),</p> <p>TRACKING (Tracks the current satellite, operational)</p> <p>NO TX ZONE (Antenna is pointing in a no TX zone, TX is off)</p> <p>BLOCKING ZONE (Antenna is pointing into a blocking zone),</p> <p>SERVICE SWITCH (Service switch in ADU activated)</p> <p>SAFE MODE (Error, followed by an error description)</p> |
| MAIN | Current menu. For all menus see <i>Antenna Control Unit, menu tree</i> on page 6-36. |
| TX:ON | The ADU is ready to transmit. |
| GPS:OK | A GPS signal is received from the GPS module. |
| HDG:OK | Ship heading data received from the ship's gyro. |

Table 6-9: Items in the ACU display (Example)

| Display text | Explanation |
|--------------|--|
| LAN:1--- | LAN connectors used. Example: LAN1 is used, LAN 2, 3 and 4 are not used |
| SAT:151.2 W | Satellite position of currently active satellite profile. Example: 151.2° West. |
| RX:H | RX polarisation of currently active satellite profile. Example: Horizontal. |
| 11.362/10.75 | Rx RF frequency and LNB LO Frequency |
| TX:X | TX polarisation of currently active satellite profile. Example: Cross polarisation. |


Table 6-9: Items in the ACU display (Example)

After 1 hour the display is dimmed to lowest intensity. Press any key to light up the display.

6.4.2 Navigating the menus

Use the keypad to navigate the menus.

- Press **OK** or ► to select a menu item.
- Use the arrow keys ▲ and ▼ to go through the menu items or enter a number, digit by digit.
- Use the arrow keys ◀ and ▶ to go through the settings and move from one digit to the next.
- Press **OK** to select a setting.
- Press ◀ again to move one level up. If applicable, confirm to store the new setting by pressing **OK**.



6.4.3 The menu tree

In the menu tree you can see how the system has been configured. You can also enter satellite information directly, if it is necessary to change the satellite information and you cannot use a connected PC and the web interface.




Figure 6-28: Antenna Control Unit, menu tree

Top-level menu


| Top-level menu | Description |
|----------------|--|
| MAIN | <p>View with current status of the SAILOR 900 VSAT. Example when logged on to the satellite:</p>  <p>This view is displayed after a time out of 10 minutes. Press any key (except left arrow) to enter the menu at MAIN.</p> <p>New events are shown in this display. If an event is displayed, press OK to jump directly to the menu EVENTS for viewing the currently active events.</p> |
| ANTENNA | Shows the current ADU parameters, position, software version and serial numbers of the ADU and ACU. |
| MODEM | Selected VMU type and setup, including signal level. |
| NETWORK | Shows the IP address of the web interface of the ACU and the management mask. You need this IP address to access the web interface with a PC. |
| SATELLITE | Current satellite information. This information is entered using the web interface. |
| EVENTS | View system events. Active events are shown as: X ACTIVE EVENTS in the MAIN display. Press OK to update the list. |

Table 6-10: Top-level menus of the ACU

Menu descriptions

| ANTENNA menu | Description |
|----------------|--|
| POINTING | <p>ANTENNA: READY (no satellite profile selected), ACQUISITION (in the process of logging on), TRACKING (tracks the current satellite, operational)</p> <p>ELEVATION: Current elevation angle of the antenna</p> <p>AZIMUTH: Current azimuth of the antenna, with reference to North</p> |
| POLARIZATION | <p>RX POLARIZATION: HORIZONTAL or VERTICAL, read from connected VSAT modem.</p> <p>TX POLARIZATION: X-POL or P-POL, read from connected VSAT modem.</p> |
| GPS | <p>LATITUDE: current latitude, read from GPS module.</p> <p>LONGITUDE: current longitude, read from GPS module.</p> <p>FIX TYPE: 2D or 3D</p> |
| HEADING | Ship's heading in degrees with reference to North, provided by the ship's gyro. |
| VERSIONS | Current software version. |
| SERIAL NUMBERS | <p>ACU: Serial number of the below-deck unit</p> <p>ADU: Serial number of the antenna</p> |

Table 6-11: ANTENNA menu of the ACU

| MODEM menu | Description |
|------------|---|
| MODEM TYPE | Connected modem type. |
| TX ENABLE | On or off, information delivered by the connected VSAT modem. |

Table 6-12: MODEM menu of the ACU

| MODEM menu | Description |
|--------------|--|
| RX LOCK | On or off, information delivered by the connected VSAT modem. |
| SIGNAL LEVEL | Current input signal level from VSAT modem. iDirect openAMIP modem: (PWR) 0-500, delivered by the connected modem. For values <250 the antenna searches after a new signal. Other modem: Signal level in dB. |

Table 6-12: MODEM menu of the ACU (Continued)

| NETWORK menu | Description |
|-----------------|---|
| MANAGEMENT IP | Current IP address of the SAILOR 900 VSAT web interface (default: 192.168.0.1). |
| MANAGEMENT MASK | Current netmask of the SAILOR 900 VSAT web interface (default: 255.255.255.0). |

Table 6-13: NETWORK menu of the ACU

| SATELLITE menu | Description |
|-----------------|--|
| POSITION | Position of the active satellite |
| RX POLARIZATION | Horizontal or vertical (current satellite) |
| TX POLARIZATION | X-polarisation or Co-polarisation, auto-selected by VSAT modem |
| RX FREQUENCY | Ku band receiving frequency of the active satellite, auto-selected by VSAT modem |
| LNB LO | Auto selected by VSAT modem |
| TX FREQUENCY | Transmission frequency, auto-selected by VSAT modem |
| BUC LO | 12.8 GHz, system parameter |

Table 6-14: SATELLITE menu of the ACU

| EVENT menu | Description |
|------------|--|
| <EVENT> | <p>In this menu all active events are listed. Use ▼ and ▲ to go through the active events.</p> <p>Events can be of the type WARNING or ERROR. For a list of events see <i>Event messages – overview</i> on page F-1.</p> <p>If a new event occurs or there is a change in the event list while you are in the EVENTS menu, a * is shown in the upper left corner of the display, next to the menu name. Press OK to update the EVENTS list, the * will be removed.</p> <p>A > means the event text is longer than the display. Press to > to see the remaining text.</p> |

Table 6-15: EVENTS menu of the ACU

Example: **EVENT 1/4***: This is the first event out of a list of 4 and there has been a change in the list. EVENT 1/4 will always be shown, the * indicates that there has been a change.

6.4.4 Adjusting brightness of the display

To adjust the brightness do the following:

1. Press and hold **OK** for a short moment until BRIGHTNESS XXX% is displayed (XXX is the current brightness value).
2. Hold OK pressed + press ▲ for lighter or ▼ for darker display.
3. Release OK to leave the brightness menu.

6.4.5 Resetting the system

To reset the system do the following:

1. Press and hold ▲ and ▼ until the ACU display shuts down and the ACU reboots.



Figure 6-29: Reset the system

2. Wait until the system has rebooted and is operational again. The last active satellite profile will be selected.

Installation check

Now that you have installed the system, you can test the system to verify it is ready for customer delivery. Follow the check lists below to test the system for proper operation.

- *Installation check list: Antenna*
- *Installation check list: ACU, connectors and wiring*
- *Installation check list: Functional test in harbor*

7.1 Installation check list: Antenna

| Step | Task | Further information | Done |
|------|---|--|------|
| 1. | Check that the antenna is free of obstructions. | See <i>Obstructions (ADU shadowing)</i> on page 3-3. | |
| 2. | Make sure there is sufficient space for access through the service hatch. | See <i>Installing the ADU</i> on page 3-19. | |
| 3. | Make sure to maintain the vertical orientation of the ADU center line. | | |
| 4. | Check that the ADU is installed where vibrations are limited to a minimum. | | |
| 5. | Check that you programmed the blocking zones correctly. | See <i>Blocking zones – azimuth and elevation</i> on page 3-5 and <i>Setting up Blocking zones (RX and TX)</i> on page 6-20 | |
| 6. | Make sure that the safety distance for radiation hazard of 30 metres is kept. | See <i>Safe access to the ADU: Radiation hazard</i> on page 3-6 | |

Table 7-1: Installation check list: Antenna

| Step | Task | Further information | Done |
|------|--|--|------|
| 7. | Check that the mounting height of the antenna is in accordance with the ship's min. roll period. | See <i>Ship motion and offset from the ship's motion centre</i> on page 3-7. | |
| 8. | Make sure that the requirements for mast foundation and height, including flatness, gusset plates and distance from welding seams are met. | See <i>ADU mast design: Foundation and height</i> on page 3-8. | |
| 9. | Make sure that the distances to radar, Inmarsat systems, GPS receivers and other transmitters are as required. | See <i>Interference</i> on page 3-13. | |
| 10. | Make sure that the drain tube is open and risk for water intrusion is at a minimum. | See <i>Other precautions</i> on page 3-17. | |
| 11. | Check that the ADU is grounded correctly, using the mounting bolts. | See <i>Grounding the ADU</i> on page 3-23 and <i>Grounding and RF protection</i> on page E-1. | |

Table 7-1: Installation check list: Antenna (Continued)

7.2 Installation check list: ACU, connectors and wiring

| Step | Task | Further information | Done |
|------|--|---|------|
| 1. | Check that the ACU is grounded correctly, using the mounting bolts and washers. | See <i>Grounding the ACU (bulkhead)</i> on page 3-25 or <i>Grounding the 19" rack version of the ACU</i> on page 3-28 and <i>Grounding and RF protection</i> on page E-1. | |
| 2. | Make sure you strain relieved the cables. | See <i>Installation of the ACU (bulkhead)</i> on page 3-24 or <i>Installing the 19" rack version of the ACU</i> on page 3-27. | |
| 3. | Make sure that the VSAT modem is mounted close to the ACU. | See <i>General mounting considerations – VMU</i> on page 3-29. | |
| 4. | Check that the ADU antenna N-connector is properly connected with the 50 ohm RF cable. | Visual inspection of the cover plate at the bottom of the ADU. | |
| 5. | Check that the ACU antenna N-connector is properly connected with the 50 ohm RF cable. | Visual inspection of the connector panel of the ACU. | |
| 6. | Check that the ACU's Rx Out is connected to the VSAT modem's Rx in using the included 1 m F-F 75 ohm cable. | Visual inspection of the connector panel of the ACU and the VSAT modem. | |
| 7. | Check that the ACU's Tx In is connected to the VSAT modem's Tx out using the included 1 m F-F 75 ohm cable. | Visual inspection of the connector panel of the ACU and the VSAT modem. | |

Table 7-2: Installation check list: ACU, connectors and wiring

| Step | Task | Further information | Done |
|------|--|--|------|
| 8. | <p>Check connection of the VSAT modem:</p> <p>COMTECH only: Check that the ACU RS-232 port is connected to the Remote Control port of the VMU using the included serial cable.</p> <p>iDirect iNFINITI 5000 Series/ Evolution X5 only: Check that the ACU RS-232 port is connected to the Console port of the VMU using the included serial cable.</p> <p>iDirect iNFINITY 5000 Series only: Check that the ACU LAN port 1 is connected to the LAN B of the VMU using the included CAT5 Ethernet cable.</p> <p>iDirect Evolution X5 only: Check that the ACU LAN port 1 is connected to the LAN of the VMU using the included CAT5 Ethernet cable.</p> | Visual inspection of the connector panel of the ACU and the VSAT modem. | |
| 9. | Check that the ADU's NMEA 0183 connector is connected to the NMEA 0183 bus of the vessel using the included multi-connector | Visual inspection of the connector panel of the ACU connector. | |
| 10. | Measure that the power has the correct polarity in the power connector, before connecting it to the ACU power input. | Use a volt meter. See Table 4-1: <i>DC Input plug, outline and pin assignment</i> on page 4-3. | |

Table 7-2: Installation check list: ACU, connectors and wiring (Continued)

7.3 Installation check list: Functional test in harbor

| Step | Task | Further information | Done |
|------|---|--|------|
| 1 | Check that the antenna is locked to the satellite | The logon LED in the ACU display must be steady green and the display shows: TRACKING . In the web interface check: DASHBOARD: System status: Tracking | |
| 2 | Check that the VMU is in lock and ready for Tx. | In the web interface check: DASHBOARD > VSAT MODEM > Signal level and RX frequency show values. | |
| 3 | Connect a user PC LAN (not the service PC) to the Internet LAN connector, either on the LAN port 2 of the ACU (only X5 VSAT modem) or to the User LAN connector on the VMU. | Check the VSAT modem documentation for details. | |
| 4 | Open a DOS window and type: ping 4.2.2.2. | Check that you get a response. | |
| 5 | Open a web browser and browse to www.google.com. | Check that the web page is downloaded. | |
| 6 | If step 4 is successful and step 5 is not then it seems like the DNS is not configured correctly. | Check with the VSAT modem documentation how the DNS server must be set up, "Obtain DNS server address automatically" or enter specific DNS server addresses. | |

Table 7-3: Installation check list: Functional test in harbor

Daily use – Quick guide

QUICK GUIDE

SAILOR 900 VSAT

Introduction

The SAILOR 900 VSAT system has been configured during installation with all needed satellite and modem profiles. After startup it uses the last selected satellite profile.

To change to another satellite (or modem profile), or change an antenna parameter, connect a PC to the Antenna Control Unit (ACU) and enter the built-in web interface.


Setup and configuration

Set up your PC network connection to use a static IP address:

- IP address: 192.168.0.2
- Subnet mask: 255.255.255.0
- Gateway: 192.168.0.1


Switch on the SAILOR 900 VSAT at the power switch of the ACU.

Connect a PC to LAN port 3 (Rack version: Front LAN connector) of the ACU, use a straight Ethernet cable.



Enter the address **http://192.168.0.1** (default) in your Internet browser. The built-in web interface opens directly with the **DASHBOARD**.

Click **SETTINGS** and activate the new satellite profile.



For detailed information about the SAILOR 900 VSAT system see the **SAILOR 900 VSAT Installation & user manual**.

Thrane & Thrane

Figure 8-1: SAILOR 900 VSAT Quick Guide – web interface and satellite profiles

SAILOR 900 VSAT

Viewing system parameters

Introduction

Use the arrow keys of the Antenna Control Unit (ACU) for navigation. See the menu tree for an overview of the parameters available.



Navigation

Switch on the SAILOR 900 VSAT at the power switch of the ACU.

Use the arrow keys on the keypad to go to a menu.

Press **OK**, then the arrow keys on the keypad to select a parameter.


The current menu name is shown in the upper left corner of the display.

For changing a parameter in the SAILOR 900 VSAT use the built-in web interface of the ACU. See overleaf for a short introduction.

Resetting the ACU

Press and hold the arrow up and down keys until the ACU display shuts down and the ACU reboots.

Wait until the system has rebooted and is operational again. The last active satellite profile will be selected.



For more detailed information about the SAILOR 900 VSAT system see the **SAILOR 900 VSAT Installation & user manual**.

98-133401-B

thrane.com

Thrane & Thrane

Figure 8-2: SAILOR 900 VSAT Quick Guide – Viewing system parameters

Service

In this chapter you find the following sections:

- *Getting support: Helpdesk*
- *Software update*
- *Status signalling with LEDs and status messages*
- *Removal and replacement of the ACU*
- *Removal and replacement of ADU modules*
- *Initial troubleshooting*

9.1 Getting support: Helpdesk

If this manual does not provide the remedies to solve your problem, contact your Airtime Provider.

9.1.1 Help desk and diagnostic report

Support at the Help desk

During the installation you must enter the support contact for this installation.

To access the Help desk, select **HELP DESK** from the left navigation pane.



Figure 9-1: Web interface: HELPDESK

Click the link, enter support contact information and click **Apply**.




Figure 9-2: Web interface: HELPDESK, enter support contact

Clicking the link Legal notice provides licence text for the source code of the parts of SAILOR 900 VSAT software that falls under free and open source software.

If you need help **with ACU or ADU related issues** call your service provider.

Generating a diagnostic report

You can generate a diagnostic reports. The diagnostic report contains information relevant for the service personnel during troubleshooting.

To generate a diagnostic report click **Generate report**, then you can save it on your computer.

You can also configure the system to send diagnostic reports at defined time intervals. For further details on this see *Sending a diagnostic report* on page 6-29.

Event list

Use the event list when troubleshooting the installation, for further details see *Viewing the Event list* on page 9-15 and *System messages* on page F-1. Only active events are shown in the list. Once an event is cleared, it is not displayed any longer.

Self test

You can start a self test of the SAILOR 900 VSAT ADU and ACU.

1. Click **Self test** in the **HELP DESK** page.
2. Click the menu item **Self test**.

Important

Warning! The SAILOR 900 VSAT will reboot to perform the self test. Rebooting the ACU will terminate all existing connections.

9.2 Software update

Hardware and software requirements

The following items are required before the software can be updated:

- One computer with a standard Ethernet port available.
- A standard Internet browser.
- 1024×768 pixels or higher display resolution. The program is best viewed using small fonts.
- One straight LAN cable.
- The file containing the new software.

9.2.1 Software update (ADU and ACU)

Note Software update should only be done by qualified service personnel.

1. Power up the SAILOR 900 VSAT system, i.e. switch on the ACU. Wait until the LEDs on the front plate of the ACU show that the system is ready to be configured.
 - Power LED: Green
 - Logon LED: Off
 - Fail/Pass LED: Flashing green, during power-on self test, after that steady green.
2. Set up your PC network connection to use a static IP address:
 - IP: 192.168.0.2
 - Subnet mask: 255.255.255.0
 - Gateway: 192.168.0.1

For more detailed instructions and proxy server settings see *Overview and navigation* on page 6-8.

3. Connect a PC to LAN interface 3 (Service port, standard Ethernet) of the ACU. For the rack version connect the LAN cable to the front LAN connector of the ACU.




Figure 9-3: LAN connector used for configuring the SAILOR 900 VSAT

4. Open your Internet browser and enter the IP address of the ACU. The IP address is **http://192.168.0.1** (default).

5. The web interface opens directly with the **DASHBOARD** page.
6. Click **SERVICE** from the left navigation pane. The **Upload** page is displayed.




Figure 9-4: Web interface: SERVICE, Upload

7. The **Current software version** field shows the current software version.
8. In the section **UPLOAD SOFTWARE TO TERMINAL** Click **Browse...** and locate the new software file.
9. Click **Upload**.
Note that the upload procedure takes a couple of minutes. When done, the ACU automatically restarts with the new software version.
The start-up procedure after a software upload takes longer than the usual start-up time, as the software in the ADU must also be updated. The ACU display shows: **ADU SW UPLOAD**.

If software upload fails - how to recover

To recover from a failed software upload, turn off the ACU and turn it on again. Then repeat the upload procedure as described in *Software update* on page 9-4.

9.2.2 Verifying the software update

Testing procedure

1. The software version can be viewed in the **DASHBOARD** window of the web interface.
2. After completing the software update procedure, the ACU will perform a POST (Power On Self Test).

- When the POST has finished, the green Pass/Fail LED on the front of the ACU must become steadily green. Verify that the Pass/Fail LED is not red nor flashing orange once every 2 seconds. Wait until the Pass/Fail LED is green.
- Verify that the software update has been completed successfully. You find the software version number in the **DASHBOARD** window of the web interface.

The screenshot shows the Thrane & Thrane web interface. At the top, there's a header with the company name. Below it, a 'SIGNAL:' indicator shows a full bar graph. A left sidebar contains navigation links: DASHBOARD, SETTINGS, SERVICE, ADMINISTRATION, HELPDESK, and SITE MAP. The main content area is divided into sections. The 'SAILOR 900 VSAT' section displays various system parameters in a table. The 'VSAT MODEM' section shows modem details. The 'POINTING' section shows antenna orientation data. A red circle highlights the 'Software version' field, which displays '1.10'.

| SAILOR 900 VSAT | | | |
|-----------------------|--------------------|-------------------|----------|
| System status | Tracking | ACU part name | TT-7016A |
| GPS position | 55°48' N, 12°31' E | ADU part name | TT-7009A |
| Vessel heading | 5° | ACU serial number | ACU_4 |
| Satellite profile | ROSS (auto) | ADU serial number | 80539020 |
| Satellite position | 40°E | Software version | 1.10 |
| RX polarisation | Horizontal | | |
| TX polarisation | X-pol | | |
| RX RF frequency | 11.120847GHz | | |
| LNB LO frequency | 9.750000GHz | | |
| TX RF frequency | 14.417282GHz | | |
| BUC LO frequency | 12.800000GHz | | |
| Tracking RF frequency | 11.120847GHz | | |

| VSAT MODEM | |
|-----------------|---------------------------|
| Model | ComTech CDM 570L and ROSS |
| Signal level | 14dB |
| RX IF frequency | 1370.847000MHz |
| TX IF frequency | 1617.282000MHz |

| POINTING | |
|--------------------|--------|
| Azimuth relative | 143.6° |
| Elevation relative | 20.4° |
| Polarisation skew | -17.6° |

Figure 9-5: Verifying software update

9.3 Status signalling with LEDs and status messages

Built-In Test Equipment

The ADU and the ACU have a Built-In Test Equipment (BITE) function in order to make fault diagnostics easy during service and installation.

The BITE test is performed during:

- Power On Self Test (POST), which is automatically performed each time the system is powered on.
- Person Activated Self Test (PAST), which is initiated by starting a self test in the web interface **HELPDESK > Self test**.

Details on error messages after a POST or a self test can be found in the event list of the ACU, see *Viewing the Event list* on page 9-15.

Means of signalling

The SAILOR 900 VSAT system provides various methods for signalling the status of the system.

- **LEDs** on the front panel of the ACU are used to signal:
 - Power on/off
 - Logon
 - Fail/Pass
- The built-in web interface of the ACU shows any events (BITE error codes) with a short message describing each error. This is also displayed in the ACU.

In case of an error situation, one of the following system status messages may be shown:

- ACU POST error
- ADU POST error
- SAFE MODE (plus information about the specific error, see *System messages* on page F-1).

9.3.1 LEDs of the ADU modules

Each ADU module has a Power and a Service LED.

| LED | Behavior | Description |
|---------|--------------------|---------------------------------|
| Power | Steady green | Power supply OK |
| | Off | No power |
| Service | Steady green | Module ok, application running. |
| | Flashing green | Waiting for upload |
| | Flashing red/green | Uploading application |
| | Steady red | Module error or loading error |

Table 9-1: LEDs of the ADU modules

For a list of modules see *Removal and replacement of ADU modules* on page 9-12.

9.3.2 LEDs in the ACU

The ACU has 3 LEDs: Power, Logon and Fail/Pass LED.



LEDs

Figure 9-6: LEDs on the ACU



LEDs

Figure 9-7: LEDs on the ACU, 19" rack version

| LED | Behavior | Description |
|-------|----------------|---|
| Power | Steady green | Power supply OK |
| | Steady red | Power supply failure |
| | Off | No power |
| Logon | Flashing green | Current status is displayed: <ul style="list-style-type: none">Searching satelliteIdentifying satelliteCarrier lock & TX enabled from modem |
| | Steady green | Satellite link established |
| | Off | No satellite link acquired |

Table 9-2: LEDs on the ACU

| LED | Behavior | Description |
|---------------|----------------|---|
| Fail/Pass LED | Steady red | A fault which prevents operation is present in the system (ACU, ADU, MODEM). |
| | Flashing green | A Power On Self Test (POST) or Person Activated Test (PAST) in progress. The current status is displayed. |
| | Flashing red | Active BITE failure or warning. The event is shown in the ACU display. |
| | Steady green | No faults. |

Table 9-2: LEDs on the ACU (Continued)

9.4 Removal and replacement of the ACU

There are no parts in the ACU that you can remove or replace. If the ACU malfunctions, remove it from the wall, desk or rack and contact your Thrane & Thrane service partner for further repair or replacement.



Figure 9-8: Removal and replacement of the ACU bulkhead



Figure 9-9: Removal and replacement of the ACU 19" rack

9.5 Removal and replacement of ADU modules

For replacement of a module contact your Thrane & Thrane service partner. The figure below shows the modules and their position. Some modules are equipped with LEDs for status information and troubleshooting.

For instructions how to open and remove the service hatch see *Opening and removing the service hatch* on page 3-22.




Figure 9-10: ADU modules and motor stop switch

1. GPS module.
2. VSAT Interface Module (VIM).
3. DC-Motor Driver Module for cross elevation (DDM).
4. Cross elevation motor and encoder.

5. Zero Reference Module (x4) (ZRM). (not visible on photo)
6. DC-Motor Driver Module for elevation (on the side) (DDM).
7. Elevation motor and encoder. (not visible on photo)
8. Polarisation Motor Module (PMM). (not visible on photo)
9. Polarisation motor and encoder. (not visible on photo)
10. Block Up Converter (BUC). (behind cable screen, not visible on photo)
11. Low Noise Block downconverter (x2) (LNB). (not visible on photo)
12. Ortho Mode Transducer (OMT). (not visible on photo)
13. Inertial Sensor Module (ISM).
14. Pedestal Control Module (PCM).
15. Service switch.

In switch-off position the DC Motor Driver modules and the BUC are turned off for safe conditions during service and repair. The switch must be in on position for normal ADU operation.




Figure 9-11: Above Deck Unit modules (continued)

- 16. DC-Motor Driver Module for Azimuth (DDM).
- 17. Azimuth motor and encoder. (not visible on photo)
- 18. Rotary joint. (not visible on photo)
- 19. Feed horn.

Before contacting your service partner check the LEDs on each module. See *LEDs of the ADU modules* on page 9-8 and *LEDs in the ACU* on page 9-9.

9.6 Initial troubleshooting

Overview

This section describes an initial check of the primary functions of the SAILOR 900 VSAT system, and provides some guidelines for troubleshooting, if one of the checks should fail.

Generally, if a fault occurs without any obvious reason, it is always recommended to observe the LEDs and the ACU display showing the active events.


For information on the function of the LEDs, see *Status signalling with LEDs and status messages* on page 9-7.

For a list of all the error messages and warnings, see *Event messages – overview* on page F-1.

Possible failure states are shown in the web interface and the display of the ACU:

- SAFE MODE (error in unit)
- ADU POST error (hardware error)
- ACU POST error (hardware error)

9.6.1 Viewing the Event list

When an event is registered, the web interface shows an event icon  in the icon bar as long as the event is active. The ACU display shows also active events.

The **Event list** in the web interface shows a list of events that are currently active.

Event list

To view the event list, click the event icon from the icon bar at the top of the web interface, or select **HELPDESK > Event list** from the left navigation pane.

The **Event list** page shows a detailed list of active events and notifications including the time of the first occurrence, ID and severity of the event message, and a short text describing the error. Active events are cleared when the error is cleared. Notifications are cleared automatically after 24 hours and after restart of the system.

For a list of events with description, error code (ID), explanation and remedy see *List of events with explanation and remedy* on page C-1.

You cannot download the event list, but you can generate a diagnostic report containing results from the POST, all events and system log information since the last reset to factory default. For more information see *Sending a diagnostic report* on page 6-29.

Appendices

Technical specifications

A.1 SAILOR 900 VSAT system components

A.1.1 General specifications

| Item | Specification |
|--------------------------------|---|
| Frequency band | Ku-band (VSAT) |
| Rx | 10.70 to 12.75 GHz |
| Tx | 13.75 to 14.50 GHz (extended) |
| Reflector size | 103 cm (40 inch) |
| Certification (approval) | Compliant with CE (Maritime), ETSI EN 302 340, CEI/IEC 60950-1, CEI/IEC 60945, CEI/IEC 60950-22 |
| ADU cable type (ACU to ADU) | Single 50 Ohm coax cable for Rx, Tx, ACU-ADU modem and power |
| ADU cable connector at the ADU | Female N-Connector (50 Ohm) |
| ADU cable connector at the ACU | Female N-Connector (50 Ohm) |
| System power supply range | 20–32 VDC (Start up voltage: 22 VDC guaranteed) |
| Total system power consumption | 370 W peak, 175 W typical (up to 8 W BUC) |

Table A-1: General specifications

A.1.2 ADU

| Item | Specification |
|-------------------------------------|---|
| Dimensions (overall) | Diameter x Height: Ø 130 cm (51.3 inch) x H 150 cm (58.9 inch) |
| Weight | 135 kg (288 lbs) |
| Antenna type, pedestal | 3-axis (plus skew) stabilised tracking ADU with integrated GPS |
| Antenna type, reflector system | Reflector/sub-reflector, ring focus |
| Transmit Gain | 41.4 dBi typ. @ 14.25 GHz (excluding radome) |
| Receive Gain | 40.1 dBi typ. @ 11.70 GHz (excluding radome) |
| System G/T | 17.9 dB/K typ. @ 11.70 GHz, at $\geq 30^\circ$ elevation and clear sky (including radome) |
| BUC output power | 8 W |
| EIRP | ≥ 49 dBW (including radome) |
| LNB | 2 units 4-band LNBs (band selection by ACU) |
| Tracking Receiver | Internal "all band/modulation type" and VSAT modem RSSI |
| Polarisation | Linear Cross or Co-Pol (selected by ACU) |
| Elevation Range | -25° to $+125^\circ$ |
| Azimuth Range | Unlimited (Rotary Joint) |
| Ship motion, angular | Roll $\pm 30^\circ$, Pitch $\pm 15^\circ$, Yaw $\pm 10^\circ$ |
| Ship, turning rate and acceleration | $15^\circ/\text{s}$ and $15^\circ/\text{s}^2$ |
| ADU motion, linear | Linear accelerations ± 2.5 g max any direction |

Table A-2: Technical specifications for the Above Deck Unit

| Item | Specification |
|--------------------------|---|
| Satellite acquisition | Automatic - w. Gyro/GPS compass input |
| Vibration, operational | Sine: IEC 945 (8.7.2), DNV A, MIL-STD-167-1 (5.1.3.3.5). Random: Maritime |
| Vibration, survival | Sine: IEC 945 (8.7.2) dwell, MIL-STD-167-1 (5.1.3.3.5) dwell. Random: Maritime survival |
| Shock | MIL-STD-810F 516.5 (Proc. II) |
| Temperature (ambient) | Operational: -25° C to 55° C Storage: -40°C to 85°C |
| Humidity | 100%, condensing |
| Rain (IP class) | IEC 945 Exposed (IPX6) |
| Wind resistance | Operational: 80 kt. Survial: 110 kt. |
| Ice | Survival: 25 mm (1 inch) |
| Solar radiation | 1120 W/m2 to MIL-STD-810F 505.4 |
| Compass safe distance | 1 m to IEC 945 |
| Maintenance, scheduled | None ($T_{amb} > 10^{\circ}\text{C}$) |
| Maintenance, unscheduled | All electronic, electromechanical modules and belts can be replaced through the service hatch. |
| Built-in tests | Power On Self Test (POST) Person Activated Self Test (PAST) Continuous Monitoring (CM) with error log |
| Power OFF | Automatic safe mode |

Table A-2: Technical specifications for the Above Deck Unit (Continued)

A.1.3 ACU

| Item | Specification |
|----------------------------|--|
| Dimensions, rack mount | 1 U, 19 inch |
| H x W x D | 4.4 x 48 x 33 cm (1.75 x 19 x 13 inch) |
| Dimensions, bulkhead mount | stand-alone unit |
| H x W x D | 4.3 x 25.5 x 27.8 cm (1.67 x 10.0 x 10.9 inch) |
| Weight, rack mount | 4.5 kg (10 lbs) |
| Weight, bulkhead mount | 2.7 kg (6 lbs) |
| Ambient temperature | Operational: -25°C to +55°C Storage: -40°C to +85°C |
| Humidity | IEC 945 protected, 95% (non-condensing) |
| IP class | IP31 |
| Compass safe distance | 1 m to IEC 945 |
| Interfaces | 1 x N-Connector for antenna RF Cable (50 Ohm) w. automatic cable loss compensation 2 x F-Connectors (75 Ohm) for Rx/Tx to VSAT modem 1 x Ethernet data (VSAT Modem Control) 1 x RS-422 data (VSAT Modem Control) 1 x RS-232 data (VSAT Modem Control) 1 x NMEA 2000 (CAN bus) and NMEA 0183 (RS-422) for Gyro/GPS compass input 2 x Ethernet (user) 1 x Ethernet (service, set-up etc.) 1 x DC power input 1 x Grounding bolt |
| Input power | See <i>System power supply range</i> and <i>Total system power consumption</i> on page A-1. |

Table A-3: Technical specifications for the ACU

| Item | Specification |
|-----------------------------|--|
| Modem interface (control) | iDirect openAMIP protocol & custom protocol |
| Man Machine Interface (MMI) | OLED (red) display, 5 push buttons, 3 discrete indicator LEDs and ON/OFF switch |
| No transmit zones | Programmable |

Table A-3: Technical specifications for the ACU (Continued)

A.1.4 Supported VSAT modems

| Item | Specification |
|------------------|---|
| Modems supported | For a list of supported VSAT modems see the SAILOR 900 VSAT data sheet. |

Table A-4: Supported VSAT modems

A.2.2 ACU, bulkhead




Figure A-2: Outline drawing: ACU, bulkhead

VMU cable specifications

This appendix contains cable specifications for cables between the ACU and a VSAT modem.

- *Modem Cable Comtech Serial & RSSI TT7016A*
- *Modem Cable iNIFINITI iDirect VSAT modem*

B.1 Modem Cable Comtech Serial & RSSI TT7016A




Figure B-1: Modem Cable Comtech Serial & RSSI TT7016A

Figure B-2: Modem Cable iNFINITI iDirect VSAT modem



VMU settings requirements

In this appendix you find detailed information how to set up supported VSAT modems. The following VSAT modems are described:

- *Open AMIP setup for iDirect INFINITI 5000 & Evolution X5*
- *Non-Open-AMIP setup for iDirect iNFINITI 5000 & Evolution X5*
- *Setup of Comtech 570L, ROSS box & ACU*

C.1 Open AMIP setup for iDirect INFINITI 5000 & Evolution X5

C.1.1 Protocol and interfaces

Introduction

The following sections describe the protocol and interface between the SAILOR 900 VSAT ACU and an iDirect OpenAMIP VSAT modem. OpenAMIP operation is normally used by service providers offering global VSAT service as the protocol supports roaming between satellites.

OpenAMIP, an ASCII message based protocol invented and Trademarked by iDirect is a specification for the interchange of information between an antenna controller (ACU) and a VSAT modem (VMU). This protocol allows the VSAT modem to command the ACU to seek a particular satellite as well as allowing exchange of information necessary to permit the VSAT modem to initiate and maintain communication via the antenna and the satellite. In general, OpenAMIP is not intended for any purpose except to permit a modem and the ACU to perform synchronized automatic beam switching.

Thrane & Thrane A/S received OpenAMIP certification for SAILOR 900 VSAT from VT iDirect Inc on 22 September 2011.

Connections

Connect the ACU and iDirect modem with the following cables:

- Ethernet cable for TCP/IP data communication
- RS-232 console cable for signal strength indication
- 75 RF cables F-F connectors for rx and tx frequencies.

See *Connecting an iNFINITI® 5000 Series Satellite Router* on page 4-9 and *Connecting an Evolution® X5 Satellite Router* on page 4-10 for details on cable connections and pin allocation for the RS-232 Console cable.




Figure C-1: Connecting iDirect iNFINITI 5000 series to the ACU (OpenAMIP)




Figure C-2: Connecting iDirect Evolution X5 to the ACU (OpenAMIP)

Protocol

The SAILOR 900 VSAT ACU supports all OpenAMIP commands except the X command which is optional. All the supported OpenAMIP commands are shown in the following figure.

| Messages Sent from Remote | | | Messages Sent from Antenna | | |
|---------------------------|---------|--------------|--|--------------------|----------------------|
| iDS/iDX Release | Message | # Parameters | Mapped to Options File Keys | Options File Group | Message # Parameters |
| iDX 2.0.x | A | | keepalive_interval Default value of 15 seconds. Will not appear in Options file unless overwritten. | [ANTENNA] | a |
| | B | 2 | rx_lcl_osc, tx_lcl_osc | [SATELLITE] | |
| | H | 2 | hunt_frequency, hunt_bandwidth | [SATELLITE] | |
| | K | 1 | max_skew Maximum skew of the beam short axis to the geosynchronous arc. | [SATELLITE] | |
| | P | 2 | polarity, tx_polarity | [SATELLITE] | |
| | S | 3 | longitude, max_lat, pol_skew | [SATELLITE] | s 2 |
| | T | 2 | tx_frequency, tx_bandwidth | [SATELLITE] | |
| | W | 1 | latlong_interval Message contains single value in seconds. Does not generate Options file key. | [MOBILE] | w 4 |

Figure C-3: Supported OpenAMIP commands

| Messages sent from VSAT modem | Explanation |
|--------------------------------|--|
| S -15.000000 0.000000 0.000000 | Longitude, Max_lat, Pol_skew |
| H 1451.815000 1.905000 | Hunt_frequency, Hunt_bandwidth |
| P H V | Rx_polarity, Tx_polarity |
| B 11250.000000 12800.00000 | Rx-lcl_osc, Tx_lcl_osc |
| T 1403.290000 0.618000 | Tx_frequency, Tx_bandwidth |
| A 15 | Keepalive_interval in mS [ACU: s message] |
| W 300 | latlong_interval in seconds [ACU: w message] |
| L 11 | Modem locked |
| K 90.000000 | Max_skew |

Table C-1: Messages sent from the VSAT modem to the ACU (examples)

| Messages sent from the ACU to the VSAT modem | Explanation |
|--|--------------------------------------|
| s 11 | Functional, Tx OK |
| w 1 55.794010 12.52272 985523005 | GPS valid, Latitude, Longitude, Time |

Table C-2: Messages sent from the ACU to the VSAT modem (examples)

Note

The iDirect modems only send the satellite information once when booting. If the ACU has not received the information for some reason, the system cannot point. In that case the modem will automatically boot after 5 minutes and send the satellite information again.

The signal strength from the modem is measured on RS-232 pin 9. It is a DC voltage in the range of 0 - 5 VDC.

| Ranges for signal strength | |
|----------------------------|--|
| VDC | Antenna status |
| 0-2.5 | RF energy is detected, but from the wrong satellite. |
| 2.6-5.0 | Carrier lock, correct satellite. |

Table C-3: Ranges for signal strength for iDirect Open AMIP VSAT modem

The signal strength displayed web interface on the Dashboard as 0 - 500. The minimum value for an Internet connection is 250 - 260.

C.1.2 Sample options file

The following section presents a portion of a sample iDX 2.0.x Options file with OpenAMIP messages and parameters defined. OpenAMIP keys appear highlighted in bold.

```
[OPTIONS_FILE]
product_mode = idirect_scpc
modem_sn = 40170
generated_by = NMS-10.0.0
did = 12885226
modem_type = Remote
```

```
modem_hardware = 5000
is_mesh = 0
disable_options_flash_command = 0
carrier_type = 0
...
[MOBILE]
is_mobile = 1
tx_handshake_enabled = 0
gps_input = 2
latlong_interval = 300
latlong_fail_interval = 10
init_tx_power_offset = 0.000000
[MAPSERVER_0]
hostname = 172.20.130.3
port = 5003
[BEAMS]
beam_21 = PPS_Perf_Eval
maxbeam = 21
[ANTENNA]
manufacturer = OpenAMIP
model = OpenAMIP
addr = 172.26.81.34
port = 2000
connect_timeout = 30
dedicated_interface = ixp1
[SATELLITE]
min_look_angle = 0.000000
tx_frequency = 1200.000000
tx_bandwidth = 36.000000
hunt_bandwidth = 36.000000
rx_lcl_osc = 11250.000000
tx_lcl_osc = 12800.000000
```

```
max_skew = 90.000000  
name = T12  
channelname = T12_EMEA  
longitude = -15.000000  
max_lat = 0.000000  
pol_skew = 0.000000  
hunt_frequency = 1075.000000  
polarity = H  
tx_polarity = X  
noise_reference_frequency = 0.000000
```

The option file must use following information:

| Section in the option file | Requirements |
|----------------------------|--|
| [SATELLITE] | <p>The modem must use the following up and down conversion frequencies for rx and tx! SAILOR 900 VSAT has O-Type LNBS (Co-Pol & X-Pol) with following Local Oscillator (LO) down conversion frequencies:</p> <ul style="list-style-type: none"> – 9.75 GHz – 10.25 GHz – 10.75 GHz – 11.25 GHz <p>Example: “rx_lcl_osc = 11250.000000”</p> <p>SAILOR 900 has an extended 8 Watt BUC with LO up conversion frequency of 12.8 GHz.</p> <p>– Example: “tx_lcl_osc = 12800.000000”</p> |
| [MOBILE] | <p>The iDirect modem must be set to mobile unit and receive the GPS information from the ACU with the command “w <Valid> <Lat> <Lon> <Time>”.</p> <p>Example: “is_mobile = 1”</p> <p>Tx handshake must not be enabled in the iDirect modem.</p> <p>Example: “tx_handshake_enabled = 0”</p> |
| [ODU] | <p>The SAILOR 900 VSAT can work either using the Rx 10 MHz reference signal provided by the modem or using its own built-in 10 MHz reference signal. It is recommended to use the 10 MHz reference signal from the modem.</p> <p>Example: “odu_rx_10_mhz = 1”</p> <p>The SAILOR 900 VSAT needs the Tx 10 MHz reference signal in order to allow TX ON.</p> <p>Example: “odu_tx_10_mhz = 1”</p> |

Table C-4: Information in the VSAT modem option file

C.1.3 Configuration examples (OpenAMIP)

Examples of modem profile and satellite configuration from the ACU web MMI are shown in the figures below.

EDIT VSAT MODEM PROFILE

Profile name: 5000 iDirect OpenAMIP

VSAT modem: iDirect INFINITI 5000 Series (OpenAMIP)

This modem profile is used on: 1 satellite profile

VSAT modem root password:

VSAT modem user password:

OpenAMIP IP address: 10.224.10.82

OpenAMIP port: 2000

Apply Cancel

Figure C-4: VSAT modem profile, OpenAMIP (example)

EDIT SATELLITE PROFILE

Satellite profile name: HM-OpenAMIP

VSAT modem profile: 5000 iDirect OpenAMIP

Apply Cancel

Tracking

RX frequency: ☒ VSAT modem ☐ User defined

0 GHz

☐ DVB-S / DVB-S2

Symbol rate: 0 MS/s

NID: 0

☐ DVB power

☒ Narrow band

☐ VSAT modem RSSI

Apply Cancel

Figure C-5: Satellite profile, OpenAMIP (example)

C.2 Non-Open-AMIP setup for iDirect iNFINITI 5000 & Evolution X5

C.2.1 Protocol and interfaces

Introduction

The following sections describe the protocol and interface between the ACU and an iDirect Non-OpenAMIP modem. Non-OpenAMIP operation is normally used by service providers offering regional VSAT service.

Connections

Connect the ACU and iDirect modem with the following cables:

- RS-232 console cable for control communication
- 75 RF cables F-F connectors for rx and tx frequencies.

See *Connecting an iNFINITI® 5000 Series Satellite Router* on page 4-9 and *Connecting an Evolution® X5 Satellite Router* on page 4-10 for details on cable connections.




Figure C-6: Connecting iDirect iNFINITI 5000 series to the ACU (Non-OpenAMIP)




Figure C-7: Connecting iDirect Evolution X5 to the ACU (Non-OpenAMIP)

The pin allocation for the RS-232 Console cable is shown below.

| Console Port(DTE) | RJ-45 Pin | Color Code | RJ-45 to DB-9 Adapter Pin | Console Device |
|-------------------|-----------|------------|---------------------------|----------------|
| RTS | 1 | Blue | 8 | CTS |
| DTR | 2 | Orange | 6 | DSR |
| TxD | 3 | Black | 2 | RxD |
| GND | 4 | Red | NC | GND |
| GND | 5 | Green | 5 | GND |
| RxD | 6 | Yellow | 3 | TxD |
| DSR | 7 | Brown | 4 | DTR |
| Rx-RF-Power | 8 | White/Grey | 9 | -- |

Figure C-8: RS-232 Console cable for iDirect Non-OpenAMIP VSAT modem

C.2.2 Console port settings

The iDirect modem must be configured to use following console port settings:

- Baud rate: 9600
- Data bits: 8
- Parity: None
- Stop bit: 1

Passwords

The SAILOR 900 VSAT ACU will log in to the modem using root and user passwords. The default passwords are:

- Root: P@55w0rd!
- User: iDirect

Supported commands

After login to the modem the ACU will issue commands to the modem every second. The following commands are supported by the SAILOR 900 ACU:

- rx snr
- options show FREQ_TRANS
- rx freq
- tx freq
- latlong <lat> <long>

The signal strength command: rx snr is issued every 2 seconds. The rest of the commands are issued one by one every 2 seconds between each signal strength command. Meaning each of the other commands is issued every 8 seconds.

The signal strength in the ACU display and web interface is shown as dB., e.g: 8.5 dB. The minimum value for Internet connection is around 2-3 dB.

VSAT modem option file

The option file of the VSAT modem must also include the following information:

| Section in option file | Description |
|-----------------------------|--|
| Satellite information | Receive frequency of the transponder. Used with “rx freq” command Transmit frequency if known otherwise just a dummy tx frequency (e.g. 1.000 MHz). Used with “tx freq” command. |
| SAILOR 900 VSAT information | <p>The modem needs to use following up and down conversion frequencies for rx and tx. Used with “options show FREQ_TRANS” command. The SAILOR 900 VSAT has O-Type LNBs (Co-Pol & X-Pol) with following Local Oscillator (LO) down conversion frequencies:</p> <ul style="list-style-type: none"> – 9.75 GHz – 10.25 GHz – 10.75 GHz – 11.25 GHz <p>The SAILOR 900 VSAT has an extended 8 Watt BUC with LO up conversion frequency of 12.8 GHz.</p> |
| GPS | <p>The iDirect modem must be set to mobile unit and receive the GPS information from the ACU with the command “latlong <lat> <long>”.</p> <p>Tx handshake must be disabled in the iDirect modem.</p> |
| Rx 10 MHz | The SAILOR 900 VSAT can work either using the Rx 10 MHz reference signal provided by the VSAT modem or using its own built-in 10 MHz reference signal. It is recommended to use the 10 MHz reference signal from the modem’s rx connector. |
| Tx 10 MHz | The SAILOR 900 VSAT needs the Tx 10 MHz reference signal in order to allow TX ON. |

Figure C-9: Requirements for VSAT modem option file, Non-OpenAMIP

C.2.3 Configuration examples (Non-OpenAMIP)

Examples of modem profile and satellite configuration from the ACU web MMI are shown in the figures below.

EDIT VSAT MODEM PROFILE

Profile name: X5 (non-OpenAMIP)

VSAT modem: iDirect Evolution X5 Series

This modem profile is used on: 1 satellite profile

VSAT modem root password: P@55w0rd!

VSAT modem user password: iDirect

OpenAMIP IP address: 0.0.0.0

OpenAMIP port: 0

Apply Cancel

Figure C-10: VSAT modem profile, Non-OpenAMIP (example)

EDIT SATELLITE PROFILE

Satellite profile name: HM-X5 (Non-OpenAMIP)

VSAT modem profile: HM-X5 (non-OpenAMIP)

Apply Cancel

Satellite position: 7 E °

Polarisation skew: 0 °

Maximum inclination: 0 °

RX polarisation: ☒ Horizontal ☐ Vertical

TX polarisation: ☐ Co-pol ☒ X-pol

Tracking

RX frequency: ☒ VSAT modem ☐ User defined

0 GHz

☐ DVB-S / DVB-S2

Symbol rate: 0 MS/s

MID: 0

☐ DVB power

☒ Narrow band

☐ VSAT modem RSSI

Apply Cancel

Figure C-11: Satellite profile, Non-OpenAMIP (example)

C.3 Setup of Comtech 570L, ROSS box & ACU

C.3.1 Protocols and interfaces

The following sections describe how to connect an ACU, a Comtech570L VSAT modem, a ROSS box and an Ethernet switch.

Connections

Connect the ACU and Comtech 570L, ROSS box and Ethernet switch with the following cables:

- Ethernet cables for TCP/IP data communication (x3)
- RS-232 console cable
- 75 RF cables F-F connectors for rx and tx frequencies.




Figure C-12: Connecting Comtech 570L and ROSS box to the ACU (example)

See also *Connecting a Comtech 570 L or 625 Satellite Modem* on page 4-11 and cable specifications at *Modem Cable Comtech Serial & RSSI TT7016A* on page B-2.

DVB S satellites

This appendix contains DVB-S satellite data for azimuth calibration of the SAILOR 900 VSAT.






| VSAT coverage | Satellite name | Satellite position | RX polarisation | RX frequency | Symbol rate | NID |
|---|---|--------------------|--------------------------|--------------------------|----------------------------|----------|
| Americas  | SatMex6 Transponder Backup | 133°WE | Horizontal Horizontal | 12.800 GHz 11.680 GHz | 25.635 MS/s 2.170 MS/s | 51 0 |
| USA  | SES Transponder Backup | 101°W | Vertical Horizontal | 12.120 GHz 11.860 GHz | 30 MS/s 30 MS/s | 0 0 |
| South East Asia  | NSS6 Transponder Backup | 95°E | Vertical Vertical | 11.542 GHz 11.680 GHz | 43.200 MS/s 28.800 MS/s | 0 0 |
| Europe  | Thor 5 T2 Transponder Backup | 0.8°W | Horizontal Vertical | 11.785 GHz 12.418 GHz | 30.000 MS/s 28.000 MS/s | 70 70 |
|  | Astra2 Transponder Backup | 28.2°W | Horizontal Vertical | 11.785 GHz 12.418 GHz | 30.000 MS/s 28.000 MS/s | 70 70 |

Table D-1: DVB-S satellites for azimuth calibration



| VSAT coverage | Satellite name | Satellite position | RX polarisation | RX frequency | Symbol rate | NID |
|---|-----------------------|--------------------|--------------------------|--------------------------|----------------------------|----------|
|  | China | 134°E | | | | |
| | Transponder Backup | | Horizontal Vertical | 12.435 GHz 12.675 GHz | 27.500 MS/s 27.500 MS/s | 65 65 |
|  | Australia | 160°E | | | | |
| | Transponder Backup | 45°skew | Horizontal Horizontal | 12.391 GHz 12.407 GHz | 12.600 MS/s 12.600 MS/s | 0 0 |

Table D-1: DVB-S satellites for azimuth calibration (Continued)

For satellite data of other regions or transponders see www.lyngsat.com.

Example:



| Freq. Tp | Provider Name Channel Name | System Encryption | SR-FEC SID-VPID | ONID-TID APID Lang. | Beam EIRP (dBW) C/N lock | Source Updated |
|------------------|--|---|--|------------------------|--------------------------------|---------------------|
| 11038 V tp 38 |  <u>Canal +</u> |  | DVB-S Mediaguard 2 Nagravision 3 | 22000-5/6 1-1038 | Europe 51 6.5 | D Shimoni 111119 |

Figure D-1: Satellite data, example from www.lyngsat.com

The above transponder has following parameters:

- Frequency: 11.038 GHz
- Polarisation: V-Vertical
- Symbol Rate: 22.000 MS/s
- NID: 1
- Coverage: Europe.

Grounding and RF protection

E.1 Why is grounding required?

E.1.1 Reasons for grounding

Grounding the SAILOR 900 VSAT system is required for at least two reasons:

- Safety: Lightning protection of persons and equipment.
- Protection: ESD (ElectroStatic Discharge) protection of equipment.

E.1.2 Safety

First of all grounding of the system is required for safety reasons. In the event of a lightning strike at the ADU a proper grounding of the system will provide a low resistance path to divert the strike discharge to seawater.

E.1.3 ESD Protection

The ESD protection circuits in the ACU rely on proper grounding of the system in order to work properly. Otherwise sensitive circuits within the ACU might be damaged due to ESD when you are handling the equipment.

E.2 Grounding Recommendations

E.2.1 Grounding the ACU

The ACU should be grounded to the ship/hull. For this purpose you may use a short ADU cable and a grounding kit. Further, the ACU must be grounded at its grounding stud in order to ensure proper grounding if the short ADU cable is disconnected. For further information, see *Grounding the terminal* on page 2-33.

If you are using the Extended cable support, make the ground connections through the cable support. You may need to extend the ground plane using copper foil, see the following section.

Extending the ground plane

In some cases it may not be possible to access the hull and at the same time place the ACU in a suitable place.

A way to insure good grounding and at the same time make it possible to ground the coax cable - is to extend the ship ground plane by means of copper foil. The maximum length of the foil is determined by the width of the foil:

Copper foil 5 cm wide: Max 50 cm

Copper foil 10 cm wide: Max 100 cm

Copper foil 20 cm wide: Max 200 cm

Note The foil must be at least 0.1 mm thick.

Connect the foil to the hull by plenty of screws or hard-soldering. Run the foil past the place where the short ADU cable is to be grounded and mount a grounding kit on top of the foil.




Figure E-1: Extending the ground plane

E.2.2 Grounding the ADU

You can ground the ADU to the ship/hull via one or more of its mounting bolts. Make sure to remove painting, dirt, grease etc. at the mounting holes in order to make good electrical contact to the hull. Use serrated washers when securing the mounting bolts and seal the joint with protective coating to avoid corrosion.




Figure E-2: Grounding the ADU

It is always recommended to establish the shortest possible grounding path e.g. on steel hulls the ADU should be grounded directly to the hull¹. However, due to the fact that this is not possible on e.g. fiberglass hulls (nor is it preferable on aluminum hulls) a number of alternative grounding methods are suggested in the following paragraphs.

1. Please note that the ADU ground connection is made at the same electrical ground potential as the ACU.

E.3 Alternative grounding for steel hulls

The following guidelines assume a two-wire, isolated grounding arrangement; that is no part of the circuit, in particular the battery negative, is connected to any ground potential or equipment.

E.3.1 Grounding the ACU

The ACU must be grounded to the ship with the short cable. Further, the ACU must be grounded at its grounding stud in order to ensure a proper grounding if the short ADU cable is disconnected.

The ground connection can be established either at the hull (recommended) or at a dedicated RF ground if available (alternative). However, bear in mind that the ADU ground connection is to be made at the **same electrical ground potential as the ACU** (see *Grounding the ADU*).

The ACU provides galvanic isolation (as required) from its input power terminals to the chassis/grounding stud. This way the isolated grounding arrangement is maintained.

E.3.2 Grounding the ADU

Terminal grounded at the hull (recommended)

In this case the ADU is grounded to the ship via one (or more) of its mounting bolts. Make sure to remove painting, dirt, grease etc. at the mounting holes in order to make good electrical contact to the hull. Use serrated washers when securing the mounting bolts and seal the joint with protective coating to avoid corrosion.

Terminal grounded at a dedicated RF ground (alternative)

In this case the ADU is grounded with a separate ground cable. The ground cable must be routed parallel and close to the shielded coax cable connecting the ADU to the ACU grounding kit. A tinned heavy gauge wire (min. 6 mm²) can be used for this purpose.

Note

The ADU must be electrically isolated at its mounting bolts by means of shoulder bushings and washers ensuring the isolated RF ground - see *Isolation of the ADU from the mounting base* on page E-10.




Figure E-3: Grounding at a dedicated RF ground (alternative)

E.4 Alternative grounding for aluminum hulls

The following guidelines assume a two-wire, isolated grounding arrangement; that is no part of the circuit, in particular the battery negative, is connected to any ground potential or equipment.

E.4.1 Grounding the ACU

The ACU must be grounded with the short cable. Further, the ACU must be grounded at its grounding stud to ensure a proper grounding if the short ADU cable is disconnected.

The ground connection must be established at a dedicated RF ground (either capacitively or electrically coupled). Remember to make the ADU ground connection at the **same electrical ground potential** as the ACU (see *Grounding the ADU*).

The ACU provides galvanic isolation (as required) from its input power terminals to the chassis/grounding stud. This way the isolated grounding arrangement is maintained.

E.4.2 Grounding the ADU

If the mounting base of the ADU is electrically connected to the hull (or any other ground potential than the ACU), the ADU must be isolated at its mounting bolts by means of shoulder bushings and washers, see E.6.3. This is done in order to prevent DC currents flowing in the hull thus causing electrolytic corrosion.

However, a ground connection must be established via one of the mounting bolts using a separate ground cable. The ground cable must be routed parallel and in close

proximity to the shielded coax cable hence connecting the ADU to the ACU Grounding kit. A tinned heavy gauge wire (min. 6 mm²) can be used for this purpose.




Figure E-4: Alternative grounding for aluminium hulls

E.5 Alternative grounding for fiberglass hulls

E.5.1 Grounding the ACU

The ACU must be grounded with the short ADU cable and a grounding kit (available from Thrane & Thrane). Further, the ACU must be grounded at its grounding stud in order to ensure a proper grounding if the short ADU cable is disconnected.

The ground connection must be established at a dedicated RF ground (either capacitive or electrical coupled). Bear in mind that the ADU ground connection is to be made at the **same electrical ground potential** as the ACU (see *Grounding the ADU*).

E.5.2 Grounding the ADU

If the mounting base of the ADU is electrically connected to any other ground potential than the ACU (e.g. Lightning Ground), the ADU must be isolated at its mounting bolts by means of shoulder bushings and washers - see page E-10.

However, a ground connection must be established via one of the mounting bolts using a separate ground cable. The ground cable must be routed parallel and in close

proximity to the shielded coax cable hence connecting the ADU to the ACU Grounding kit. A tinned heavy gauge wire (min. 6 mm²) can be used for this purpose.




Figure E-5: Alternative grounding for fiberglass hulls

E.6 Separate ground cable

E.6.1 Ground cable - construction

When dealing with electrical installations in a marine environment, all wiring must be done with double insulated, tinned, high quality and if exposed also UV resistant cables. This shall also apply to the separate ground cable mentioned in the previous paragraphs.

The ground cable is constructed using an appropriate cable with a cross section area of at least 6 mm² (AWG10) and terminated with insulated ring crimp terminals – see illustration below. The crimp terminals must be a marine approved type e.g. the DuraSeal series from Raychem.




Figure E-6: Separate ground cable

E.6.2 Ground cable - connection

Mount the ground cable close to and parallel to the shielded coax cable thus minimizing ground loop problems. If possible, route the coax cable and the ground cable in metal conduits bonded to the hull or within a mast (depending on the actual installation).

The ground cable must be connected at one of the mounting/grounding bolts on the ADU. Use bolts and washers of stainless steel and seal the joint with protective coating to avoid corrosion. If the ADU is to be isolated from the mounting base, shoulder bushings and washers must be used – see figure E-7, *Isolation of the ADU from the mounting base* on page E-10.

At the other end, connect the ground cable as described in *Grounding the ACU* on page E-2.

E.6.3 Isolation of the ADU from the mounting base

In cases where the ADU is to be isolated from the mounting base, shoulder bushings and washers (accessories) must be used as illustrated below. Please note that the isolation has to be implemented on all four mounting bolts (including the bolt securing the ground cable).




Figure E-7: Isolation of the ADU from the mounting base

The ground cable must be connected at one of the mounting/grounding bolts on the ADU as illustrated below. Remember to seal the joint with protective coating to avoid corrosion.




Figure E-8: ADU isolation and grounding cable

E.7 RF interference

Interference induced from nearby high-power RF transmitters might cause system failures and in extreme cases permanent damage to the SAILOR 900 VSAT equipment. If there are problems with interference from HF transmitters, it is advisable to mount ferrite clamps on the coax cable in order to provide suppression of induced RF. The ferrites will have no effect on the differential-mode signals but increases the impedance in relation to common-mode RFI.

E.7.1 Recommendations

Use 1-5 pcs. hinged clamp cores (e.g. the RFC or SFC series from Kitagawa) mounted on the ADU cable near the ADU.

System messages

F.1 Event messages – overview

The SAILOR 900 VSAT detects events during

- POST (Power On Self Test) – a self test performed at every power-up.
- Self test – started in the web interface
- CM (Continuous Monitoring) – continuous monitoring while the system is in operation.

When the SAILOR 900 VSAT detects an event that requires your action, it issues an event message and the red Fail/Pass LED in the LED panel of the ACU is lit. As long as an event is active, it is shown in the ACU display and the web interface (in HELPDESK > Event list or click the event icon on the DASHBOARD).

Note

Active events and notifications are shown. As soon as the event is cleared, it is not displayed any longer. Notifications are cleared after 24 hours.

State the Event ID when contacting your service partner.

The event description might contain a number of digits in brackets, e.g. (0000000005). This is supplemental information and used for service and diagnostics purposes.

F.2 List of ADU events

| Error code (ID) | Unit | Severity | Description | Explanation |
|-----------------|---------|----------|----------------------|--|
| 0a001-0 | Antenna | ERROR | Production data | Production data is invalid |
| 0a002-0 | Antenna | ERROR | XIM internal | Antenna configuration data stored in the PCM module is invalid |
| 0a003-0 | Antenna | ERROR | XIM external | Antenna configuration data stored in the VIM module is invalid |
| 0a004-0 | Antenna | ERROR | XIM I/X match | Antenna configuration data stored in the PCM module does not match the configuration data stored in the VIM module |
| 0a005-0 | Antenna | ERROR | Antenna type | The configuration antenna type is unsupported or unknown |
| 0a006-0 | Antenna | ERROR | PCM FPGA load | The PCM FPGA cannot be initialised and loaded correctly |
| 0a007-0 | Antenna | ERROR | VIM FPGA load | The VIM FPGA cannot be initialised and loaded correctly |
| 0a008-0 | Antenna | ERROR | XIM production | Production/calibration data stored in the VIM module is invalid |
| 0a010-0 | Antenna | ERROR | GPS initialisation | The GNSS device cannot be initialised. Check cable and GNSS device |
| 0a020-0 | Antenna | ERROR | AMB device discovery | Missing one or more of the following devices: ISM, DDM and PMM. Check cables. |
| 0a021-0 | Antenna | ERROR | Azi DDM ABS device | Cannot initialise the azimuth DDM |
| 0a022-0 | Antenna | ERROR | Xel DDM ABS device | Cannot initialise the cross-elevation DDM |
| 0a023-0 | Antenna | ERROR | Ele DDM ABS device | Cannot initialise the elevation DDM |
| 0a024-0 | Antenna | ERROR | ISM ABS device | Cannot initialise the ISM |

Table F-1: ADU event messages

| Error code (ID) | Unit | Severity | Description | Explanation |
|-----------------|---------|----------|----------------------|---|
| 0a025-0 | Antenna | ERROR | PMM ABS device | Cannot initialise the azimuth PMM |
| 0a030-0 | Antenna | ERROR | Sensor sanity | Too many invalid values measured by the ISM during initialisation. Check for vibrations or malfunctioning ISM. |
| 0a033-0 | Antenna | ERROR | Azi axis calibration | Zero reference point (hall sensor) not found on azimuth axis. Check azimuth belt and hall sensor including magnet |
| 0a034-0 | Antenna | ERROR | Xel axis calibration | End stops of the cross-elevation axis not found at expected locations. Check belt and end stops. |
| 0a035-0 | Antenna | ERROR | Ele axis calibration | End stops of the elevation axis not found at expected locations. Check belt and end stops. |
| 0a036-0 | Antenna | ERROR | Pol axis calibration | Zero reference point (hall sensor) not found on polarisation axis. Check movement of the polarisation unit and the hall sensor including magnet |
| 0a037-0 | Antenna | ERROR | Antenna calibration | One or more errors occurred during antenna start-up |
| 0a040-0 | Antenna | ERROR | Demodulator load | The second receiver demodulator cannot be initialised and loaded correctly |
| 0a041-0 | Antenna | ERROR | VIM PLL lock | The PLL on the VIM does not lock. |
| 0a042-0 | Antenna | ERROR | ISM calibration data | The ISM calibration data is invalid. The ISM should be replaced. |
| 0a043-0 | Antenna | ERROR | ABS software version | The ABS software version in the antenna is too old to match the hardware requirements. Upgrade to newer/newest software version. |
| 0a052-0 | Antenna | WARNING | ACU communication | The communication link between ACU and antenna is down |

Table F-1: ADU event messages (Continued)

| Error code (ID) | Unit | Severity | Description | Explanation |
|-----------------|---------|----------|---------------------|--|
| 0a053-0 | Antenna | WARNING | ISM data valid | Sensor measurements from the ISM are invalid. This indicates a malfunctioning ISM |
| 0a054-0 | Antenna | WARNING | ISM data range | Sensor measurements from the ISM are out of range |
| 0a055-0 | Antenna | WARNING | GNSS communication | Lost connection to the GNSS device |
| 0a056-0 | Antenna | WARNING | GNSS data range | Received information from the GNSS device which is out of range |
| 0a057-0 | Antenna | WARNING | GNSS device warning | Local GNSS device warning |
| 0a058-0 | Antenna | WARNING | GNSS device error | Local GNSS device error |
| 0a059-0 | Antenna | ERROR | Azi DDM shutdown | The azimuth motor control has detected one of the following situations: Extreme temperature, voltage, current or velocity. The motor was then shut down. This is usually a temporary situation and is probably fixed by a restart of the system. |
| 0a060-0 | Antenna | ERROR | Xel DDM shutdown | As Azi DDM shutdown but detected by the cross-elevation motor control. |
| 0a061-0 | Antenna | ERROR | Ele DDM shutdown | As Azi DDM shutdown but detected by the elevation motor control. |
| 0a062-0 | Antenna | ERROR | PMM shutdown | As Azi DDM shutdown but detected by the polarisation motor control. |
| 0a063-0 | Antenna | WARNING | AMB timing | This indicates a busy situation. It may occur during installation procedures. No user interaction is required. |
| 0a064-0 | Antenna | WARNING | VIM cable attn | The output power cannot be controlled correctly. Check the Tx chain |

Table F-1: ADU event messages (Continued)

| Error code (ID) | Unit | Severity | Description | Explanation |
|-----------------|---------|----------|------------------|--|
| 0a065-0 | Antenna | WARNING | BUC voltage low | The voltage for the BUC is too low probably caused by a malfunctioning VIM or BUC |
| 0a066-0 | Antenna | WARNING | BUC voltage high | The voltage for the BUC is too high probably caused by a malfunctioning VIM |
| 0a067-0 | Antenna | WARNING | LNB voltage low | The voltage for the LNB is too low probably caused by a malfunctioning VIM or LNB |
| 0a068-0 | Antenna | WARNING | LNB voltage high | The voltage for the LNB is too high probably caused by a malfunctioning VIM |
| 0a069-0 | Antenna | WARNING | PMM fan | The fan is not working or the tachometer input from the fan is not connected. Check cable and fan. |
| 0a070-0 | Antenna | WARNING | OMT temperature | The temperature of the BUC is too high. Check if fan is working. |
| 0a071-0 | Antenna | ERROR | VIM PLL lock | The PLL of the VIM is out of lock. Check the 10 MHz reference signal. |
| 0a072-0 | Antenna | WARNING | VIM tuner lock | The PLL of the second receiver (DVB) is out of lock. Check the 10 MHz reference signal |
| 0a073-0 | Antenna | WARNING | Azi encoder slip | A slip of the azimuth encoder has been detected. No user interaction is required unless this is a permanent situation in which case the belt and encoder of the azimuth axis must be checked |
| 0a074-0 | Antenna | WARNING | Xel encoder slip | A slip of the cross-elevation encoder has been detected. No user interaction is required unless this is a permanent situation in which case the belt and encoder of the cross-elevation axis must be checked |

Table F-1: ADU event messages (Continued)

| Error code (ID) | Unit | Severity | Description | Explanation |
|-----------------|---------|----------|-----------------------|--|
| 0a075-0 | Antenna | WARNING | Ele encoder slip | A slip of the elevation encoder has been detected. No user interaction is required unless this is a permanent situation in which case the belt and encoder of the elevation axis must be checked |
| 0a076-0 | Antenna | WARNING | Pol encoder slip | A slip of the polarisation encoder has been detected. No user interaction is required unless this is a permanent situation in which case the encoder of the polarisation axis must be checked |
| 0a077-0 | Antenna | WARNING | GNSS position | No position available from the GNSS device or position too old. |
| 0a078-0 | Antenna | WARNING | GNSS velocity | No velocity available from the GNSS device |
| 0a079-0 | Antenna | ERROR | Heading data | Heading information is missing in the antenna |
| 0a080-0 | Antenna | ERROR | Azi DDM communication | Communication error between PCM and azimuth DDM. Check cable. |
| 0a081-0 | Antenna | ERROR | Xel DDM communication | Communication error between PCM and cross-elevation DDM. Check cable. |
| 0a082-0 | Antenna | ERROR | Ele DDM communication | Communication error between PCM and elevation DDM. Check cable. |
| 0a083-0 | Antenna | ERROR | ISM communication | Communication error between PCM and ISM. Check cable. |
| 0a084-0 | Antenna | ERROR | PMM communication | Communication error between PCM and PMM. Check cable. |
| 0a085-0 | Antenna | WARNING | Azi DDM warning | The azimuth motor controller has temporarily observed an unusual situation with regards to temperature, voltage, current or velocity. No user interaction required. |

Table F-1: ADU event messages (Continued)

| Error code (ID) | Unit | Severity | Description | Explanation |
|-----------------|---------|----------|-----------------|---|
| 0a086-0 | Antenna | WARNING | Xel DDM warning | The cross-elevation motor controller has temporarily observed an unusual situation with regards to temperature, voltage, current or velocity. No user interaction required. |
| 0a087-0 | Antenna | WARNING | Ele DDM warning | The elevation motor controller has temporarily observed an unusual situation with regards to temperature, voltage, current or velocity. No user interaction required. |
| 0a088-0 | Antenna | WARNING | PMM warning | The polarisation motor controller has temporarily observed an unusual situation with regards to temperature, voltage, current or velocity. No user interaction required. |
| 0a089-0 | Antenna | WARNING | Azi cal. limits | Azimuth axis calibration result check limits exceeded. Pointing performance may be degraded. |
| 0a090-0 | Antenna | WARNING | Xel cal. limits | Cross-elevation axis calibration result check limits exceeded. Pointing performance may be degraded. |
| 0a091-0 | Antenna | WARNING | Ele cal. limits | Elevation axis calibration result check limits exceeded. Pointing performance may be degraded. |
| 0a092-0 | Antenna | WARNING | Pol cal. limits | Polarisation axis calibration result check limits exceeded. Pointing performance may be degraded. |

Table F-1: ADU event messages (Continued)

| Error code (ID) | Unit | Severity | Description | Explanation |
|-----------------|---------|----------|---------------|--|
| 0a093-0 | Antenna | WARNING | ISM warning | The ISM has temporarily observed an unusual situation with regards to temperature or voltage. No user interaction required. If repeated after cooldown and reboot, the ISM or cables around it may be defective. |
| 0a094-0 | Antenna | WARNING | Low elevation | The antenna can not point at the satellite, because the elevation is too low. |

Table F-1: ADU event messages (Continued)

F.3 List of ACU events

| Error code (ID) | ACU PCB | Severity | Description | Explanation |
|-----------------|---------|----------|-------------------------------|--|
| 08100-0 | ADM | ERROR | PSM low voltage (22 V) | The ADM measures a different ADU voltage than expected. If the problem is not solved by a restart, and the PSM is not reporting any errors, the ADM is probably defect. |
| 08101-0 | ADM | ERROR | PSM high voltage (48 V) | The ADM measures a different ADU voltage than expected. Check for short circuit of the antenna coax connector. If the problem is not solved by a restart, and the PSM is not reporting any errors, the ADM is probably defective. |
| 08102-0 | ADM | ERROR | PSM 5 V power | Internal voltage supply error of the ADM. |
| 08103-0 | ADM | ERROR | ADM hotswap | The ACU is not able to supply the correct voltage to the antenna. Check for short circuits in coax cable and the antenna |
| 08104-0 | ADM | ERROR | ADU communication | The ACU cannot communicate with the antenna. Check cable and antenna. |
| 08107-0 | ADM | ERROR | ADM FPGA load | The ADM FPGA cannot be initialised and loaded |
| 08108-0 | ADM | ERROR | TX Power Detector calibration | The Tx power detector calibration is not valid. |
| 08109-0 | ADM | ERROR | ADU XIM data | There is a mismatch with the antenna configuration data. Either the PCM or the VIM in the antenna are malfunctioning or one of them has been replaced. In the latter case, please select which is the original device in the web MMI and restart the system. |
| 0810a-0 | ADM | ERROR | ADM production data | Production data has been corrupted |

Table F-2: ACU event messages

| Error code (ID) | ACU PCB | Severity | Description | Explanation |
|-----------------|---------|----------|-----------------------|---|
| 0810b-0 | ADM | ERROR | ADU software version | Some error occurred during upload of software to the ADU, which means that the ADU software version is not as expected. Either the software in the ACU, does not meet the minimum version required by the ADU, the software image in the ACU is corrupted or the upload procedure failed because of an communication error. |
| 0810c-0 | ADM | ERROR | File system integrity | One or more file system partitions are corrupt. You may have lost your settings and collected statistics. If restarting the system does not help, contact your service technician. |
| 09000-0 | KDM | ERROR | KDM 3V3 supply | Internal 3V3 voltage supply error in the KDM |
| 09001-0 | KDM | ERROR | KDM 12V supply | Internal 12V voltage supply error in the KDM |
| 09002-0 | KDM | ERROR | KDM display | Display hardware error in the KDM |
| 09010-0 | KDM | ERROR | KDM link/SW version | Link to the KDM module could not be established. Either the KDM board is malfunctioning, or - if the system software has just been updated - the SW is too old and is not compatible with the PSM hardware. |
| 0b000-0 | PSM | ERROR | PSM production data | Missing or invalid production data in the PSM. It should be replaced. |
| 0b001-0 | PSM | ERROR | NMEA 2000 identifier | Missing or invalid production data in the PSM. It should be replaced. |
| 0b010-0 | PSM | ERROR | PSM link/SW version | Link to the PSM module could not be established. Either the PSM board is malfunctioning, or - if the system software has just been updated - the SW is too old and is not compatible with the PSM hardware. |

Table F-2: ACU event messages (Continued)

| Error code (ID) | ACU PCB | Severity | Description | Explanation |
|-----------------|---------|----------|--------------------------|---|
| 08060-0 | ADM | WARNING | ADU modem | ACU/ADU communication error detected (framing and parity). If the situation is persistent, check if cable specifications comply (length and attenuation). |
| 08061-0 | ADM | WARNING | VMU linux shell password | The specified password (root) for the VSAT modem is not accepted by the modem |
| 08062-0 | ADM | WARNING | VMU debug shell password | The specified password (user) for the VSAT modem is not accepted by the modem |
| 08063-0 | ADM | ERROR | ADU connection | The ACU has lost connection with the antenna |
| 08064-0 | ADM | ERROR | ADM PLL lock | The intermediate frequency PLL is not in lock. Check the 10 MHz reference signal |
| 08065-0 | ADM | WARNING | GNSS data | Missing GPS data (fix) |
| 08066-0 | ADM | WARNING | Heading data | Missing heading information. Check cable and heading provider device. |
| 08067-0 | ADM | ERROR | PCB temperature | ADM temperature too high. The ACU is not equipped with a fan, so make sure environmental specifications comply |
| 08068-0 | ADM | ERROR | PSM power | The PSM fails to provide the requested supply voltage |
| 08069-0 | ADM | WARNING | Blocking Zone | The antenna has entered a blocking zone |
| 0806a-0 | ADM | WARNING | VMU connection | The ACU has lost connection with the VSAT modem |
| 0806b-0 | ADM | WARNING | ROSS connection | The ACU has lost connection with the ROSS device |

Table F-2: ACU event messages (Continued)

| Error code (ID) | ACU PCB | Severity | Description | Explanation |
|-----------------|---------|----------|-------------------------|---|
| 0806c-0 | ADM | ERROR | VMU frequency setup | There is a mismatch in the frequency setup. Probably the VSAT modem is not configured correctly to match the requirements of the ACU and antenna. A common mismatch is the absence of Rx or Tx LO parameter in the VSAT modem. |
| 0806d-0 | ADM | ERROR | ADU power | The ADU supply voltage is outside the allowed limits. This could happen if the PSM fails to provide the requested supply voltage or if the voltage difference across the hotswap is unacceptable high. |
| 0806e-0 | ADM | ERROR | VMU RX 10 MHz reference | The VMU 10 MHz reference signal is not present. Make sure VMU Rx cable is connected and that the VMU is configured to output the RX 10 MHz reference signal. |
| 0806f-0 | ADM | ERROR | ROSS synchronization | The ACU has become out of sync with the ROSS device, most likely because the ACU has been replaced, or the ROSS satellite profile is new. A manual (forced) handoff sequence must be initiated from the ROSS, refer to the ROSS manual for the procedure. |
| 0b060-0 | PSM | WARNING | NMEA 0183 parse error | Parse errors detected on the NMEA 0183 interface. Check NMEA 0183 cable, signal levels etc. |

Table F-2: ACU event messages (Continued)

A

| | |
|-----|-----------------------------------|
| ABS | Term used for service and support |
| ACU | Antenna Control Unit |
| ADM | Term for an ACU module |
| AMB | Term used for service and support |

B

| | |
|-----|---|
| BUC | Block Up Converter - The BUC can be thought of the “transmitter”, and its actions are effectively the direct opposite to the LNB. The BUC consists of the Up Converter and HPA. |
|-----|---|

C

| | |
|----|---|
| CE | Conformité Européenne. This term signifies that a CE certified product conforms to European health, environmental, and safety regulations. In short, it makes the product legal to be sold in the European Union. |
| CM | Continuous Monitoring |

D

| | |
|------|--|
| DDM | DC-Motor Driven Module |
| DHCP | Dynamic Host Configuration Protocol. A protocol for assigning dynamic IP addresses to devices on a network. With dynamic addressing, a device can have a different IP address every time it connects to the network. |
| DNS | Domain Name System. A system translating server names (URLs) to server addresses. |
| DVB | Digital Video Broadcasting, a set of standards relating to digital television. |

E

| | |
|------|---|
| EIRP | Effective Isotropically-Radiated Power. The amount of power that would have to be emitted by an isotropic antenna (that evenly distributes power in all directions) to produce the peak power density observed in |
|------|---|

the direction of maximum antenna gain.

ESD ElectroStatic Discharge

ETSI European Telecommunication Standard Institute

F

FPGA Field Programmable Gate Array

G

GNSS Global Navigation Satellite System

GPL General Public License

GPS Global Positioning System. A system of satellites, computers, and receivers that is able to determine the latitude and longitude of a receiver on Earth by calculating the time difference for signals from different satellites to reach the receiver.

I

IEC International Electrotechnical Commission. The international standards and conformity assessment body for all fields of electrotechnology.

ISM Inertial Sensor Module

K

KDM Term for an ACU module

L

LAN Local Area Network

LEN Load Equivalent Number

LGPL Lesser General Public License

LNB Low Noise Block. A device used to amplify or boost the weak received signal without amplifying the noise signals (hence the “low noise” part of LNB) and to convert the high frequencies of the signal into lower frequencies, a process called down converting, for conveyance to the indoor equipment (demodulator) for processing.

N

NID Network IDentification

NMEA National Marine Electronics Association (standard). A combined electrical and data specification for communication between marine electronic devices such as echo sounder, sonars, anemometer (wind speed and direction), gyrocompass, autopilot, GPS receivers and many other types of instruments. It has been defined by, and is controlled by, the U.S.-based National Marine Electronics Association.

O

OMT Ortho Mode Transducer

openAMIP Open Antenna-Modem Interface Protocol, facilitates the exchange of information between an ACU and a satellite router. It allows the router to command the antenna and enables automatic beam switching (ABS).

P

PAST Person Activated Self Test

PCM Pedestal Control Module

PMM Polarisation Motor Module

POST Power On Self Test. A system test that is activated each time the system is powered on.

PSM Term for an ACU module

R

RF Radio Frequency. Electromagnetic wave frequencies between about 3 kilohertz and about 300 gigahertz including the frequencies used for communications signals (radio, television, cell-phone and satellite transmissions) or radar signals.

RFI Radio Frequency Interference. A non-desired radio signal which creates noise or dropouts in the wireless system or noise in a sound system.

ROSS Roaming Oceanic Satellite Server

RSSI Received Signal Strength Indicator

V

| | |
|------|---|
| VIM | VSAT Interface Module |
| VMU | VSAT Modem Unit |
| VSAT | Very Small Aperture Terminal, a two-way satellite ground station or a stabilized maritime VSAT antenna with a dish antenna that is smaller than 3 metres. |

W

| | |
|-----|-------------------|
| WAN | Wide Area Network |
|-----|-------------------|

X

| | |
|-----|-----------------------------------|
| XIM | Term used for service and support |
|-----|-----------------------------------|

Z

| | |
|-----|-----------------------|
| ZRM | Zero Reference Module |
|-----|-----------------------|

Numerics

10 MHz reference, 6-19

A

access

limit, 6-32

accessories available, 2-10

ACU

description, 2-6

LED, 9-7

ACU (bulkhead)

grounding, 3-25

installing, 3-24

ACU bulkhead

connector panel, overview, 4-2

LEDs, display and keypad, 4-1

ACU display

description, 6-34

ACU events, F-9

ACU interfaces, 2-7

ACU menus

quick guide, 8-2

ACU rack version

connector panel, overview, 4-2

grounding, 3-28

installing, 3-27

LEDs, display and keypad, 4-1

administration

settings, 6-30

administrator

log off, 6-32

login, 6-30

password, change, 6-31

password, reset, 6-31

ADU

connector, 4-4

description, 2-3

ADU cable

alternatives, 3-23

connection, 3-21

modem attenuation, 3-23

ADU cable loop

DC-resistance, 3-23

ADU events, F-2

aluminum hulls

grounding, E-6

antenna

drainage, 3-17

grounding recommendations, E-3

installation location, 3-3

isolation from mounting base, E-10

mast design, 3-8

obstructions, 3-3

opening, 3-22

radiation, 3-6

stabilization, 2-3

Astra2 satellite, D-1

attenuation

ADU cable, 3-23

Australia satellite, D-2

azimuth calibration, 6-3

B

baud rate

NMEA 0183, 4-5

VSAT modem, 6-19

beam switching, C-2

BITE test, 9-7

blocking zones

azimuth, 3-5

elevation, 3-5

braces

mast, 2 pieces, 3-12

mast, 3 pieces, 3-11

browser settings

for web interface, 6-10

browsers supported, 6-1

C

- cable
 - Comtech 570 L or 625 Satellite Modem, 4-11
 - ground, E-9
 - iNFINITI 5000 Series Satellite Router, 4-9
 - power, 5-2
 - RS-232 to Console, 4-9
- cable loss
 - ADU cable, 3-21
- cable requirements
 - NMEA, 4-5
- cable support
 - ACU (bulkhead), 3-25
- cable type
 - LAN, 4-8
- calibration
 - azimuth, 6-3, 6-6
 - cable, 6-6
 - elevation requirements, 6-5
 - NID, 6-5
 - polarisation, 6-5
 - satellite data, 6-5, 6-16, D-1
- calibration data, 6-33
- change administrator password, 6-31
- Change network, 6-33
- China satellite, D-2
- compass safe distance, A-4
- Comtech 570 L or 625 Satellite Modem, 4-11
 - cable, 4-11
- condensation in antenna, 3-17
- configuration
 - LAN network, 6-22
 - site map, 6-8
 - step-by-step, 6-2
- configuration examples
 - Non-OpenAMIP, C-13
 - OpenAMIP, C-9
- Configuration program, 6-1
- connect
 - Comtech 570 L or 625 Satellite Modem, 4-11
 - Evolution X5 Satellite Router, 4-10
 - iNFINITI 5000 Series Satellite Router, 4-9
 - power cable, 5-4
 - web interface, 6-2

- connector
 - ADU, 4-4
 - DC, 4-3
 - DC Input, 4-3
 - LAN, 4-7
 - management PC, 4-7
 - modem control, 4-7
 - NMEA 0183/2000, 4-5
 - RS-232, 4-6
 - RS-422, 4-6
 - service port, 4-7
 - TNC, 4-4
 - VMU Rx-Tx, 4-4
 - VSAT modem, 4-7
- contact information, 9-2
- corrosion
 - smoke deposits, 3-17
- country restrictions
 - VSAT, -v
- current
 - start up peak, 5-1

D

- daily use, 8-1
- DC connector, 4-3
- DC Input
 - connector, 4-3
- default
 - reset to factory settings, 6-33
- default gateway, 6-24
- degradation
 - due to the radar, 3-15
 - Ku-band connection, 3-15
- DHCP client, 6-23
- diagnostic report, 6-29, 9-2
- display
 - ACU, description, 6-34
- distance
 - antenna to GPS receiver, 3-15
 - antenna to radar, 3-13
- DNS setup, 6-23
- drainage of antenna, 3-17
- drawing
 - ACU bulkhead, A-7
 - ACU rack version, A-8
 - ADU, A-6

DVB-S, 6-5
 DVB-S satellite data, D-1
 DVB-S2, 6-5

E

elevation angle
 minimum, 6-17
 elevation cutoff, 6-17
 E-mail setup, 6-25
 error codes, F-1
 error messages, 9-15, F-1
 ACU, F-9
 ADU, F-2
 ETSI
 elevation angle, 6-17
 event, F-1
 events
 ACU, F-9
 ADU, F-2
 list of active, 9-15
 Evolution X5 Satellite Router
 connect, 4-10

F

factory default
 calibration data, 6-33
 reset, 6-33
 FCC
 elevation angle, 6-17
 Features, 2-3
 fiberglass hulls
 grounding, E-7
 fixed heading, 6-6
 flange thickness, 3-8
 flatness, 3-8

G

gateway setup, 6-24
 GPS receiver
 distance from antenna, 3-15

grounding, E-1
 ACU (bulkhead), 3-25
 ACU rack version, 3-28
 ADU, 3-23
 aluminum hulls, E-6
 antenna, E-3
 cable, E-9
 fiberglass hulls, E-7
 recommendations, E-2
 steel hulls, E-4
 terminal, E-2
 gusset plates, 3-8

H

hatch
 remove, 3-22
 help desk number, 9-2
 changing in web interface, 9-2
 humidity in antenna, 3-17

I

impedance
 cable, 5-3
 ship, 5-2
 total, 5-2
 iNFINITI 5000 Series Satellite Router
 cable, 4-9
 connect, 4-9
 installation
 ACU (bulkhead), 3-24
 ACU rack version, 3-27
 Interfaces, 4-1, 5-1
 interference, 3-13
 from radar, 3-13
 RF, E-11
 IP address
 connecting to service port, 6-2, 9-4
 for web interface, 6-2, 9-4
 OpenAMIP modem, 6-19, 6-23
 static, 6-23

L

LAN

- cable type, 4-8
- connector, 4-7
- network setup, 6-22

LAN configuration

- default gateway, 6-24
- DHCP client, 6-23

LAN connector

- management, 4-7

LAN network

- configuration, 6-22

LED

- ACU, 9-7

license

- software, -ii

limit access to web interface, 6-32

log off

- administrator, 6-32

logon

- administrator, 6-30

M

management PC

- connect, 4-7

mast

- 2 braces, 3-12
- 3 braces, 3-11
- design, 3-8
- flange thickness, 3-8
- flatness, 3-8
- foundation, 3-8
- gusset plates, 3-8
- height, 3-8
- without braces, 3-11

mast flange, 3-8

mast for antenna, 3-8

mast length, 3-11

messages, F-1

- sent from VMU, OpenAMIP, C-4

microwave radiation, -iii

minimum elevation angle, 6-17

Model numbers, 2-10

modem

- signal level, ACU display, 6-37

modem control

- connector, 4-7

modify XIM data, 6-33

motion centre

- ship, 3-7

N

navigation, 6-9

navigation in web interface, 6-10

network

- LAN setup, 6-22

NID

- calibration, 6-5

NMEA

- cable requirements, 4-5
- connector, 4-5
- LEN, 4-5

NMEA 0183

- baud rate, 4-5

Non-Open AMIP

- examples, C-13

Non-Open-AMIP

- setup, C-10

Non-OpenAMIP

- supported commands, C-11

notifications, 9-15

NSS6 satellite, D-1

O

obstructions

- distance and size, 3-3

On/Off switch

- rack version, 4-2

OpenAMIP

- setup, C-2
- supported commands, C-4

OpenAMIP IP modem

- IP address, 6-19, 6-23

OpenAMIP keys, C-5

opening antenna, 3-22

options

- order number, 2-10

options file, C-5

- order number
 - options, 2-10
- order numbers, 2-10
- outline drawing
 - ACU bulkhead, A-7
 - ACU rack version, A-8
 - ADU, A-6

P

- PAST, 9-7
- peak current, 5-1
- permissions
 - user, 6-32
- Person Activated Self Test, 9-7
- placing the antenna, 3-3
- pole mount, 3-8
- POST, 9-7
- power
 - sources, 5-1
- power cable
 - connect, 5-4
 - selection, 5-2
- Power On Self Test, 9-7
- power supply, 2-6
- protect access to settings, 6-32
- Proxy server, disabling, 6-10

Q

- quick guide, 8-1
 - ACU menus, 8-2
 - web interface, 8-1

R

- radar
 - distance from antenna, 3-13
 - signal degradation, 3-15
- radiation, -iii
- radiation level, 3-6
- remove
 - service hatch, 3-22
- report
 - send by e-mail, 6-25

- reset, 6-40
 - ACU key, 6-34
 - factory default, 6-33
 - password, 6-31
- reset administrator password, 6-31
- reset keys on ACU, 6-40
- RF interference
 - recommendations, E-11
- RF loss
 - ADU cable, maximum, 3-21
- roll period
 - limitations, 3-7
 - mounting height, 3-7
 - ship, 3-7
- RS-232
 - connector, 4-6
- RS-232 to Console
 - cable, 4-9
- RS-422
 - connector, 4-6
- Rx-Tx
 - connector, 4-4

S

- safety summary, -iii
- samples
 - statistics, 6-26
- sampling interval, 6-26
- satellite
 - Astra2, D-1
 - Australia, D-2
 - China, D-2
 - NSS6, D-1
 - SatMex6, D-1
 - SES, D-1
 - Thor 5 T2, D-1
- satellite data, D-1, D-2
 - calibration, 6-5, 6-16
- SatMex6 satellite, D-1
- self test, 2-6, 9-3
- send e-mail
 - diagnostic report, 6-29
- service hatch
 - remove, 3-22

- service port
 - IP address (static), 6-2
 - IP address of PC, 9-4
 - rack version, 4-2
- SES satellite, D-1
- setup
 - diagnostic report, 6-29
 - e-mail, 6-25
 - for statistics report, 6-25
 - statistics report, 6-26
 - user permissions, 6-32
- shadowing, 3-3
- ship motion centre, 3-7
- signal level
 - modem, ACU display, 6-37
- site map, 6-8
- smoke deposits, 3-17
- SMTP login, 6-25
- software license, -ii
- software update, 9-4
- software version, 1-2
- source impedance
 - measuring, 5-2
- specifications, A-1
 - ACU, A-4
 - ADU, A-2
 - cable Comtech VSAT modem, B-2
 - cable iDirect VSAT modem, B-3
- spreadsheet
 - statistics report, 6-28
- start-up current, 5-1
- static IP, 6-2
- static IP address, 6-23
 - how to set up, 6-11
- statistics
 - sampling frequency, 6-26
 - send by e-mail, 6-25
- statistics report, 6-26, 6-27
 - example, 6-28
 - import into spreadsheet application, 6-28
 - setup, 6-26
- status messages, 9-7
- steel hulls
 - grounding, E-4
- support
 - contact information, 9-2

- system
 - ACU reset
 - keys to press, 6-40
- System messages, F-1
- system reset
 - ACU key, 6-34

T

- technical data, A-1
- terminal
 - grounding recommendations, E-2
- Thor 5 T2 satellite, D-1
- TNC connector, 4-4
- tools needed, 3-2
- troubleshooting
 - diagnostic report, 9-2
- TT number, 2-10

U

- updating software, 9-4
- use
 - daily, 8-1
- user permissions, 6-32
 - setup, 6-32

V

- VMU connector, 4-4
- VSAT modem
 - baud rate, 6-19
- VSAT modem option file
 - Non-OpenAMIP, C-12
 - OpenAMIP, C-5
- VSAT restrictions, -v

W

- warning messages, F-1
- warnings, 9-15

- web interface
 - browser settings, 6-10
 - connect, 6-2
 - LAN connector, 4-7
 - navigating, 6-10
- web mmi
 - LAN connector, 4-7
- Wiring, 4-1, 5-1

X

- XIM data
 - modify, 6-33

98-133400-C